



## Carriers & Cargo Hauling Accessories - Hitches & Towing - Hitch Gooseneck - Gooseneck Prep

Part Number 82213664AB

For 3500 trucks without production Gooseneck Prep package (Sales Code: AHU), install this underbed hardware to mount Gooseneck Ball and Safety Chain Tie Downs Mopar Gooseneck Trailer Hitches can be installed on trucks equipped with the factory, or dealer-installed Gooseneck/Fifth-Wheel Prep Package. Check the vehicle User Guide for hitch type, load capacity and heavy-duty equipment required. Do not exceed rated tow capacity of the vehicle as equipped. Trailer may require items not supplied by Mopar.

Gooseneck Prep

Install Time: 2.0 hrs.



Part specifications are subject to change without notice.

©2023 FCA US LLC. All Rights Reserved. Chrysler, Dodge, Jeep, Ram, Mopar and SRT are registered trademarks of FCA US LLC.

ALFA ROMEO and FIAT are registered trademarks of FCA Group Marketing S.p.A., used with permission.

03/24/2023