300 MAINTAINING YOUR VEHICLE

Chassis

Component	Fluid, Lubricant, or Genuine Part
Automatic Transmission	Mopar® ATF+4 Automatic Transmission Fluid.
Manual Transmission	Mopar® Manual Transmission Lubricant or equivalent.
Transfer Case	Mopar® ATF+4 Automatic Transmission Fluid.
Axle Differential (front-rear)	Mopar [®] Hypoid Gear Lubricant (SAE 80W-90) (API GL5) or equivalent. For trailer towing, use a SAE 75W-140 Synthetic Gear Lubricant. Models equipped with Trac-Lok require an additive.
Brake Master Cylinder	Mopar® DOT 3, SAE J1703 should be used. If DOT 3, SAE J1703 brake fluid is not available, then DOT 4 is acceptable. Use only recommended brake fluids.
Power Steering Reservoir	Mopar® ATF+4 Automatic Transmission Fluid.
Steering Gear & Linkage, Ball Joints, Prop Shafts & Yokes, Wheel Bearings	Mopar® Multi-Purpose Lubricant NLGI Grade 2 EP, GC-LB