

# 2002 CHRYSLER, DODGE MINIVAN (RS)

## PARTS CATALOG

ILLUSTRATION AND TEXT  
(CHASSIS - BODY - TRIM)

November 2003

**SUPERSEDES**  
October 2003  
**ENGLISH**



**Jeep**

---

CHRYSLER • PLYMOUTH • DODGE • JEEP

**THE MOPAR DIFFERENCE**



## INDEX TO INFORMATION PAGES

The use of this Parts Catalog and the arrangement of information herein is explained in the General Information Section as indexed below.

<b>Abbreviations .....</b>	<b>INF-13</b>
<b>Alphabetic Index .....</b>	<b>INF-10</b>
<b>Body Code Plate Interpretation .....</b>	<b>INF-12</b>
<b>Catalog Groups - Titles &amp; Contents .....</b>	<b>INF-2</b>
<b>How to Use This Catalog and Locate Parts .....</b>	<b>INF-8</b>
<b>Illustration Index .....</b>	<b>INF-10</b>
<b>Illustration Numbering Index .....</b>	<b>INF-9</b>
<b>Index.....</b>	<b>INF-1</b>
<b>Logical Illustration Index.....</b>	<b>INF-3</b>
<b>Logical Illustrations .....</b>	<b>INF-9</b>
<b>Numerical Index .....</b>	<b>INF-10</b>
<b>Page Numbering.....</b>	<b>INF-9</b>
<b>Part Packages .....</b>	<b>INF-10</b>
<b>Standard Parts.....</b>	<b>INF-10</b>
<b>Symbols Used in this Catalog.....</b>	<b>INF-9</b>
<b>VIN Plate Decoding Information .....</b>	<b>INF-11</b>

## CATALOG GROUPS - TITLES & CONTENT

Group	Content
001	Component Parts for Mopar Accessories
002	Front Suspension & Drive
003	Rear Axle
004	Parking Brake
005	Service Brakes
007	Cooling
008	Electrical
009	Engine Mounting
011	Exhaust
013	Frames and Bumpers
014	Fuel
016	Propeller Shafts and U-Joints
017	Rear Suspension
019	Steering
022	Wheels, Covers and Jacks
024	Air Conditioning & Heater
025	Emission Systems
088	Power Transfer Unit AWD
08A	Instrument Panel and Radios and Consoles
2.4L	Engine 2.4L Four Cylinder
21P	Speedometer Pinions
23D	Wiper/Lock Cylinder and Keys
3.3L6T	Engine 3.3L Six Cylinder
3.8L	Engine 3.8L Six Cylinder
31TH	Automatic Transaxle 3 Speed
41TE-AE	Automatic Transaxle 4 Speed
DRS	Doors and Related Parts
ERS	Exterior Ornamentation
IRS	Interior Trim
SRS	Body Sheet Metal Except Doors

## LOGICAL ILLUSTRATION INDEX

Group	Logical Illustration	Logical Illustration Name
001	100	Audio & Electronics
001	200	Carriers & Cargo Hauling
001	400	Exterior Appearance
001	500	Exterior Protection
001	800	Interior Storage
001	900	Security
002	100	Front Suspension
002	200	Front Axle Drive Shafts
003	100	Rear Axle
003	400	Rear Axle Shafts
004	100	Parking Brake Lever and Cables
005	100	Front Brakes
005	200	Rear Brakes
005	300	Power Brake Booster
005	400	Brake Master Cylinder
005	500	Brake Lines and Hoses
005	600	Brake Pedals
007	100	Radiator and Related Parts
007	200	Water Pump and Related Parts
007	300	Tank, Coolant Engine
007	400	Pulleys and Related Parts
007	500	Drive Belts
007	600	Lines, Transmission Oil Cooler
008	100	Starters
008	1000	Battery Tray and Cables
008	1100	Lamps - Front, Rear and Courtesy
008	1200	Wiring-Engine & Related Parts
008	1300	Wiring-Headlamp to Dash
008	1400	Wiring-Instrument Panel
008	1500	Wiring-Body & Accessories
008	1600	Wiring Repair
008	1900	Spark Plugs-Cables-Coils
008	200	Alternators

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

---

008	400	Modules
008	500	Relays
008	600	Sensors
008	700	Single Board Engine Controllers
008	800	Switches
008	900	Horns
009	100	Engine Mounting
011	100	Exhaust System
011	200	Heat Shields
013	100	Frames
013	200	Front Bumper and Fascia
013	300	Rear Bumper and Fascia
014	100	Tank, Fuel
014	1000	Speed Control
014	1100	Accelerator Pedal
014	200	Fuel Tank Filler Tube
014	300	Fuel Lines
014	400	Fuel Rail
014	500	Fuel Pump and Sending Unit
014	600	Throttle Body
014	700	Throttle Controls
014	800	Air Cleaner
016	100	Propeller Shaft
017	100	Rear Suspension
019	100	Steering Wheel
019	200	Steering Column
019	300	Steering Gear
019	500	Power Steering Pump
019	700	Power Steering Hoses
022	100	Wheels and Hardware
022	200	Wheel Covers and Center Caps
022	300	Jack Stowage
022	400	Spare Tire Stowage
024	100	Air Conditioner and Heater Units
024	200	Air Conditioner and Heater Plumbing
024	300	Air Conditioner and Heater Controls

024	400	Air Conditioning Compressor
024	600	Air Ducts and Outlets
025	100	Emission Labels
025	200	EGR System
025	300	Vacuum Canister
025	400	Emission Harness
088	100	Power Transfer Assembly and Mounting
08A	100	Instrument Panel
08A	200	Instrument Panel Cluster
08A	300	Radio, Antenna, and Speakers
08A	400	Consoles
2.4L	100	Engine Identification
2.4L	200	Cylinder Head
2.4L	300	Cylinder Block
2.4L	400	Crankshaft, Piston, and Drive Plate
2.4L	500	Camshafts and Valves
2.4L	600	Timing Belt and Cover
2.4L	700	Engine Oiling
2.4L	800	Manifolds
2.4L	900	Crankcase Ventilation
21P	100	Speedometer Pinions
23D	100	Lock Cylinders and Keys
23D	200	Windshield Wiper and Washer Systems
23D	300	Rear Wiper and Washer System
3.3L6T	100	Engine Identification
3.3L6T	200	Cylinder Head
3.3L6T	300	Cylinder Block
3.3L6T	400	Crankshaft, Piston and Torque Converter
3.3L6T	500	Camshafts & Valves
3.3L6T	600	Timing Chain and Cover
3.3L6T	700	Engine Oiling
3.3L6T	800	Manifolds
3.3L6T	900	Crankcase Ventilation
3.8L	100	Engine Identification
3.8L	200	Cylinder Head
3.8L	300	Cylinder Block

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

3.8L	400	Crankshaft, Piston and Torque Converter
3.8L	500	Camshafts & Valves
3.8L	600	Timing Chain and Cover
3.8L	700	Engine Oiling
3.8L	800	Manifolds
3.8L	900	Crankcase Ventilation
31TH	100	Transaxle Assembly
31TH	1200	Gearshift Controls
31TH	200	Case and Extension
31TH	300	Oil Pump
31TH	400	Gear Train
31TH	500	Bands, Reverse and Kickdown
31TH	600	Governor
31TH	700	Valve Body
31TH	800	Differential
41TE-AE	100	Transaxle Assembly
41TE-AE	1200	Gearshift Controls
41TE-AE	200	Case and Extension
41TE-AE	300	Oil Pump
41TE-AE	400	Gear Train
41TE-AE	700	Valve Body
41TE-AE	800	Differential
DRS	100	Front Door
DRS	300	Door, Sliding Cargo
DRS	500	Exterior Mirror
DRS	600	Weatherstrips and Seals
ERS	100	Nameplates
ERS	200	Moldings and Ornamentation
IRS	100	Headliner and Visor
IRS	1000	Lift Gate Trim
IRS	200	Panel-Mouldings, Scuff Plates
IRS	300	Carpet
IRS	400	Door Trim Panels, Front and Sliding
IRS	500	Front Seats and Attaching Parts
IRS	600	Rear Seats-Folding and Quads
IRS	700	Seat Belts-Front and Rear



**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

IRS	800	Adjusters, Covers, Shields and Risers
SRS	1000	Seals and Weatherstrip
SRS	1100	Roof Panels
SRS	1300	Liftgate Panel
SRS	1600	Luggage Rack
SRS	200	Floor Pans
SRS	300	Plugs
SRS	400	Front Fenders
SRS	500	Hood and Hood Release
SRS	600	Cowl and Dash Panel
SRS	700	Glass and Rear View Mirror
SRS	800	Aperture Panel
SRS	900	Quarter Panel and Pillars

## HOW TO USE THIS CATALOG AND LOCATE PARTS

**This Catalog is divided into Part Groups in which illustrations for parts of a similar function and/or location are published. The Group contents listing on the next page shows the type of parts contained in each group. Tabs are provided or available to separate each group.**

Several methods may be used to locate a specific part:

- Option 1: From the Group Contents listing. Select the group which would most logically contain the part to be found. Open the catalog to the beginning of that group. The first page of the group will contain the part. Turn to the selected illustration and locate the part by reviewing the illustration item numbers and associated text information following the illustration.
- Option 2: If the “noun” name of the part you seek is known, an alphabetical index of Nouns and illustration titles is provided to assist in finding the part. Several keys may be found in this index.

RESERVOIR, Power Steering Oil Pump Group	19	Group Reference
ALTERNATOR All Engines	8-210	Illustration Reference
BELT, Front Seat	Imdl/710/3	Illustration/Item Reference

Group by Model	_____
Illustration Number	_____
Item	_____

- Option 3: If the part number is known but the applications need to be determined, refer to the numerical index. This index shows the group, illustration number and each part listed in the catalog. Multiple references mean the part is listed more than once.
- Option 4: Other options such as group identifiers exist in these catalogs. For Example, Group 23 Body has been broken in sections, i.e. 23A Sheet Metal now is S(model code). Example: SGS for model GS. Group 23C Doors now is D(model code) ex. DGS. Group 23 Exterior Ornamentation now is E(model code). This same logic applies to the Interior Trim Section (ex. IGS).

The Group 9 Engine sections in prior parts catalogs had been numbered 9A, 9B, 9C, etc. There was no real meaning to this numbering scheme. In this new MACS produced catalog the group numbering scheme is as follows: 2.5LD means 2.5 Liter Diesel Engine; 2.0L means 2.0 Liter Four Cylinder Gas Engine; 3.3L6T means 3.3 Liter Six Cylinder Transverse Mounted Engine; and 3.8L means 3.8 Liter Six Cylinder Engine. Also note that Engine Mounting parts are located in Group 9.

## PAGE NUMBERING

Two-part page numbers are used throughout this catalog. The first part of the page designation indicates one major group or section. The second part indicates the actual page number in the group. For example:

2-1 indicates Group 2, Front Suspension, Page 1

3-4 indicates Group 3, Axle Rear, Page 4

In the maintenance of the Loose Leaf Parts Catalog Revision Service, it may become necessary to add information beyond the capacity of the page. In this event, an "A" page will be used. For example, if it becomes necessary, because of change, to add several part numbers to page 2-1 and space does not permit the addition, you will be given Page 2-1A. Page 2-1A should be filed immediately following Page 2-1.

Figure and Item Numbers are also commonly used to identify locations in the Catalog, ie., 14-910/8 refers to Group 14, illustration 910, Item Number 8. Illustration Numbers are always ascending sequential within the Groups.

## SYMBOLS USED IN THIS CATALOG

The Following symbols are commonly used with Part Number and Quantity information in this Catalog:

AR - Indicates the quantity required may vary or is to be determined by the user.

PAR - Indicates "Paint As Required"

BLANK - Indicates "All Condition

- = "Not Illustrated"

## LOGICAL ILLUSTRATIONS

Refer to Illustration in front of each group. This will give assistance to as how each group is broken down and what Specific Illustration should be referenced.

## ILLUSTRATION NUMBERING INDEX

Illustration numbers in this Catalog are Group standards. This indicates group and consistent content.

EXAMPLE: 8-100 is a Logical Illustration for Starters. 8-101 to 8-199 are Specific Illustrations used for Starters for all Catalogs. 8-200 will contain Alternators for all Catalogs and so on.

Always refer to group index in front of each group.

## ILLUSTRATION INDEX

This index is a compilation of catalog parts description data with reference to illustrations, figures and key numbers as shown:

Fender ie; Model.....Group: S(Model) .....Illustration 410  
(Fender is located in Sheet Metal Section (S) in Illustration 410)

The first page of each group contains a listing of all illustrations and group breakdown within that group. Also refer to illustrations alphabetically listed in information section.

## ALPHABETIC INDEX

This index is a compilation of catalog parts description data with a reference to the location of the item by Group, Figure, and Key Number as shown in the following example:

Housing, w/Pump.....Group 7 Illustration 210 Item 10  
(Housing, w/Pump.....7-210/10)

The index will be expanded progressively as data is added to computer files. To locate a part by name refer to the Alphabetical Index. This index indicates the group and illustration and item number where the part is located. Alphabetical Index can be found in INF section of this Catalog.

## NUMERICAL INDEX

A listing of Part Numbers contained in the catalog. The numbers are in numerical sequence with reference to the group and Illustration and item number where the part is located.

## PARTS PACKAGES

Service Parts Packages, containing all parts needed for specific service operation, are listed in their respective groups with related parts. The listing will show adaptability and model application.

## STANDARD PARTS

Important attaching standard parts such as bolts, nuts, etc, are generally listed in the text of the respective major parts groups.

## VIN PLATE DECODING INFORMATION

<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>	<b>9</b>	<b>10</b>	<b>11</b>	<b>12 thru 17</b>
<b>Country</b>	<b>Make</b>	<b>Vehicle Type</b>	<b>Other</b>	<b>Line</b>	<b>Series</b>	<b>Body Style</b>	<b>Engine</b>	<b>Check Digit</b>	<b>Model Year</b>	<b>Assy. Plant</b>	<b>Sequence No.</b>

The following table interprets the VIN Plate positions shown above.

Position	Interpretation	Codes = Description
1	Country of Origin	1 = Built in U.S. by DaimlerChrysler Corporation 2 = Built in Canada by DaimlerChrysler Canada Inc
2	Make	B = Dodge C = Chrysler
3	Vehicle type	4 = Multipurpose Passenger Vehicle With Side Air Bags
4	GVWR & Pass. Safety	D=0-1360 kg (0-3000 lbs) E=1361-1814 kg (3001-4000 lbs) F=1815-2267 kg (4001-5000 lbs) G=2268-2721 kg (5001-6000 lbs) H=2722-3175 kg (6001-7000 lbs) J=3176-3628 kg (7001-8000 lbs) K=3629-4082 kg (8001-9000 lbs) L=4083-4535 kg (9001-10000 lbs)
5	Vehicle Line	C = Chrysler Town & Country (AWD) D = Dodge Grand Caravan / Caravan (AWD) Y = Chrysler Town & Country / Voyager (FWD) K = Dodge Grand Caravan (FWD)
6	Series	2 = Dodge Caravan/Grand Caravan SE (FWD) 4 = Dodge Caravan/Grand Caravan Sport (FWD/AWD) 5 = Dodge Grand Caravan ES (FWD/AWD) 7 = Dodge Grand Caravan EX (FWD)
7	Body Style	4= RS - 53      5 = RS - 52
8	Engine	B = 2.4L 4 Cyl., 16V DOHC (EDZ) L = 3,8 6 Cyl. MPI (EGH) E = 3.5L 6 Cyl High Output (EGF) R = 3.3L 6 Cyl (SMPI) (EGA)
9	Check Digit	
10	Model Year	2 = 2002
11	Assembly Plant	B = St. Louis Assembly South R = Windsor Assembly
12 thru 17	Vehicle Build Sequence	Model Year Assembly Sequence

## BODY CODE PLATE INTERPRETATION

The Body Code Plate is located on the Left Front Side Shield or Wheel Housing or the Upper Radiator Support. The Plate contains 7 rows of data. The bottom 3 rows are reserved for the specific information as depicted below. Starting at the fourth row (following the reserved portion), other Sales Codes used to build a specific vehicle are listed in the ascending order by ALPHA sequence.

1	2	3	4	5	6	7	8	9	10	11	12		13	14	15		16	17	18	19	20	21
22	23	24		25	26	27	28		29	30	31	32		33	34	35	36		37	38	39	
40	41	42		43		44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60

1-12	VEHICLE ORDER NUMBER
13-15	VINYL ROOF CODE/DOOR COMBO CODES
16-18	VEHICLE SHELL CAR LINE
19	PRICE CLASS
20-21	BODY TYPE
22-24	PAINT PROCEDURE
25-28	PRIMARY PAINT
29-32	SECONDARY PAINT
33-36	INTERIOR TRIM CODE
37-39	ENGINE CODES
40-42	TRANSMISSION CODES
43	MARKET CODES
44-46	VEHICLE IDENTIFICATION NUMBER (VIN) For definition of the Elements and the individual position see Vin Plate Defined.

## ABBREVIATIONS

A/C	Air Conditioner
ABS	Anti-Lock Brakes System
AR	As Required
ATC	Automatic Temperature Control
AWD	All Wheel Drive
BUX	Built Up Export
CV	Constant Velocity
DOHC	Dual (or Double) OverHead Cam
EFI	Electronic Fuel Injection
EGR	Exhaust Gas Recirculation
ECU	Electronic Control Unit
FWD	Front Wheel Drive
HEX	HEXagon
HCU	Hydraulic Control Unit
I/D	Inside Diameter
L	Liter
LED	Light Emitting Diode
MAP	Manifold Absolute Pressure
MPH	Miles Per Hour
O/D	Outside Diameter
P/S	Power Steering
PSI	Pounds per Square Inch
PSF	Pounds per Square Foot
PRNODL	Park, Reverse, Neutral, Overdrive, Drive, Low
PRNDL	Park, Reverse, Neutral, Drive, Low
PTO	Power Take Off
RFI	Radio Frequency Interference
RPM	Revolutions Per Minute
RTV	Room Temperature Vulcanizer (sealant)
T/BODY	Throttle BODY
U/BODY	Under BODY
SOHC	Single OverHead Cam
PAR	Paint As Required





**-A-**

ABSORBER, Front Energy	013-260/7
ACCELERATOR PEDAL	014/1110
ACCUMULATOR PISTON AND SPRINGS	41TE-AE/725
ACTUATOR	SRS-1330/10
ACTUATOR, A/C and Heater	024-120/13
ACTUATOR, A/C and Heater	024-130/13
ACTUATOR, A/C and Heater	024-140/13
ACTUATOR, A/C and Heater	024-150/16
ACTUATOR, Power Cinch	DRS-310/21
ACTUATOR, Power Door Lock	DRS-310/20
ACTUATOR, Power Latch	SRS-1320/2
ADAPTER, Antenna	08A-310/20
ADAPTER, Disc Brake	005-220/13
ADAPTER, Oil Filter	3.8L-710/2
ADAPTER, Oil Filter	3.3L6T-710/2
ADJUSTER, Brake Shoe	005-210/11
ADJUSTER, Manual Seat	IRS-535/7
ADJUSTER, Parking Brake	005-220/18
ADJUSTER, Power Seat	IRS-535/8
ADJUSTER, Power Seat	IRS-540/11
ADJUSTER, Valve Lash	2.4L-510/15
AIR BAG, Driver	019-145/3
AIR BAG, Passenger	08A-105/12
AIR CLEANER	014-810/1
AIR CLEANER	014-830/1
AIR CLEANER [EDZ]	014/810
AIR CLEANER [EGA],[EGH],[EGM]	014/830
AIR CONDITIONING AND HEATER UNIT [HAD,HAG]	024/130
AIR CONDITIONING AND HEATER UNIT [HAA]	024/120
AIR CONDITIONING AND HEATER, ATC WITH ZONE [HAH]	024/140
AIR DAM	013-260/16
AIR DAM	SRS-610/33
ALARM - WITHOUT POWER DOOR LOCKS,Without Power Door Locks	001/910
ALTERNATOR	008-205/1
ALTERNATOR	008-215/1
ALTERNATOR [2.4L EDZ ENGINE]	008/205
ALTERNATOR [3.3L,3.8LEGA,EGH,EGMENGINES]	008/215
ANCHOR KIT, Tether-Child Seat	IRS-730/4
ANCHOR, Reverse Band	31TH-520/12
ANTENNA, Global Positioning	001-130/10
ANTI LOCK , BRAKE CONTROL	005/431
APPLIQUE, Front Door	ERS-220/3
APPLIQUE, Quarter Lower	ERS-220/5
APPLIQUE, Sliding Door Outside	ERS-220/4
ARM KIT, Control	SRS-1330/9
ARM, Control	002-145/18
ARM, Liftgate Wiper	23D-305/2
ARM, Wiper	23D-205/2
ARMREST, Seat	IRS-510/5
ARMREST, Seat	IRS-515/5
ARMREST, Seat	IRS-520/5
ARMREST, Seat	IRS-525/7
ARMREST, Seat	IRS-530/6
ARMREST, Seat	IRS-610/4
ARMREST, Seat	IRS-615/4
ARMREST, Seat	IRS-620/5
ARMREST, Seat	IRS-625/5
ARMREST, Seat	IRS-630/3
ARMREST, Seat	IRS-635/3
ARMREST, Seat	IRS-820/7
ARMREST, Seat	IRS-535/22
ARMREST, Seat	IRS-640/10
ARMREST, Seat	IRS-815/16
ASH RECEIVER, Instrument Panel	08A-105/54
ASH RECEIVER, Quarter Panel	IRS-240/10
AUDIO KIT, Rear	08A-310/27
AUX. AIR CONDITIONING AND HEATER	024/150
AXLE, Rear	017-145/12
AXLE, Rear	017-155/15

**-B-**

B PILLAR TRIM	IRS/220
BACKING PLATE, Rear Drum Brake	005-210/15

BAFFLE, Transfer Shaft	41TE-AE-415/43
BALANCE SHAFTS 2.4L [EDZ]	2.4L/620
BALL JOINT, Lower Control Arm	002-145/19
BALL, Check	41TE-AE-320/5
BALL, Check	41TE-AE-320/11
BALL, Check	41TE-AE-715/22
BALL, Transmission Oil Pump	31TH-320/10
BALL, Valve Body Check	31TH-715/23
BAND, Kickdown	31TH-520/3
BAND, Reverse	31TH-520/10
BANDS, REVERSE AND KICKDOWN	31TH/520
BAR, Front Sway	002-145/33
BAR, Rear Sway	017-145/13
BAR, Rear Sway	017-145/33
BAR, Rear Sway	017-155/16
BASE, Cigar Lighter	08A-105/30
BATTERY	008-1005/8
BATTERY	008-1005/9
BATTERY TRAY AND SHIELD	008/1005
BATTERY, Transmitter	001-910/5
BATTERY, Transmitter	23D-105/36
BDORC UNIT, AWD Rear Axle	003-115/11
BDORC/VISCOUS UNIT KIT, Rear axle	003-115/5
BEAM PACKAGE, Front Fender Shield	SRS-410/6
BEARING	088-120/2
BEARING	003-115/10
BEARING	31TH-425/2
BEARING	31TH-425/9
BEARING	31TH-820/14
BEARING	41TE-AE-440/2
BEARING	41TE-AE-820/18
BEARING CONE, Differential	31TH-820/13
BEARING CONE, Differential	41TE-AE-820/17
BEARING CONE, Differential	41TE-AE-820/19
BEARING CONE, Output Shaft	31TH-460/11
BEARING CONE, Output Shaft	41TE-AE-440/37
BEARING CONE, Transfer Shaft	41TE-AE-415/4
BEARING CUP, Differential	088-120/1
BEARING CUP, Differential	31TH-425/3
BEARING CUP, Differential	31TH-425/8
BEARING CUP, Differential	31TH-215/42
BEARING CUP, Differential	31TH-820/15
BEARING CUP, Differential	41TE-AE-240/33
BEARING CUP, Differential	41TE-AE-440/11
BEARING CUP, Differential	41TE-AE-820/20
BEARING CUP, Output Shaft	31TH-460/12
BEARING CUP, Output Shaft	41TE-AE-440/36
BEARING CUP, Transfer Gear	41TE-AE-415/2
BEARING KIT, Connecting Rod, .025 mm U/S	2.4L-410/2
BEARING KIT, Connecting Rod, .25 mm U/S	2.4L-410/3
BEARING KIT, Connecting Rod, Standard	2.4L-410/1
BEARING KIT, Crankshaft Thrust, .025mm Undersize	2.4L-410/5
BEARING KIT, Crankshaft Thrust, .25mm Undersize	2.4L-410/6
BEARING KIT, Crankshaft Thrust, Std	2.4L-410/4
BEARING KIT, Crankshaft, .025mm Undersize	2.4L-410/8
BEARING KIT, Crankshaft, .25mm Undersize	2.4L-410/9
BEARING KIT, Crankshaft, Standard	2.4L-410/7
BEARINGPACKAGEConnectingRod,.025mmUndersize	3.8L-410/4
BEARINGPACKAGEConnectingRod,.025mmUndersize	3.3L6T-410/4
BEARINGPACKAGE,ConnectingRod,.25mmUndersize	3.8L-410/5
BEARINGPACKAGE,ConnectingRod,.25mmUndersize	3.3L6T-410/5

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

Alphabetic  
Index

Page AL-2

BEARING PACKAGE, Connecting Rod, Standard . 3.8L-410/3  
 BEARING PACKAGE, Connecting Rod, Standard . 3.3L6T-410/3  
 BEARING PACKAGE, Crankshaft, .025mm Undersize 3.8L-410/7  
 BEARING PACKAGE, Crankshaft, .025mm Undersize 3.8L-410/10  
 BEARING PACKAGE, Crankshaft, .025mm Undersize 3.3L6T-410/7  
 BEARING PACKAGE, Crankshaft, .025mm Undersize 3.3L6T-410/10  
 BEARING PACKAGE, Crankshaft, .25 mm Undersize 3.8L-410/8  
 BEARING PACKAGE, Crankshaft, .25 mm Undersize 3.8L-410/11  
 BEARING PACKAGE, Crankshaft, .25 mm Undersize 3.3L6T-410/8  
 BEARING PACKAGE, Crankshaft, .25 mm Undersize 3.3L6T-410/11  
 BEARING PACKAGE, Crankshaft, Standard . . . . . 3.8L-410/6  
 BEARING PACKAGE, Crankshaft, Standard . . . . . 3.8L-410/9  
 BEARING PACKAGE, Crankshaft, Standard . . . . . 3.3L6T-410/6  
 BEARING PACKAGE, Crankshaft, Standard . . . . . 3.3L6T-410/9  
 BEARING PACKAGE, Transfer Shaft . . . . . 41TE-AE-415/45  
 BEARING, Camshaft. . . . . 3.8L-510/23  
 BEARING, Camshaft. . . . . 3.3L6T-510/21  
 BEARING, Drive Shaft . . . . . 088-120/51  
 BEARING, Strut Mount . . . . . 002-145/8  
 BELT, A/C Compressor . . . . . 007-530/1  
 BELT, A/C Compressor . . . . . 008-215/6  
 BELT, Alternator Drive . . . . . 007-520/2  
 BELT, Alternator Drive . . . . . 008-205/6  
 BELT, Power Steering . . . . . 007-520/1  
 BELT, Timing . . . . . 2.4L-610/5  
 BEZEL, Front Door Trim Panel . . . . . DRS-180/11  
 BEZEL, Instrument Cluster . . . . . 08A-105/6  
 BEZEL, Instrument Panel . . . . . 08A-105/5  
 BEZEL, Instrument Panel . . . . . 08A-105/15  
 BEZEL, Instrument Panel, Center . . . . . 08A-105/7  
 BEZEL, Lock Knob . . . . . IRS-410/14  
 BEZEL, Overhead Console . . . . . 024-310/8  
 BEZEL, Overhead Console . . . . . 024-620/7  
 BEZEL, Overhead Console . . . . . 08A-405/8  
 BEZEL, Overhead Console . . . . . 08A-315/10  
 BEZEL, Power Window Switch . . . . . 008-815/4  
 BEZEL, Power Window Switch . . . . . DRS-180/12  
 BEZEL, Power Window/Door Lock Switch . . . . . 008-815/5  
 BEZEL, Sliding Door Bumper . . . . . IRS-420/11  
 BIKE CARRIER - HITCH MOUNT,1.25 inch Receiver 001/210  
 BIKE CARRIER - HITCH MOUNT,2.0 inch Receiver 001/212  
 BIKE CARRIER - ROOF,Fork Mount. . . . . 001/214  
 BIKE CARRIER - ROOF,Upright Mount . . . . . 001/216  
 BIN, Instrument Panel . . . . . 08A-105/9  
 BIN, Storage . . . . . 001-140/6  
 BLADE, Wiper . . . . . 23D-205/1  
 BLADE, Wiper . . . . . 23D-305/1  
 BLEEDER SCREW, Brake . . . . . 005-220/8  
 BLEEDER SCREW, Brake . . . . . 005-155/19  
 BLEEDER SCREW, Brake . . . . . 005-210/18  
 BLOCK, Short . . . . . 2.4L-310/3  
 BLOCK, Short . . . . . 3.8L-310/2  
 BLOCK, Short . . . . . 3.3L6T-310/2  
 BODY AND CABLE, Antenna . . . . . 08A-310/23  
 BODY FRONT PILLAR AND APERTURE PANEL. . . . . SRS/810  
 BODY PILLAR - SLIDING DOOR. . . . . SRS/815  
 BODY, Governor . . . . . 31TH-620/3  
 BOLSTER, Quarter Trim Panel . . . . . IRS-235/3  
 BOLSTER, Quarter Trim Panel . . . . . IRS-240/7  
 BOLT . . . . . 003-135/6  
 BOLT . . . . . 016-120/2  
 BOLT . . . . . IRS-535/5  
 BOLT . . . . . IRS-540/9  
 BOLT . . . . . IRS-710/7  
 BOLT . . . . . IRS-830/3  
 BOLT . . . . . 002-145/13  
 BOLT . . . . . 009-140/11  
 BOLT . . . . . 009-140/26  
 BOLT . . . . . 009-160/11  
 BOLT . . . . . 009-160/26  
 BOLT . . . . . 009-160/27  
 BOLT . . . . . 009-160/28  
 BOLT . . . . . 3.8L-510/5  
 BOLT . . . . . IRS-510/10

BOLT . . . . . IRS-515/10  
 BOLT . . . . . IRS-520/10  
 BOLT . . . . . IRS-525/12  
 BOLT . . . . . IRS-530/11  
 BOLT . . . . . IRS-535/27  
 BOLT . . . . . IRS-535/31  
 BOLT . . . . . 008-1905/19  
 BOLT . . . . . 2.4L-620/22  
 BOLT . . . . . 3.8L-610/14  
 BOLT . . . . . 3.8L-810/14  
 BOLT . . . . . 3.3L6T-510/5  
 BOLT . . . . . 3.3L6T-810/12  
 BOLT AND WASHER, M6x12. . . . . 3.8L-310/7  
 BOLT AND WASHER, M6x12. . . . . 3.8L-610/7  
 BOLT AND WASHER, M6x12. . . . . 3.8L-610/10  
 BOLT AND WASHER, M6x12. . . . . 3.8L-810/18  
 BOLT AND WASHER, M6x12. . . . . 3.3L6T-310/7  
 BOLT AND WASHER, M6x12. . . . . 3.3L6T-610/7  
 BOLT AND WASHER, M6x12. . . . . 3.3L6T-610/10  
 BOLT AND WASHER, M6x12. . . . . 3.3L6T-810/26  
 BOLT AND CONED WASHER, Hex Head, M6x1.0x20 007-225/2  
 BOLT AND CONED WASHER, Hex Head, M6x1.0x20 019-520/4  
 BOLT AND CONED WASHER, Hex Head, M6x1.0x20 DRS-310/17  
 BOLT AND CONED WASHER, Hex Head, M6x14x12.5 41TE-AE-240/56  
 BOLT AND CONED WASHER, Hex Head, M6x14x14 007-207/6  
 BOLT AND CONED WASHER, Hex Head, M6x14x14 2.4L-810/10  
 BOLT AND CONED WASHER, Hex Head, M6x16x14 014-460/6  
 BOLT AND CONED WASHER, Hex Head, M6x20x14 SRS-815/3  
 BOLT AND CONED WASHER, Hex Head, M6x20x14 SRS-915/6  
 BOLT AND CONED WASHER, Hex Head, M6x20x14 005-561/12  
 BOLT AND CONED WASHER, Hex Head, M6x25x12.5 31TH-1225/4  
 BOLT AND CONED WASHER, Hex Head, M6x45x12.5 2.4L-620/20  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 004-147/8  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 005-431/6  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 005-561/4  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 005-645/3  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 019-720/2  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 019-730/3  
 BOLT AND CONED WASHER, Hex Head, M8x1.25x25 025-310/19  
 BOLT AND CONED WASHER, Hex Head, M8x14x17 005-565/5  
 BOLT AND CONED WASHER, Hex Head, M8x14x17 005-565/11  
 BOLT AND CONED WASHER, Hex Head, M8x14x17 005-565/16  
 BOLT AND CONED WASHER, Hex Head, M8x14x17 3.8L-710/10  
 BOLT AND CONED WASHER, Hex Head, M8x25x17 022-410/3  
 BOLT AND CONED WASHER, Hex Head, M8x25x20 08A-105/58  
 BOLT AND CONED WASHER, Hex Head, M8x30x20 004-142/3  
 BOLT AND CONED WASHER, Hex Head, M8x35x20 31TH-620/8  
 BOLT AND CONED WASHER, M8x1.25x18. . . . . 014-440/2  
 BOLT AND WASHER, Hex Head, M10x1.50x62 . . . . . 2.4L-610/15  
 BOLT AND WASHER, Hex Head, M10x1.5x30 . . . . . 019-510/3  
 BOLT AND WASHER, Hex Head, M10x1.5x30 . . . . . 009-140/24  
 BOLT AND WASHER, Hex Head, M10x1.5x30 . . . . . 017-145/17  
 BOLT AND WASHER, Hex Head, M10x1.5x30 . . . . . 017-155/19  
 BOLT AND WASHER, Hex Head, M10x1.5x30 . . . . . 31TH-210/17  
 BOLT AND WASHER, Hex Head, M10x1.5x35 . . . . . 007-404/9  
 BOLT AND WASHER, Hex Head, M10x1.5x35 . . . . . 008-205/5  
 BOLT AND WASHER, Hex Head, M10x1.5x35 . . . . . 024-410/1  
 BOLT AND WASHER, Hex Head, M10x1.5x90 . . . . . 007-404/8  
 BOLT AND WASHER, Hex Head, M10x1.5x90 . . . . . 008-205/4  
 BOLT AND WASHER, Hex Head, M8x1.25x20 . . . . . 019-730/9  
 BOLT AND WASHER, Hex Head, M8x1.25x20 . . . . . 024-205/2  
 BOLT AND WASHER, M10x35 . . . . . 009-140/14  
 BOLT AND WASHER, M10x35 . . . . . 009-160/14  
 BOLT AND WASHER, M10x60 . . . . . 009-160/29  
 BOLT AND WASHER, SelfTapingFlangeHead, M8x1.25x40.00 024-230/1  
 BOLT KIT, Security. . . . . 001-210/4  
 BOLT KIT, Security. . . . . 001-212/4  
 BOLT KIT, Security. . . . . 001-220/3  
 BOLT PACKAGE, Camber Adjustment . . . . . 002-145/35  
 BOLT, Bearing Cap . . . . . 3.8L-310/13  
 BOLT, Connecting Rod. . . . . 2.4L-410/20  
 BOLT, Cylinder Head . . . . . 3.8L-210/9  
 BOLT, Cylinder Head . . . . . 2.4L-210/12

BOLT, Cylinder Head . . . . .	3.3L6T-210/ 10	BOLT, Hex Head, M8x1.25x35 . . . . .	017-145/25
BOLT, Drive Plate and Flywheel . . . . .	2.4L-410/13	BOLT, Hex Head, M8x1.25x37.50 . . . . .	2.4L-710/24
BOLT, Drive Plate and Flywheel . . . . .	3.8L-410/19	BOLT, Hex Head, M8x1.25x70 . . . . .	007-425/2
BOLT, Drive Plate and Flywheel . . . . .	3.3L6T-410/ 20	BOLT, Hex Head, M8x1.25x70 . . . . .	009-170/5
BOLT, EGR Tube . . . . .	025-240/4	BOLT, Hex Head, M8x1.25x70 . . . . .	2.4L-310/9
BOLT, EGR Tube . . . . .	025-260/5	BOLT, Hex Head, M8x30 . . . . .	31TH-715/15
BOLT, Hex Flange Head . . . . .	005-155/9	BOLT, Hex Head, M8x30 . . . . .	41TE-AE- 715/13
BOLT, Hex Flange Head . . . . .	31TH-210/18	BOLT, M6x1.00x20 . . . . .	2.4L-510/20
BOLT, Hex Flange Head, M10x1.50x108 . . . . .	2.4L-620/21	BOLT, M8x1.25x25 . . . . .	IRS-830/14
BOLT, Hex Flange Head, M10x1.50x25 . . . . .	003-420/2	BOLT, M8x1.25x30 . . . . .	3.8L-810/25
BOLT, Hex Flange Head, M10x1.5x50 . . . . .	009-170/4	BOLT, Main Bearing Cap . . . . .	2.4L-310/8
BOLT, Hex Flange Head, M10x1.5x50 . . . . .	088-110/2	BOLT, Main Bearing Cap . . . . .	3.8L-310/12
BOLT, Hex Flange Head, M12x1.75x45 . . . . .	013-110/17	BOLT, Main Bearing Cap . . . . .	3.3L6T-310/ 16
BOLT, Hex Flange Head, M12x1.75x87.50 . . . . .	007-404/2	BOLT, Main Bearing Cap . . . . .	3.3L6T-410/ 17
BOLT, Hex Flange Head, M12x1.75x87.50 . . . . .	2.4L-610/13	BOLT, RISER . . . . .	IRS-815/21
BOLT, Hex Flange Head, M6x1.00x35 . . . . .	2.4L-210/14	BOLT, RISER . . . . .	IRS-830/15
BOLT, Hex Flange Head, M6x1.00x40 . . . . .	2.4L-510/19	BOLT, Recliner . . . . .	IRS-815/5
BOLT, Hex Flange Head, M8x1.25x23 . . . . .	31TH-740/3	BOLT, Recliner . . . . .	IRS-825/5
BOLT, Hex Flange Head, M8x1.25x30 . . . . .	009-170/3	BOLT, Recliner . . . . .	IRS-820/10
BOLT, Hex Flange Head, M8x1.25x30 . . . . .	088-110/4	BOLT, Recliner . . . . .	IRS-820/11
BOLT, Hex Flange Head, M8x1.25x30 . . . . .	2.4L-810/6	BOLT, Recliner . . . . .	IRS-830/11
BOLT, Hex Flange Head, M8x1.25x30 . . . . .	3.3L6T-810/ 21	BOLT, Recliner . . . . .	IRS-830/12
BOLT, Hex Head . . . . .	IRS-710/4	BOLT, Recliner to Seat Back . . . . .	IRS-815/4
BOLT, Hex Head . . . . .	IRS-720/2	BOLT, Recliner to Seat Back . . . . .	IRS-825/4
BOLT, Hex Head . . . . .	IRS-740/2	BOLT, Seat . . . . .	IRS-825/11
BOLT, Hex Head . . . . .	IRS-750/2	BOLT, Seat Belt . . . . .	IRS-710/3
BOLT, Hex Head . . . . .	IRS-610/18	BOLT, Seat Belt . . . . .	IRS-730/3
BOLT, Hex Head . . . . .	2.4L-710/23	BOLT, Shoulder, M10x1.5x34 . . . . .	IRS-535/6
BOLT, Hex Head, .437-20x.937 . . . . .	005-561/5	BOLT, Special Head Locking, M8x1.25x42.50 . . . . .	019-245/29
BOLT, Hex Head, .437-20x.937 . . . . .	005-565/8	BOLT, Special Head, M10x1.5x40 . . . . .	019-510/8
BOLT, Hex Head, .437-20x.937 . . . . .	005-565/14	BOLT, Wheel Cylinder . . . . .	005-210/3
BOLT, Hex Head, .437-20x1.80 . . . . .	IRS-740/7	BOOSTER, Power Brake . . . . .	005-343/1
BOLT, Hex Head, M10x1.00x25 . . . . .	31TH-820/11	BOOSTER, POWER BRAKE . . . . .	005/343
BOLT, Hex Head, M10x1.00x25 . . . . .	41TE-AE- 820/15	BOOT AND SEAL, Disc Brake . . . . .	005-220/4
BOLT, Hex Head, M10x1.50 x 13.20 . . . . .	2.4L-410/14	BOOT AND SEAL, Disc Brake . . . . .	005-155/18
BOLT, Hex Head, M10x1.50 x 13.20 . . . . .	3.8L-410/21	BOOT KIT, Half Shaft . . . . .	003-420/3
BOLT, Hex Head, M10x1.50 x 13.20 . . . . .	3.3L6T-410/ 22	BOOT KIT, Half Shaft, Inner . . . . .	002-245/3
BOLT, Hex Head, M10x1.50 x 13.20 . . . . .	41TE-AE- 220/15	BOOT KIT, Half Shaft, Outer . . . . .	002-245/4
BOLT, Hex Head, M10x1.50x125 . . . . .	009-140/20	BOOT, Brake Booster Push Rod . . . . .	005-343/9
BOLT, Hex Head, M10x1.50x125 . . . . .	009-160/20	BOOT, Headlamp . . . . .	008-1105/10
BOLT, Hex Head, M10x1.5x20 . . . . .	019-510/5	BOTTLE, Coolant Reserve . . . . .	007-330/4
BOLT, Hex Head, M10x1.5x20 . . . . .	009-160/25	BOW, Roof, Number 1 . . . . .	SRS-1110/3
BOLT, Hex Head, M10x1.5x20 . . . . .	41TE-AE- 220/3	BOW, Roof, Number 2 and 3 . . . . .	SRS-1110/4
BOLT, Hex Head, M10x1.5x50 . . . . .	002-145/16	BOX, Connector Repair . . . . .	008-1605/11
BOLT, Hex Head, M12-1.75x60 . . . . .	009-160/9	BRACE, Cowl Grille . . . . .	SRS-610/8
BOLT, Hex Head, M12x1.50x52 . . . . .	2.4L-610/9	BRACE, Cowl Grille . . . . .	23D-205/12
BOLT, Hex Head, M14 x 2.00 x 120.00 . . . . .	002-145/26	BRACE, Cowl Grille . . . . .	23D-205/13
BOLT, Hex Head, M14x2.0x 120 . . . . .	017-145/2	BRACE, Cowl Grille . . . . .	SRS-610/11
BOLT, Hex Head, M14x2.0x 120 . . . . .	017-155/6	BRACE, Cowl Plenum To Cowl Side . . . . .	SRS-610/5
BOLT, Hex Head, M18x1.5x34 . . . . .	41TE-AE- 440/40	BRACE, Instrument Panel to Floor . . . . .	08A-410/4
BOLT, Hex Head, M6x1.0x22 . . . . .	007-207/2	BRACE, Instrument Panel to Floor . . . . .	08A-105/42
BOLT, Hex Head, M8x1.25x10.00 . . . . .	31TH-425/27	BRACE, Transmission . . . . .	009-160/23
BOLT, Hex Head, M8x1.25x10.00 . . . . .	31TH-460/21	BRACE, Transmission . . . . .	009-160/24
BOLT, Hex Head, M8x1.25x10.00 . . . . .	41TE-AE- 440/70	BRACE, Transmission . . . . .	41TE-AE- 220/2
BOLT, Hex Head, M8x1.25x16 . . . . .	31TH-215/3	BRACE, Transmission . . . . .	41TE-AE- 220/4
BOLT, Hex Head, M8x1.25x16 . . . . .	31TH-215/34	BRACKET . . . . .	001-140/2
BOLT, Hex Head, M8x1.25x16 . . . . .	31TH-215/39	BRACKET . . . . .	001-142/2
BOLT, Hex Head, M8x1.25x16 . . . . .	41TE-AE- 240/5	BRACKET . . . . .	IRS-235/7
BOLT, Hex Head, M8x1.25x16 . . . . .	41TE-AE- 240/7	BRACKET . . . . .	IRS-240/3
BOLT, Hex Head, M8x1.25x16 . . . . .	41TE-AE- 240/21	BRACKET . . . . .	08A-105/62
BOLT, Hex Head, M8x1.25x19 . . . . .	31TH-320/4	BRACKET & FILTER, LDP Base . . . . .	025-490/4
BOLT, Hex Head, M8x1.25x19 . . . . .	41TE-AE- 320/4	BRACKET AND HINGE, Floor Pan Rear Suspension . . . . .	013-120/4
BOLT, Hex Head, M8x1.25x35 . . . . .	017-145/8	BRACKET AND HINGE, Floor Pan Rear Suspension . . . . .	SRS-210/2
		BRACKET AND HINGE, Floor Pan Rear Suspension . . . . .	SRS-210/6
		BRACKET AND HINGE, Floor Pan Rear Suspension . . . . .	017-145/38
		BRACKET AND HINGE, Floor Pan Rear Suspension . . . . .	017-155/34
		BRACKET ASSY, REAR SEAT VIDEO . . . . .	08A-315/5
		BRACKET KIT, Trailer Tow . . . . .	001-295/11
		BRACKET, A/C Compressor . . . . .	024-410/2
		BRACKET, A/C Filter Drier . . . . .	024-210/13
		BRACKET, A/C Filter Drier . . . . .	024-220/23
		BRACKET, Alternator . . . . .	007-404/7
		BRACKET, Alternator . . . . .	008-205/2

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

BRACKET, Armrest Support . . . . . IRS-535/21  
 BRACKET, Aux A/C And Heater Line . . . . . 024-230/10  
 BRACKET, Aux A/C And Heater Line . . . . . 024-230/11  
 BRACKET, Aux A/C And Heater Line . . . . . 024-230/12  
 BRACKET, Battery Tray . . . . . 008-1005/2  
 BRACKET, Body Side Aperture . . . . . DRS-180/25  
 BRACKET, Body Side Aperture . . . . . SRS-410/10  
 BRACKET, Brake Caliper . . . . . 005-155/13  
 BRACKET, Cable Mounting . . . . . 014-740/6  
 BRACKET, Cargo Tie Down . . . . . 001-230/4  
 BRACKET, Connector . . . . . 008-1505/20  
 BRACKET, Console Tray . . . . . 001-810/15  
 BRACKET, Console Tray . . . . . 08A-410/21  
 BRACKET, Cushion To Back . . . . . IRS-815/20  
 BRACKET, Cushion to Riser . . . . . IRS-825/13  
 BRACKET, Cushion to Riser . . . . . IRS-825/26  
 BRACKET, D Pillar . . . . . IRS-245/8  
 BRACKET, Dash Panel Heat Shield . . . . . SRS-610/21  
 BRACKET, Dash Panel Heat Shield . . . . . SRS-610/22  
 BRACKET, Differential Pinion Shaft . . . . . 31TH-820/8  
 BRACKET, Differential Pinion Shaft . . . . . 41TE-AE-820/10  
 BRACKET, Door Pull Handle . . . . . DRS-310/10  
 BRACKET, EATX . . . . . 008-405/2  
 BRACKET, EGR Valve Mtg. . . . . 025-260/1  
 BRACKET, Engine Mount . . . . . 007-425/6  
 BRACKET, Engine Mount . . . . . 009-140/2  
 BRACKET, Engine Mount . . . . . 009-140/4  
 BRACKET, Engine Mount . . . . . 009-140/6  
 BRACKET, Engine Mount . . . . . 009-140/8  
 BRACKET, Engine Mount . . . . . 009-160/2  
 BRACKET, Engine Mount . . . . . 009-160/4  
 BRACKET, Engine Mount . . . . . 009-160/6  
 BRACKET, Engine Mount . . . . . 009-160/8  
 BRACKET, Engine Mount . . . . . 009-140/25  
 BRACKET, Engine Wiring . . . . . 008-1205/7  
 BRACKET, Fender to Cowl Grille . . . . . SRS-610/25  
 BRACKET, Gearshift Cable . . . . . 31TH-1225/6  
 BRACKET, Grab Handle . . . . . DRS-310/39  
 BRACKET, Grab Handle . . . . . IRS-235/13  
 BRACKET, H Valve . . . . . 024-150/15  
 BRACKET, Hydraulic Control Unit . . . . . 005-431/3  
 BRACKET, Ignition Wire Sperator . . . . . 008-1905/14  
 BRACKET, Ignition Wire Sperator . . . . . 008-1905/15  
 BRACKET, Ignition Wire Sperator . . . . . 3.8L-210/10  
 BRACKET, Ignition Wire Sperator . . . . . 3.8L-210/11  
 BRACKET, Ignition Wire Sperator . . . . . 3.3L6T-210/8  
 BRACKET, Instrument Panel . . . . . 008-405/19  
 BRACKET, Instrument Panel . . . . . 08A-105/53  
 BRACKET, Isolator . . . . . SRS-410/9  
 BRACKET, Isolator . . . . . SRS-410/13  
 BRACKET, Leak Detection Pump . . . . . 025-490/3  
 BRACKET, Module . . . . . 008-505/3  
 BRACKET, Module . . . . . 008-1305/4  
 BRACKET, Molding . . . . . IRS-230/4  
 BRACKET, Navigation Controller . . . . . 001-130/4  
 BRACKET, Navigation Display . . . . . 001-130/7  
 BRACKET, Overhead Console . . . . . 08A-405/5  
 BRACKET, Overhead Console . . . . . IRS-110/4  
 BRACKET, Parking Brake Cable . . . . . 004-147/5  
 BRACKET, Pivot . . . . . IRS-825/9  
 BRACKET, Pivot . . . . . IRS-825/25  
 BRACKET, Power Steering Hose . . . . . 019-730/4  
 BRACKET, Power Steering Pump . . . . . 019-510/4  
 BRACKET, Power Steering Pump . . . . . 019-510/7  
 BRACKET, Power Steering Reservoir . . . . . 019-520/7  
 BRACKET, Power Take Off . . . . . 009-170/2  
 BRACKET, Power Take Off . . . . . 088-110/3  
 BRACKET, Power Transfer Unit . . . . . 009-170/1  
 BRACKET, Power Transfer Unit . . . . . 088-110/5  
 BRACKET, Proportional Purge Solenoid . . . . . 025-410/3  
 BRACKET, Pull Handle . . . . . IRS-410/3  
 BRACKET, Quarter Inner . . . . . IRS-235/12  
 BRACKET, Quarter Trim . . . . . IRS-235/9  
 BRACKET, Quarter Trim . . . . . IRS-240/13  
 BRACKET, Quarter Trim, Right . . . . . IRS-235/4  
 BRACKET, Scuff Plate . . . . . IRS-215/10  
 BRACKET, Seat Belt . . . . . IRS-740/1

BRACKET, Sliding Door Track . . . . . IRS-420/2  
 BRACKET, Speaker . . . . . 08A-310/11  
 BRACKET, Speaker . . . . . 08A-310/12  
 BRACKET, Speed Control Servo . . . . . 014-1010/1  
 BRACKET, Stabilizer Bar . . . . . 017-155/18  
 BRACKET, Stabilizer Bar . . . . . 017-155/36  
 BRACKET, Stabilizer Bar Link . . . . . 017-145/15  
 BRACKET, Stabilizer Bar Link . . . . . 017-145/19  
 BRACKET, Stabilizer Bar Link . . . . . 017-155/29  
 BRACKET, Stabilizer Bar Link . . . . . 017-155/37  
 BRACKET, Steering Column . . . . . 019-245/13  
 BRACKET, Steering Column . . . . . SRS-610/14  
 BRACKET, Stop Lamp Switch . . . . . 005-645/6  
 BRACKET, Stop Lamp Switch . . . . . 008-805/13  
 BRACKET, Suspension Hanger . . . . . 013-120/6  
 BRACKET, Suspension Hanger . . . . . 013-120/7  
 BRACKET, Suspension Hanger . . . . . SRS-210/5  
 BRACKET, Throttle Control Cable . . . . . 014-740/4  
 BRACKET, Throttle Control Cable . . . . . 014-760/3  
 BRACKET, Throttle Control Cable . . . . . 3.8L-810/8  
 BRACKET, Throttle Control Cable . . . . . 3.3L6T-810/9  
 BRACKET, Tie Down . . . . . 013-120/8  
 BRACKET, Tie Down . . . . . SRS-210/8  
 BRACKET, Track Bar . . . . . 017-145/34  
 BRACKET, Vapor Canister . . . . . 025-310/2  
 BRACKET, Vapor Canister . . . . . 025-310/12  
 BRACKET, Vapor Canister . . . . . 025-310/13  
 BRACKET, Wheel House . . . . . SRS-210/7  
 BRACKET, Wheel House . . . . . SRS-910/22  
 BRACKET, Wiring . . . . . 008-1210/7  
 BRAKES, FRONT . . . . . 005/155  
 BRAKES, REAR DISC . . . . . 005/220  
 BRAKES, REAR DRUM . . . . . 005/210  
 BULB AND SOCKET . . . . . 008-1120/11  
 BULB, 168 . . . . . 008-1120/10  
 BULB, 194 . . . . . 008-1120/8  
 BULB, 3057 . . . . . 008-1110/5  
 BULB, 3057 . . . . . 008-1120/2  
 BULB, 3157A . . . . . 008-1105/5  
 BULB, 3157A . . . . . 008-1120/4  
 BULB, 578 . . . . . 008-1115/4  
 BULB, 578 . . . . . 008-1115/7  
 BULB, 578 . . . . . 008-1120/9  
 BULB, 578 . . . . . 008-1115/10  
 BULB, 578 . . . . . 008-1115/13  
 BULB, 578 . . . . . 008-1115/16  
 BULB, 578 . . . . . 008-1115/20  
 BULB, 578 . . . . . 008-1120/5  
 BULB, Fog Lamp, 50 Watt . . . . . 008-1105/17  
 BULB, Fog Lamp, 50 Watt . . . . . 008-1105/3  
 BULB, Headlamp, 9007 . . . . . 008-1120/3  
 BULB, Headlamp, 9007 . . . . . 008-1120/3  
 BULB, Liftgate Chmsl . . . . . 008-1110/12  
 BULB, PC579 . . . . . 008-1120/6  
 BULB, PC579 . . . . . 08A-405/10  
 BULB, PC74 . . . . . 08A-205/3  
 BULB, PC74 . . . . . 008-1120/1  
 BULB, Sunvisor . . . . . 008-1120/7  
 BULBS . . . . . 008/1120  
 BUMPER, Armrest Lid . . . . . IRS-240/12  
 BUMPER, Deck Lid Overslam . . . . . SRS-520/4  
 BUMPER, Floor Console Bin . . . . . 08A-410/26  
 BUMPER, Glove Box Door . . . . . 08A-410/5  
 BUMPER, Glove Box Door . . . . . 08A-105/37  
 BUMPER, Jounce . . . . . 002-145/3  
 BUMPER, Jounce . . . . . 017-145/24  
 BUMPER, Jounce . . . . . 017-155/27  
 BUMPER, License Plate . . . . . SRS-1320/15  
 BUMPER, License Plate . . . . . SRS-1330/12  
 BUMPER, Liftgate . . . . . SRS-1320/7  
 BUMPER, Rubber . . . . . SRS-1320/5  
 BUMPER, Sliding Door . . . . . SRS-915/3  
 BUMPER, Sliding Door . . . . . DRS-310/29  
 BUMPER, Sliding Door . . . . . DRS-310/30  
 BUMPER, Sliding Door . . . . . IRS-420/12  
 BUMPER, Sliding Door Hinge . . . . . DRS-310/27  
 BUNDLE, Fuel Line . . . . . 014-310/1  
 BUSHING . . . . . IRS-815/6

BUSHING .....	41TE-AE-240/27	CAP, Door Lock Cylinder, Bright .....	23D-105/19
BUSHING, Caliper .....	005-220/6	CAP, Door Lock Cylinder, Bright .....	23D-105/29
BUSHING, Caliper .....	005-155/15	CAP, Fuel Filler .....	014-210/5
BUSHING, Front Pump .....	31TH-320/8	CAP, Handle Screw Cover .....	IRS-510/13
BUSHING, Front Pump .....	41TE-AE-320/9	CAP, Handle Screw Cover .....	IRS-515/12
BUSHING, Hood Hinge Pivot .....	SRS-510/6	CAP, Heater Hose, 5/8" .....	024-205/6
BUSHING, Idler Pulley .....	007-425/5	CAP, Master Cylinder Reservoir .....	005-416/4
BUSHING, Isolator .....	003-135/5	CAP, Oil Filler .....	2.4L-210/7
BUSHING, Isolator Mounting Leg .....	014-810/3	CAP, Oil Filler .....	3.8L-210/6
BUSHING, Isolator Mounting Leg .....	014-830/4	CAP, Oil Filler .....	3.3L6T-210/6
BUSHING, Lower Control Arm .....	002-145/25	CAP, Oil Pressure Relief Valve .....	2.4L-710/14
BUSHING, Pedal Shaft .....	005-645/2	CAP, Oil Pressure Relief Valve .....	3.8L-710/16
BUSHING, Pivot .....	017-155/2	CAP, Oil Pressure Relief Valve .....	3.3L6T-710/18
BUSHING, Pivot .....	002-145/24	CAP, Power Steering Pump .....	019-720/11
BUSHING, Pivot .....	017-145/16	CAP, Power Steering Pump .....	019-730/12
BUSHING, Spring .....	017-145/7	CAP, Radiator .....	007-105/7
BUSHING, Spring .....	017-155/3	CAP, Radiator .....	007-175/2
BUSHING, Sway Bar .....	017-145/14	CAP, Vacuum .....	025-410/4
BUSHING, Sway Bar .....	017-145/27	CAP, Valve Stem, Chrome .....	022-140/4
BUSHING, Sway Bar .....	017-155/17	CAP, Valve Stem, Chrome .....	022-140/14
BUTTON, Adjuster .....	IRS-710/6	CAP, Washer Reservoir .....	23D-210/12
BUTTON, Adjuster .....	IRS-740/5	CAP, Wheel Center .....	022-140/8
BUTTON, Rear View Mirror .....	SRS-710/5	CAP, Wheel Center .....	022-240/6
		CAP, Wiper Arm Nut .....	23D-305/7
		CAPACITOR, Ignition .....	008-1905/16
		CARGO ORGANIZER .....	IRS/245
		CARPET .....	IRS/310
		CARPET, Floor .....	IRS-310/1
		CARRIER AND BEARING, Planet Pinion .....	41TE-AE-440/1
		CARRIER KIT - CANOE .....	001/230
		CARRIER KIT - LUGGAGE .....	001/272
		CARRIER KIT - SKI, HITCH MOUNT .....	001/220
		CARRIER KIT - VINYL .....	001/274
		CARRIER KIT - WATER SPORTS .....	001/232
		CARRIER KIT, Bike .....	001-210/1
		CARRIER KIT, Bike .....	001-212/1
		CARRIER KIT, Bike .....	001-214/1
		CARRIER KIT, Bike .....	001-216/1
		CARRIER KIT, Canoe .....	001-230/1
		CARRIER KIT, Luggage .....	001-272/1
		CARRIER KIT, Luggage .....	001-274/1
		CARRIER KIT, Ski - 4 Pair .....	001-220/1
		CARRIER KIT, Water Sports .....	001-232/1
		CARRIER, Balance Shaft .....	2.4L-620/2
		CARRIER, Instrument Panel .....	08A-105/23
		CARRIER, Planetary Pinion .....	31TH-445/7
		CARRIER, Planetary Pinion .....	31TH-460/4
		CARRIER, Planetary Pinion .....	41TE-AE-440/55
		CASE, Differential .....	41TE-AE-820/5
		CASE, EXTENSION AND RETAINER .....	31TH/215
		CASE, EXTENSION AND SOLENOID .....	41TE-AE/240
		CASE, Transaxle .....	31TH-820/3
		CASE, Transaxle .....	41TE-AE-240/3
		CASE, Transaxle Rear .....	41TE-AE-240/29
		CASE, Transmission .....	31TH-215/40
		CHAIN PACKAGE, Timing .....	3.8L-610/3
		CHAIN PACKAGE, Timing .....	3.3L6T-610/3
		CHAIN, Balance .....	2.4L-620/1
		CHANGER, CD .....	001-110/2
		CHANGER, CD .....	08A-305/5
		CHANNEL, Instrument Panel Top Cover .....	08A-105/2
		CHECK BALL, Dia-.187 .....	31TH-435/2
		CHECK BALL, Dia-.187 .....	31TH-415/12
		CHECK VALVE, Washer .....	23D-210/20
		CHECK, Front Door .....	DRS-180/36
		CHOKE, Speaker .....	DRS-190/7
		CHOKE, Speaker .....	08A-310/13
		CIRCLIP, Half Shaft .....	002-245/2
		CLAMP .....	014-810/9
		CLAMP .....	014-830/10
		CLAMP .....	23D-205/21
		CLAMP, Exhaust .....	011-110/6

**-C-**

C PILLAR .....	IRS/225
CABLE .....	DRS-310/7
CABLE .....	DRS-310/8
CABLE KIT, IGNITION .....	008-1905/1
CABLE PACKAGE, Ignition .....	008-1905/3
CABLE, Antenna Extension .....	08A-310/15
CABLE, Drive .....	DRS-310/16
CABLE, Gearshift Control .....	31TH-1225/1
CABLE, Gearshift Control .....	41TE-AE-1225/1
CABLE, Ignition .....	008-1905/2
CABLE, Ignition .....	008-1905/4
CABLE, Ignition .....	008-1905/5
CABLE, Parking Brake .....	004-142/9
CABLE, Parking Brake .....	004-147/1
CABLE, Parking Brake .....	004-147/2
CABLE, Parking Brake .....	004-147/3
CABLE, Parking Brake .....	004-147/4
CABLE, Recliner .....	IRS-815/8
CABLE, Recliner .....	IRS-820/3
CABLE, Recliner .....	IRS-825/7
CABLE, Recliner .....	IRS-830/13
CABLE, Sliding Door Release .....	DRS-310/6
CABLE, Speed Control .....	014-1010/3
CABLE, Throttle Control .....	014-740/2
CABLE, Throttle Control .....	014-760/2
CABLE, Trans Kickdown .....	014-740/7
CABLES, PARKING BRAKE .....	004/147
CALIPER, Disc Brake .....	005-220/5
CALIPER, Disc Brake .....	005-155/10
CAM MAGNET, Target .....	008-605/2
CAM MAGNET, Target .....	2.4L-510/17
CAMSHAFT & VALVES, 3.3L [EGA], [EGM] .....	3.3L6T/510
CAMSHAFT AND VALVES 2.4L [EDZ] .....	2.4L/510
CAMSHAFT AND VALVES 3.8L EGH ENGINE .....	3.8L/510
CAMSHAFT, Engine .....	3.8L-510/18
CAMSHAFT, Engine .....	3.3L6T-510/16
CAMSHAFT, Exhaust .....	2.4L-510/6
CAMSHAFT, Intake .....	2.4L-510/5
CANISTER, Vapor .....	025-310/1
CANISTER, Vapor .....	025-310/11
CAP NUT, Antenna, Black .....	08A-310/19
CAP, A/C Charge Valve .....	024-210/16
CAP, A/C Check Valve .....	024-220/5
CAP, Alternator Pulley .....	008-215/8
CAP, Assist Handle Screw Cover .....	IRS-215/4
CAP, Bleeder .....	005-220/9
CAP, Bleeder .....	005-155/20
CAP, Bleeder .....	005-210/19
CAP, Coolant Reserve Tank .....	007-330/5

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

CLAMP, HOSE, Open Dia = M15.0 Thk = .88 . . . . .	025-310/15	CLIP, Tube . . . . .	005-565/21
CLAMP, Heater Hose . . . . .	024-205/7	CLIP, Vapor Line . . . . .	014-310/2
CLAMP, Heater Hose . . . . .	2.4L-910/3	CLIP, Vapor Line . . . . .	014-310/6
CLAMP, Hose . . . . .	007-330/7	CLIP, Washer Hose . . . . .	23D-210/9
CLAMP, Hose . . . . .	014-210/4	CLIP, Washer Hose . . . . .	23D-210/24
CLAMP, Hose, Snap Type . . . . .	025-310/7	CLIP, Washer Hose And Wiring . . . . .	23D-210/19
CLAMP, Hose, Snap Type . . . . .	025-310/17	CLIP, Wiring . . . . .	008-1605/3
CLAMP, Hose, Snap Type . . . . .	025-310/18	CLOCKSPRING . . . . .	008-805/4
CLAMP, Oil Cooler Tube . . . . .	007-630/4	CLOCKSPRING . . . . .	019-145/12
CLAMP, Power Steering Hose . . . . .	019-720/7	CLOCKSPRING . . . . .	019-245/17
CLAMP, Stabilizer Bar to Sill . . . . .	002-145/31	CLUSTER, Instrument Panel . . . . .	08A-205/1
CLAMP, Supply Hose, 26 mm Diameter . . . . .	024-205/16	CLUSTER--INSTRUMENT PANEL . . . . .	08A/205
CLIP . . . . .	005-645/8	CLUTCH OVERHAUL KIT, A/C Compressor . . . . .	024-410/7
CLIP . . . . .	SRS-520/7	CLUTCH OVERHAUL KIT, A/C Compressor . . . . .	024-410/12
CLIP . . . . .	005-210/12	CLUTCH OVERHAUL KIT, A/C Compressor . . . . .	024-410/20
CLIP . . . . .	005-431/13	CLUTCH, FRONT . . . . .	31TH/435
CLIP . . . . .	007-175/12	CLUTCH, INPUT SHAFT . . . . .	41TE-AE/425
CLIP . . . . .	007-330/10	CLUTCH, REAR AND INPUT SHAFT . . . . .	31TH/415
CLIP . . . . .	DRS-180/37	COIL, Ignition . . . . .	008-1905/8
CLIP . . . . .	SRS-915/29	COIL, Ignition . . . . .	008-1905/18
CLIP, A/C Liquid Line . . . . .	024-220/17	COIL, Stator, A/C Compressor Clutch . . . . .	024-410/8
CLIP, A/C Suction Line . . . . .	024-210/22	COIL, Stator, A/C Compressor Clutch . . . . .	024-410/14
CLIP, Air Duct . . . . .	024-610/11	COLLAR, Structural, Oil Pan To Transmission . . . . .	009-140/23
CLIP, B-Pillar Applique, .53 Diameter . . . . .	ERS-210/8	COLLAR, Structural, Oil Pan To Transmission . . . . .	31TH-210/16
CLIP, B-Pillar Applique, .53 Diameter . . . . .	ERS-220/14	COLUMN, STEERING UPPER AND LOWER, . . . . .	019/245
CLIP, Bezel . . . . .	008-815/6	COLUMN, Steering, Tilt . . . . .	019-245/1
CLIP, Bracket . . . . .	019-720/3	COLUMN, steering, non tilt . . . . .	019-245/2
CLIP, Bracket . . . . .	019-730/5	COMPACT DISC, Navigation . . . . .	001-130/2
CLIP, Bracket and Fuel Tube . . . . .	005-569/2	COMPRESSOR AND MOUNTING BRACKETS, ENGINES . . . . .	024/410
CLIP, Brake . . . . .	005-561/15	COMPRESSOR, Air Conditioning . . . . .	024-410/4
CLIP, Brake Caliper . . . . .	005-155/12	COMPRESSOR, Air Conditioning . . . . .	024-410/10
CLIP, Brake Tube Sensor . . . . .	005-565/4	CONDENSER, Air Conditioning . . . . .	024-220/9
CLIP, Brake Tube Sensor . . . . .	005-565/10	CONDENSER, Air Conditioning . . . . .	024-210/14
CLIP, Brake Tube Sensor . . . . .	005-565/17	CONNECTOR KIT, Transmission Oil Cooler Line . . . . .	007-630/5
CLIP, Cable . . . . .	014-740/3	CONNECTOR, "Y" Reserve Tank . . . . .	025-490/11
CLIP, Cable . . . . .	014-760/7	CONNECTOR, 7 Way . . . . .	001-295/6
CLIP, Cable . . . . .	014-1110/5	CONNECTOR, Heater Return Hose . . . . .	024-205/17
CLIP, Cable Routing . . . . .	DRS-310/9	CONNECTOR, Manifold Vacuum . . . . .	2.4L-810/16
CLIP, Cable to Servo Attach . . . . .	014-1010/6	CONNECTOR, Manifold Vacuum . . . . .	2.4L-810/17
CLIP, Coolant Reserve Bottle to Battery Tray . . . . .	007-330/8	CONNECTOR, Oil Cooler Hose . . . . .	31TH-210/12
CLIP, Cooler Line . . . . .	019-730/8	CONNECTOR, Oil Cooler Hose . . . . .	31TH-210/14
CLIP, Cylinder Retainer . . . . .	23D-105/33	CONNECTOR, Oil Cooler Hose . . . . .	41TE-AE-
CLIP, Floor Pan Cover Button . . . . .	008-1505/4		240/10
CLIP, Fuel Injector . . . . .	014-440/3	CONNECTOR, Oil Filter Adapter . . . . .	2.4L-710/13
CLIP, Fuel Injector . . . . .	014-460/4	CONNECTOR, Oil Filter Adapter . . . . .	3.8L-710/22
CLIP, Headliner Mounting . . . . .	IRS-110/16	CONNECTOR, Oil Filter Adapter . . . . .	3.3L6T-710/
CLIP, Heat Shield . . . . .	011-210/5		24
CLIP, Instrument Panel . . . . .	08A-105/55	CONNECTOR, Washer Hose, In Line . . . . .	23D-210/5
CLIP, Instrument Panel, End Caps Attaching . . . . .	08A-105/46	CONNECTOR, Washer Hose, In Line . . . . .	23D-210/10
CLIP, Latch . . . . .	23D-105/17	CONNECTOR, Water Outlet . . . . .	007-105/11
CLIP, Latch . . . . .	DRS-310/46	CONNECTOR, Wiring . . . . .	008-1605/4
CLIP, Latch Link . . . . .	DRS-180/29	CONNECTOR, Wiring . . . . .	08A-410/28
CLIP, Latch Link . . . . .	DRS-310/35	CONSOLE - CENTER . . . . .	001/810
CLIP, Molding . . . . .	08A-105/3	CONSOLE, Center . . . . .	001-140/3
CLIP, Molding . . . . .	IRS-210/4	CONSOLE, Center . . . . .	001-810/1
CLIP, Molding . . . . .	IRS-215/6	CONSOLE, Floor . . . . .	001-810/2
CLIP, Molding . . . . .	IRS-220/4	CONSOLE, Floor . . . . .	08A-410/9
CLIP, Molding . . . . .	IRS-230/8	CONSOLE, Instrument Panel . . . . .	08A-410/1
CLIP, Molding . . . . .	IRS-215/11	CONSOLE, Overhead . . . . .	001-140/8
CLIP, Molding . . . . .	IRS-220/10	CONSOLE, Overhead . . . . .	001-142/7
CLIP, Molding, M8.3x15.20x0.50 . . . . .	IRS-420/5	CONSOLE, Overhead . . . . .	08A-315/9
CLIP, Moulding . . . . .	IRS-420/6	CONSOLES FLOOR AND INSTRUMENT PANEL, . . . . .	08A/410
CLIP, Mounting . . . . .	008-405/4	CONSOLES-OVERHEAD, . . . . .	08A/405
CLIP, Outside Door Handle . . . . .	DRS-180/15	CONTROL UNIT, Anti-Lock Brake . . . . .	005-431/2
CLIP, Prop Rod . . . . .	SRS-520/3	CONTROL, A/C And Heater . . . . .	024-310/1
CLIP, Push, .164-7.5 . . . . .	08A-105/63	CONTROL, A/C And Heater . . . . .	024-310/6
CLIP, Quarter Panel . . . . .	IRS-220/9	CONTROL, A/C And Heater . . . . .	08A-105/13
CLIP, Quarter Panel . . . . .	IRS-230/7	CONTROL, Electronic . . . . .	005-650/2
CLIP, Radiator Fan Shroud . . . . .	007-105/18	CONTROLLER, Vehicle Navigation . . . . .	001-130/11
CLIP, Radiator Fan Shroud . . . . .	007-175/23	CONTROLS, A/C AND HEATER, . . . . .	024/310
CLIP, Radiator Hose . . . . .	007-105/5	CONTROLS, GEARSHIFT, COLUMN SHAFT, . . . . .	41TE-AE/
CLIP, Retainer . . . . .	008-505/5		1225
CLIP, Retainer . . . . .	23D-105/20	CONTROLS, GEARSHIFT, COLUMN SHIFT, . . . . .	31TH/1225
CLIP, Roof Rail . . . . .	IRS-110/17	CONVERTER PACKAGE, Torque . . . . .	31TH-120/2
CLIP, Side Molding . . . . .	IRS-210/5	CONVERTER PACKAGE, Torque . . . . .	2.4L-410/16
CLIP, Side Molding . . . . .	IRS-1010/2	CONVERTER PACKAGE, Torque . . . . .	3.8L-410/17
CLIP, Tail Lamp . . . . .	008-1110/3	CONVERTER PACKAGE, Torque . . . . .	3.3L6T-410/
CLIP, Tube . . . . .	005-561/7		18
CLIP, Tube . . . . .	005-569/1		

CONVERTER PACKAGE, Torque	41TE-AE-120/2	COVER, Rear Seat Bracket	IRS-815/19
CONVERTER, Catalytic	011-110/1	COVER, Rear Seat Cushion	IRS-620/2
COOLANT RESERVE TANK	007/330	COVER, Rear Seat Cushion	IRS-625/2
COOLER, Engine Oil	3.8L-710/19	COVER, Rear Seat Cushion	IRS-640/19
COOLER, Engine Oil	3.3L6T-710/21	COVER, Rear Seat Cushion	IRS-640/20
COOLER, Oil	007-630/1	COVER, Rear Seat Cushion	IRS-640/23
CORD, Engine Block Heater	008-1205/4	COVER, Rear View Mirror Wire	SRS-710/10
CORD, Engine Block Heater	008-1210/4	COVER, Recliner Seat	IRS-815/1
CORD, Engine Block Heater	2.4L-320/3	COVER, Recliner Seat	IRS-815/3
CORD, Engine Block Heater	3.8L-320/3	COVER, Recliner Seat	IRS-825/1
CORD, Engine Block Heater	2.4L-310/15	COVER, Recliner Seat	IRS-825/3
CORD, Engine Block Heater	3.3L6T-320/3	COVER, Recliner Seat	IRS-830/4
CORD, Engine Block Heater	3.3L6T-310/13	COVER, Recliner Seat	IRS-830/5
CORE, Heater	024-150/5	COVER, Recliner Seat	IRS-830/6
CORE, Heater	024-120/14	COVER, Recliner Seat	IRS-830/7
CORE, Heater	024-130/14	COVER, Recliner Seat	IRS-820/12
CORE, Heater	024-140/14	COVER, Seat	IRS-510/2
COUNTER WEIGHT, Governor	31TH-620/9	COVER, Seat	IRS-515/2
COUPLING, Steering	019-245/8	COVER, Seat Back	IRS-520/2
COVER PACKAGE, Engine Timing	008-215/4	COVER, Seat Back	IRS-510/4
COVER PACKAGE, Engine Timing	3.8L-610/1	COVER, Seat Back	IRS-515/4
COVER PACKAGE, Engine Timing	3.8L-710/21	COVER, Seat Back	IRS-520/4
COVER PACKAGE, Engine Timing	3.3L6T-610/1	COVER, Seat Back	IRS-620/4
COVER PACKAGE, Engine Timing	3.3L6T-710/23	COVER, Seat Back	IRS-625/4
COVER, Accelerator Pedal Base	014-1110/4	COVER, Seat Back	IRS-640/15
COVER, Accumulator	41TE-AE-725/5	COVER, Seat Back	IRS-640/16
COVER, Air Bag Module	019-145/5	COVER, Seat Belt Retractor	IRS-750/5
COVER, Balance Shaft Carrier	2.4L-620/3	COVER, Seat Riser, Two Passenger	IRS-815/22
COVER, Balance Shaft Gear	2.4L-620/8	COVER, Sliding Door Hinge	DRS-310/14
COVER, Battery	008-1005/12	COVER, Sliding Door Track	SRS-1010/5
COVER, Center Distribution	024-620/9	COVER, Sliding Door Track	SRS-815/11
COVER, Center Distribution	024-120/24	COVER, Sliding Door Track	SRS-915/16
COVER, Control Unit	001-130/5	COVER, Speaker Opening	08A-310/10
COVER, Cylinder Head	2.4L-210/3	COVER, Steering Column Yoke	019-245/28
COVER, Cylinder Head, Left	3.8L-210/3	COVER, Steering Wheel	019-245/3
COVER, Cylinder Head, Left	3.3L6T-210/3	COVER, Steering Wheel, Without Speed Control	019-145/13
COVER, Cylinder Head, Right	3.8L-210/2	COVER, Timing Belt	2.4L-610/1
COVER, Cylinder Head, Right	3.3L6T-210/2	COVER, Timing Belt	2.4L-610/2
COVER, EGR Port	025-260/10	COVER, Timing Belt	2.4L-610/4
COVER, Engine Oil Pump	3.8L-710/14	COVER, Transaxle Converter	41TE-AE-220/13
COVER, Engine Oil Pump	3.3L6T-710/15	COVER, Transaxle Rear	31TH-215/32
COVER, Front Power Seat Adjuster	IRS-540/8	COVER, Transaxle Rear	41TE-AE-240/6
COVER, Front Power Seat Adjuster	IRS-540/12	COVER, Transmission Dust	31TH-210/10
COVER, Front Seat Back	IRS-525/5	COVER, Wheel, 15"	022-240/1
COVER, Front Seat Back	IRS-530/4	COVER, Wheel, 16"	022-240/2
COVER, Front Seat Cushion	IRS-525/3	COVER, Wiper Arm	23D-205/3
COVER, Front Seat Cushion	IRS-530/2	COVER, Wiring Protector	008-1505/2
COVER, Front Seat Riser	IRS-535/14	COVER, Wiring Protector	008-1505/3
COVER, Glove Box Lamp Hole	08A-105/34	COVERS AND CAPS, WHEELS,	022/240
COVER, Heater Core Tubes	024-120/17	COWL AND DASH PANEL,	SRS/610
COVER, Heater Core Tubes	024-130/16	COWL PANEL AND SILENCER,	IRS/210
COVER, Heater Core Tubes	024-140/16	CRANKCASE VENTILATION 2.4L [EDZ]	2.4L/910
COVER, Instrument Panel	08A-105/1	CRANKCASE VENTILATION 3.3L EGA-EGM ENGINE,	3.3L6T/910
COVER, Instrument Panel Brace	08A-105/49	CRANKCASE VENTILATION 3.8L [EGH]	3.8L/910
COVER, Instrument Panel Brace	08A-105/67	CRANKSHAFT	2.4L-410/10
COVER, Instrument Panel Opening	08A-105/19	CRANKSHAFT	3.8L-410/12
COVER, Instrument Panel, Steering Column Opening	08A-105/25	CRANKSHAFT	3.3L6T-410/12
COVER, Intake Manifold	3.3L6T-810/11		12
COVER, Jack	IRS-240/9	CRANKSHAFT AND PISTONS 2.4L [EDZ]	2.4L/410
COVER, Lamp Opening	IRS-1010/14	CRANKSHAFT AND PISTONS 3.3L [EGA],[EGM]	3.3L6T/410
COVER, Mirror	DRS-510/7	CRANKSHAFT AND PISTONS 3.8L EGH ENGINE,	3.8L/410
COVER, Oil Pump Back	2.4L-710/19	CROSSMEMBER, Floor Pan	SRS-210/9
COVER, Power Distribution Center	008-505/2	CROSSMEMBER, Floor Pan	013-120/11
COVER, Power Distribution Center	008-1305/3	CROSSMEMBER, Floor Pan	013-120/12
COVER, Quarter Trim Opening	IRS-240/8	CROSSMEMBER, Floor Pan	013-120/14
COVER, RISER	IRS-830/17	CROSSMEMBER, Floor Pan	013-120/15
COVER, Radio Opening	08A-310/14	CROSSMEMBER, Front Stowage Box	IRS-535/18
COVER, Rear Floor Escutcheon	IRS-810/4	CROSSMEMBER, Fuel Tank	013-120/13
COVER, Rear Floor Escutcheon	IRS-810/5	CROSSMEMBER, Radiator	013-110/6
COVER, Rear Seat Bracket	IRS-825/8	CROSSMEMBER, Radiator	013-110/9
		CROSSOVER, Exhaust Manifold	3.8L-810/19
		CROSSOVER, Exhaust Manifold	3.3L6T-810/15
		CUP HOLDER, Rear Seat	IRS-830/20
		CUP, Differential Side Bearing	31TH-215/6
		CUP, Differential Side Bearing	31TH-820/12

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

CUP, Differential Side Bearing	41TE-AE-240/34
CUP, Differential Side Bearing	41TE-AE-820/16
CUP, Door Pull	IRS-410/10
CUP, Door Pull	IRS-420/17
CUP, Parking Brake Sprag	41TE-AE-740/5
CUPHOLDER	IRS-820/24
CUPHOLDER, Instrument Panel	08A-105/39
CUSHION, 50/50 BENCH	IRS-640/17
CUSHION, 50/50 BENCH	IRS-640/18
CUSHION, Front Seat	IRS-510/1
CUSHION, Front Seat	IRS-515/1
CUSHION, Front Seat	IRS-520/1
CUSHION, Front Seat	IRS-525/1
CUSHION, Front Seat	IRS-530/1
CUSHION, Headphone	001-142/4
CUSHION, Headphone	001-140/14
CUSHION, Quad Seat	IRS-620/1
CUSHION, Quad Seat	IRS-625/1
CUSHION, Quad Seat	IRS-630/1
CUSHION, Quad Seat	IRS-635/1
CUSHION, Rear Seat, Three Passenger	IRS-640/5
CUSHION, Rear Seat, Three Passenger	IRS-640/9
CUSHION, Rear Seat, Two Passenger	IRS-610/1
CUSHION, Rear Seat, Two Passenger	IRS-615/1
CUSHION, Sway Eliminator	002-145/32
CYLINDER BLOCK 2.4L [EDZ]	2.4L/310
CYLINDER BLOCK 3.3L [EGA],[EGM]	3.3L6T/310
CYLINDER BLOCK 3.8L [EGH]	3.8L/310
CYLINDER HEAD 2.4L [EDZ]	2.4L/210
CYLINDER HEAD 3.3L [EGA],[EGM]	3.3L6T/210
CYLINDER HEAD 3.8L EGH ENGINE	3.8L/210
CYLINDER, Door Lock	23D-105/9
CYLINDER, Glove Box Lock	001-810/10
CYLINDER, Glove Box Lock	23D-105/38
CYLINDER, Ignition Lock	23D-105/3
CYLINDER, Wheel	005-210/2

**-D-**

D PILLAR	IRS/230
DAM, Differential Extension Oil	31TH-215/28
DAM, Differential Extension Oil	41TE-AE-240/11
DAMPER, Crankshaft	007-425/7
DAMPER, Crankshaft	3.8L-410/15
DAMPER, Crankshaft	3.3L6T-410/15
DAMPER, Engine Vibration	007-404/1
DAMPER, Engine Vibration	2.4L-610/12
DAMPER, Steering Wheel	019-145/10
DAMPER, Steering Wheel	019-245/31
DAMPER, Strut	002-145/1
DECAL, A/C System Specification	013-260/15
DETENT, Valve Body	31TH-715/8
DETENT, Valve Body	41TE-AE-715/19
DIFFERENTIAL	31TH/820
DIFFERENTIAL	41TE-AE/820
DIFFERENTIAL, REAR-ALL WHEEL DRIVE	003/115
DIFFERENTIAL, Rear Axle	003-115/1
DIFFERENTIAL, Transaxle	31TH-820/1
DIFFERENTIAL, Transaxle	41TE-AE-820/1
DISC, Clutch	31TH-415/18
DISC, Clutch	41TE-AE-425/10
DISC, Clutch	41TE-AE-425/14
DISC, Clutch	41TE-AE-425/25
DISC, Clutch	41TE-AE-440/44
DISC, Clutch	41TE-AE-440/67
DISC, Direct Clutch	31TH-435/7

DOOR PANEL - FRONT	IRS/410
DOOR PANEL - REAR SLIDING	IRS/420
DOOR, FRONT,Glass, Regulators and Speakers	DRS/190
DOOR, FRONT,Shell, Hinges and Handles	DRS/180
DOOR, Filter Access, A/C and Heater Unit	024-120/4
DOOR, Filter Access, A/C and Heater Unit	024-130/4
DOOR, Filter Access, A/C and Heater Unit	024-140/4
DOOR, Front	DRS-180/1
DOOR, Fuel Fill	SRS-915/26
DOOR, GLASS AND HARDWARE	DRS/310
DOOR, Glove Box	08A-105/32
DOOR, Instrument Panel Console	08A-410/27
DOOR, Panel	001-140/5
DOOR, Sliding	DRS-310/1
DOWEL, Block To Clutch Housing	2.4L-310/6
DOWEL, Block To Clutch Housing	3.8L-310/10
DOWEL, Block To Clutch Housing	31TH-210/11
DOWEL, Block To Clutch Housing	3.3L6T-310/10
DOWEL, Block To Cylinder Head	2.4L-310/4
DOWEL, Block To Cylinder Head	3.8L-310/3
DOWEL, Block To Cylinder Head	3.3L6T-310/3
DOWEL, Crankshaft Sprocket	3.8L-610/9
DOWEL, Crankshaft Sprocket	3.3L6T-610/9
DOWEL, Engine Block To Bedplate	2.4L-310/7
DOWEL, M6x14	3.8L-610/6
DOWEL, M6x14	3.3L6T-610/6
DOWEL, M6x16	31TH-715/6
DOWEL, M6x16	31TH-215/41
DRAINCOCK, Radiator	007-105/6
DRAINCOCK, Radiator	007-175/3
DRAWER, Cupholder	IRS-610/15
DRAWER, Cupholder	IRS-615/15
DRAWER, Cupholder	IRS-815/26
DRAWER, Front Seat Storage	IRS-535/20
DRIER, Receiver	024-210/12
DRIER, Receiver	024-220/22
DRIVE BELTS	007/530
DRIVE BELTS,2.4L Engine	007/520
DRUM, Automatic Transmission	31TH-460/6
DRUM, Brake	005-210/21
DUCT, Aux A/C And Heater	024-620/4
DUCT, Defroster	024-610/2
DUCT, Floor Distribution	024-620/1
DUCT, Floor Distribution	024-620/2
DUCT, Floor Distribution	024-620/3
DUCT, Fresh Air	014-840/1
DUCT, Heater Distribution	024-620/5
DUCT, Instrument Panel Demister	024-610/1
DUCT, Instrument Panel Door Extension	024-610/5
DUCT, Instrument Panel Door Extension	024-610/10
DUCTS AND OUTLETS, FRONT	024/610
DUCTS AND OUTLETS, REAR	024/620

**-E-**

EGR SYSTEM 2.4L [EDZ]	025/240
EGR SYSTEM 3.3L-3.8L [EGA],[EGH],[EGM]	025/260
ELEMENT, Air Cleaner	014-810/2
ELEMENT, Air Cleaner	014-830/2
EMBLEM	3.8L-810/13
EMBLEM	3.3L6T-810/3
EMISSION HARNESS	025/410
EMISSION LABELS	025/110
END CAP, Instrument Panel	08A-105/45
END CAP, Roof Rack Side Rail	001-292/3
END CAP, Running Board	001-430/2
END, Tie Rod	019-321/6
ENGINEMOUNTS2.4L[EDZ],4CylinderDOHC16VSMPI	009/140
ENGINE MOUNTS 3.3L-3.8L [EGA],[EGH],[EGM]	009/160
ENGINE MOUNTS POWER TRANSFER UNIT AWD	009/170
ENGINE OILING 2.4L [EDZ]	2.4L/710
ENGINE OILING 3.3L EGA-EGM ENGINE	3.3L6T/710
ENGINE OILING 3.8L[EGH]	3.8L/710
EQUALIZER, Parking Brake Cable	004-147/7
ESCUTCHEON, Seat Anchor	IRS-245/1
ESCUTCHEON, Seat Anchor	IRS-810/1
ESCUTCHEON, Seat Anchor	IRS-810/3
EVAPORATOR, Air Conditioning	024-150/4
EVAPORATOR, Air Conditioning	024-120/10



EVAPORATOR, Air Conditioning . . . . . 024-130/10  
 EVAPORATOR, Air Conditioning . . . . . 024-140/10  
 EXHAUST SYSTEM, . . . . . 011/110  
 EXHAUSTER, Quarter Panel . . . . . SRS-910/5  
 EXTENDER, Seat Belt . . . . . IRS-710/8  
 EXTENSION PACKAGE, Transmission Rear . . . . . 31TH-215/44  
 EXTENSION, A/C Evaporator . . . . . 024-150/9  
 EXTENSION, Body Side Aperture . . . . . SRS-915/21  
 EXTENSION, Headlamp . . . . . 008-1105/12  
 EXTENSION, Liftgate Opening . . . . . SRS-1310/7  
 EXTENSION, Rear Rail . . . . . 013-360/3  
 EXTENSION, Tail Lamp Opening . . . . . SRS-915/19  
 EXTENSION, Tail Lamp Opening . . . . . SRS-915/20  
 EXTENSION, Wheel House . . . . . SRS-910/17  
 EXTENSION, Wheel House . . . . . SRS-915/39

**-F-**

FACE PLATE, Console . . . . . 08A-405/9  
 FACE PLATE, Console . . . . . 08A-410/25  
 FACE PLATE, Cupholder . . . . . IRS-610/14  
 FACE PLATE, Cupholder . . . . . IRS-615/14  
 FACE PLATE, Cupholder . . . . . IRS-815/27  
 FAN MODULE, Radiator Cooling . . . . . 007-175/5  
 FAN MODULE, Radiator Cooling . . . . . 007-105/12  
 FASCIA, FRONT, . . . . . 013/260  
 FASCIA, Front . . . . . 013-260/2  
 FASCIA, Front, Primed . . . . . 013-260/1  
 FASCIA, REAR, . . . . . 013/360  
 FASCIA, Rear . . . . . 013-360/8  
 FASCIA, Rear, Primed . . . . . 013-360/7  
 FASTENER . . . . . 005-650/6  
 FASTENER . . . . . 019-245/34  
 FASTENER, Door Trim Panel . . . . . IRS-410/7  
 FASTENER, Door Trim Panel . . . . . 08A-105/10  
 FASTENER, Door Trim Panel . . . . . IRS-410/15  
 FASTENER, Door Trim Panel . . . . . IRS-420/10  
 FASTENER, Door Trim Panel . . . . . IRS-420/16  
 FASTENER, Door Trim Panel . . . . . IRS-1010/13  
 FASTENER, Push Pin . . . . . IRS-220/8  
 FASTENER, Push Pin . . . . . IRS-230/6  
 FASTENER, Tail Lamp, 190-16 x .625 . . . . . 008-1110/2  
 FASTENER, Trim Panel Attaching . . . . . IRS-220/7  
 FASTENER, Trim Panel Attaching . . . . . IRS-230/5  
 FASTENER, Trim Panel Attaching . . . . . IRS-230/9  
 FASTENER, Trim Panel Attaching . . . . . IRS-220/11  
 FENDER PACKAGE, Front . . . . . SRS-410/4  
 FILLER, Lower Instrument Panel . . . . . 08A-105/43  
 FILTER KIT, Cabin Air . . . . . 024-120/3  
 FILTER KIT, Cabin Air . . . . . 024-130/3  
 FILTER KIT, Cabin Air . . . . . 024-140/3  
 FILTER KIT, Fuel . . . . . 014-310/8  
 FILTER PACKAGE, Transmission Oil . . . . . 41TE-AE-715/14  
 FILTER, Engine Oil . . . . . 3.8L-710/1  
 FILTER, Engine Oil . . . . . 2.4L-710/12  
 FILTER, Engine Oil . . . . . 3.3L6T-710/1  
 FILTER, Fuel . . . . . 014-310/4  
 FILTER, Fuel . . . . . 014-510/3  
 FILTER, Fuel Tank Air . . . . . 025-490/5  
 FILTER, Reverse And O/D Clutch . . . . . 41TE-AE-425/48  
 FILTER, Transmission Governor . . . . . 31TH-620/10  
 FILTER, Valve Body . . . . . 31TH-715/17  
 FITTING, Ball Joint, Zirc . . . . . 002-145/20  
 FITTING, Engine Oil Cooler . . . . . 3.8L-710/23  
 FITTING, Engine Oil Cooler . . . . . 3.3L6T-710/25  
 FITTING, Reducer . . . . . 31TH-460/7  
 FITTING, Y-Style . . . . . 3.8L-810/29  
 FITTING, Y-Style . . . . . 3.3L6T-810/27  
 FLANGE, Axle Output . . . . . 003-115/2  
 FLANGE, Driveshaft Yoke . . . . . 003-115/8  
 FLANGE, Output . . . . . 088-120/54  
 FLAP AND SPRING ASSEMBLY, Cupholder . . . . . IRS-820/27  
 FLOOR PAN, . . . . . SRS/210  
 FOAM BLOCKER KIT . . . . . 23D-205/16  
 FOAM PAD, Antirattle Rear Door Lock . . . . . DRS-310/58

FOAM PAD, Fuel Door Blocker Link . . . . . SRS-915/30  
 FRAME, FRONT, . . . . . 013/110  
 FRAME, REAR, . . . . . 013/120  
 FRAME, Seat Cushion, Three Passenger . . . . . IRS-825/14  
 FRAME, Windshield . . . . . SRS-810/8  
 FRAME, Windshield . . . . . SRS-1110/2  
 FRAME, Windshield Side . . . . . SRS-810/4  
 FRESH AIR DUCT . . . . . 014/840  
 FRONT FENDER AND SHIELD, . . . . . SRS/410  
 FRONT SEAT - ATTACHING PARTS, . . . . . IRS/535  
 FRONT SEAT - ATTACHING PARTS, . . . . . IRS/540  
 FUEL LINES AND FILTER, . . . . . 014/310  
 FUEL PUMP AND LEVEL UNIT, . . . . . 014/510  
 FUEL RAIL 2.4L EDZ ENGINE, . . . . . 014/440  
 FUEL RAIL 3.3L-3.8L ENGINES,[EGA],[EGH],[EGM] . . . . . 014/460  
 FUEL TANK FILLER TUBE, . . . . . 014/210  
 FUSE CARTRIDGE, 30 Amp . . . . . 008-505/14  
 FUSE CARTRIDGE, 40 Amp . . . . . 008-505/15  
 FUSE, Mini, 10 AMP, Red . . . . . 008-505/10  
 FUSE, Mini, 15 AMP, Light Blue . . . . . 008-505/11  
 FUSE, Mini, 20 AMP, Yellow . . . . . 008-505/12  
 FUSE, Mini, 25 Amp, Natural . . . . . 008-505/13

**-G-**

GASKET . . . . . 31TH-215/5  
 GASKET . . . . . 31TH-215/33  
 GASKET . . . . . 31TH-215/38  
 GASKET & O RING KIT, A/C Line . . . . . 024-210/6  
 GASKET & O RING KIT, A/C Line . . . . . 024-220/2  
 GASKET & O RING KIT, A/C Line . . . . . 024-220/7  
 GASKET & O RING KIT, A/C Line . . . . . 024-210/18  
 GASKET & O RING KIT, A/C Line . . . . . 024-220/16  
 GASKET AND SEAL PACKAGE, Transaxle . . . . . 31TH-215/1  
 GASKET PACKAGE, Engine . . . . . 2.4L-210/1  
 GASKET PACKAGE, Engine . . . . . 2.4L-310/1  
 GASKET PACKAGE, Engine Lower . . . . . 3.8L-310/1  
 GASKET PACKAGE, Engine Lower . . . . . 3.3L6T-310/1  
 GASKET PACKAGE, Engine Oil Pan . . . . . 3.8L-710/6  
 GASKET PACKAGE, Engine Oil Pan . . . . . 3.3L6T-710/6  
 GASKET PACKAGE, Engine Upper . . . . . 2.4L-210/2  
 GASKET PACKAGE, Engine Upper . . . . . 2.4L-310/2  
 GASKET PACKAGE, Engine Upper . . . . . 3.8L-210/1  
 GASKET PACKAGE, Engine Upper . . . . . 3.3L6T-210/1  
 GASKET PACKAGE, Valve Body . . . . . 41TE-AE-715/1  
 GASKET, Chain Case Cover . . . . . 3.8L-610/13  
 GASKET, Chain Case Cover . . . . . 3.3L6T-610/13  
 GASKET, Clutch Retainer . . . . . 41TE-AE-440/10  
 GASKET, Crossover Pipe . . . . . 3.8L-810/20  
 GASKET, Crossover Pipe . . . . . 3.3L6T-810/16  
 GASKET, Cylinder Cover . . . . . 3.8L-210/4  
 GASKET, Cylinder Cover . . . . . 3.3L6T-210/4  
 GASKET, Cylinder Head . . . . . 3.8L-210/8  
 GASKET, Cylinder Head . . . . . 2.4L-210/10  
 GASKET, Cylinder Head . . . . . 3.3L6T-210/9  
 GASKET, Drain Plug . . . . . 088-120/48  
 GASKET, EGR Tube Flange . . . . . 025-240/7  
 GASKET, EGR Tube Flange . . . . . 025-240/8  
 GASKET, EGR Tube Flange . . . . . 025-260/9  
 GASKET, EGR Valve . . . . . 025-240/6  
 GASKET, EGR Valve . . . . . 025-260/7  
 GASKET, EGR Valve . . . . . 025-260/8  
 GASKET, Engine Oil Cooler . . . . . 3.8L-710/20  
 GASKET, Engine Oil Cooler . . . . . 3.3L6T-710/22  
 GASKET, Exhaust Manifold . . . . . 2.4L-810/2  
 GASKET, Exhaust Manifold to Front Converter . . . . . 011-110/3  
 GASKET, Intake Manifold . . . . . 2.4L-810/1  
 GASKET, Intake Manifold . . . . . 2.4L-810/5  
 GASKET, Intake Manifold . . . . . 3.8L-810/16  
 GASKET, Intake Manifold . . . . . 3.3L6T-810/14  
 GASKET, Intake Plenum . . . . . 3.8L-810/2  
 GASKET, Lock-up Solenoid . . . . . 31TH-715/22  
 GASKET, Oil Filter Adapter . . . . . 3.8L-710/3

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

GASKET, Oil Filter Adapter . . . . .	3.3L6T-710/3
GASKET, Oil Pan . . . . .	2.4L-710/7
GASKET, Oil Pump Relief Valve . . . . .	2.4L-710/15
GASKET, Rear Oil Seal Retainer . . . . .	3.8L-310/8
GASKET, Rear Oil Seal Retainer . . . . .	3.3L6T-310/8
GASKET, Thermostat . . . . .	007-105/9
GASKET, Throttle Body . . . . .	014-660/5
GASKET, Throttle Body To Intake . . . . .	014-640/5
GASKET, Transmission Oil Pump . . . . .	31TH-320/5
GASKET, Transmission Oil Pump . . . . .	41TE-AE- 320/6
GASKET, Transmission Fluid Filter . . . . .	31TH-715/19
GASKET, Transmission Solenoid . . . . .	41TE-AE- 240/25
GASKET, Valve Cover . . . . .	2.4L-210/4
GASKET, Water Outlet . . . . .	007-175/19
GEAR PACKAGE, Differential . . . . .	41TE-AE- 820/22
GEAR PACKAGE, Output And Transfer Shaft . . . . .	31TH-425/22
GEAR PACKAGE, Output And Transfer Shaft . . . . .	31TH-460/16
GEAR PACKAGE, Output And Transfer Shaft . . . . .	41TE-AE- 415/39
GEAR PACKAGE, Output And Transfer Shaft . . . . .	41TE-AE- 440/38
GEAR TRAIN, . . . . .	41TE-AE/440
GEAR, Annulus . . . . .	41TE-AE- 440/53
GEAR, Balance Shaft . . . . .	2.4L-620/12
GEAR, Balance Shaft Driven . . . . .	2.4L-620/7
GEAR, Balance Shaft Driver . . . . .	2.4L-620/6
GEAR, Camshaft . . . . .	2.4L-610/6
GEAR, Crankshaft . . . . .	2.4L-610/16
GEAR, Crankshaft . . . . .	2.4L-620/19
GEAR, Crankshaft . . . . .	3.8L-610/11
GEAR, Crankshaft . . . . .	3.3L6T-610/ 11
GEAR, Differential Drive . . . . .	31TH-820/2
GEAR, Differential Ring, 56 Teeth . . . . .	41TE-AE- 820/4
GEAR, Differential Ring, 59 Teeth . . . . .	41TE-AE- 820/3
GEAR, Differential Ring, 60 Teeth . . . . .	41TE-AE- 820/2
GEAR, Differential Side . . . . .	31TH-820/6
GEAR, Differential Side . . . . .	41TE-AE- 820/8
GEAR, Front Annulus . . . . .	31TH-445/5
GEAR, Power Steering . . . . .	019-321/1
GEAR, RACK AND PINION AND ATTACHING PARTS . . . . .	019/321
GEAR, Rear Annulus . . . . .	31TH-460/5
GEAR, Sun . . . . .	31TH-445/8
GEAR, Sun . . . . .	41TE-AE- 440/42
GEARS, FRONT ANNULUS AND SUN, . . . . .	31TH/445
GLASS, WINDSHIELD AND REAR QUARTERS, . . . . .	SRS/710
GLASS PACKAGE, Liftgate . . . . .	SRS-710/4
GLASS, Front Door . . . . .	DRS-190/1
GLASS, Mirror Replacement . . . . .	DRS-510/2
GLASS, Mirror Replacement . . . . .	DRS-510/4
GLASS, Mirror Replacement . . . . .	DRS-510/6
GLASS, Rear Quarter, Vented . . . . .	SRS-710/3
GLASS, Sliding Door . . . . .	DRS-310/41
GOVERNOR, . . . . .	31TH/620
GRILLE, Demister . . . . .	024-610/3
GRILLE, Demister . . . . .	024-610/8
GRILLE, Demister . . . . .	08A-105/38
GRILLE, Radiator . . . . .	013-260/10
GROMMET . . . . .	022-140/13
GROMMET . . . . .	23D-205/15
GROMMET . . . . .	23D-205/22
GROMMET . . . . .	SRS-610/26
GROMMET . . . . .	31TH-1225/2
GROMMET AND HOSE, Liftgate Washer . . . . .	23D-210/6
GROMMET AND SPACER, Auxiliary A/C and Heater . . . . .	024-150/11
GROMMET, Air Cleaner Bracket . . . . .	014-810/6
GROMMET, Air Cleaner Bracket . . . . .	014-830/6
GROMMET, Air Cleaner Bracket . . . . .	025-310/4

GROMMET, Brake Booster Check Valve . . . . .	005-343/5
GROMMET, Floor Carpet . . . . .	IRS-310/4
GROMMET, Glass . . . . .	23D-305/8
GROMMET, Hose to Reservoir . . . . .	23D-210/21
GROMMET, Lamp . . . . .	008-1110/6
GROMMET, Master Cylinder Reservoir . . . . .	005-416/8
GROMMET, Throttle Control Cable . . . . .	014-740/1
GROMMET, Throttle Control Cable . . . . .	014-760/1
GROMMET, Throttle Control Cable . . . . .	014-1110/2
GROMMET, Washer Reservoir . . . . .	23D-210/15
GROMMET, Washer Reservoir . . . . .	23D-210/17
GUIDE PACKAGE, Parking Sprag Pawl . . . . .	41TE-AE- 740/1
GUIDE, Balance Shaft Chain . . . . .	2.4L-620/11
GUIDE, Front Seat Storage Drawer . . . . .	IRS-535/19
GUIDE, Intake/Exhaust Valve, 7mm Oversize . . . . .	2.4L-510/13
GUIDE, Intake/Exhaust Valve, Standard Size . . . . .	3.8L-510/24
GUIDE, Intake/Exhaust Valve, Standard Size . . . . .	3.3L6T-510/ 22
GUIDE, Kickdown Servo . . . . .	31TH-725/3

**-H-**

HANDLE . . . . .	IRS-830/19
HANDLE AND ACTUATOR, Rear Quarter Power . . . . .	SRS-710/12
HANDLE, Door Interior . . . . .	DRS-180/4
HANDLE, Door Interior . . . . .	DRS-180/5
HANDLE, Door Interior . . . . .	DRS-180/6
HANDLE, Door Interior . . . . .	DRS-180/7
HANDLE, Door Interior . . . . .	DRS-180/8
HANDLE, Door Interior . . . . .	DRS-180/9
HANDLE, Door Interior . . . . .	DRS-180/10
HANDLE, Front Door Exterior . . . . .	DRS-180/13
HANDLE, Grab . . . . .	IRS-215/3
HANDLE, Grab . . . . .	08A-105/41
HANDLE, Grab, With Reading Lamp . . . . .	IRS-110/14
HANDLE, Grab, With Reading Lamp . . . . .	008-1115/18
HANDLE, Latch Release . . . . .	IRS-815/25
HANDLE, Latch Release . . . . .	IRS-825/19
HANDLE, Liftgate . . . . .	IRS-1010/7
HANDLE, Liftgate . . . . .	SRS-1330/4
HANDLE, Liftgate . . . . .	008-1110/13
HANDLE, Lumbar . . . . .	IRS-540/2
HANDLE, Parking Brake . . . . .	004-142/2
HANDLE, Parking Brake . . . . .	08A-105/17
HANDLE, Recliner . . . . .	IRS-535/1
HANDLE, Recliner . . . . .	IRS-820/19
HANDLE, Seat Adjuster . . . . .	IRS-535/3
HANDLE, Seat Back . . . . .	IRS-525/9
HANDLE, Seat Back . . . . .	IRS-530/8
HANDLE, Seat Back . . . . .	IRS-510/12
HANDLE, Seat Release . . . . .	IRS-820/14
HANDLE, Seat Release . . . . .	IRS-830/21
HANDLE, Seat Riser . . . . .	IRS-815/24
HANDLE, Seat Riser . . . . .	IRS-825/18
HANDLE, Sliding Door Assist . . . . .	DRS-310/23
HANDLE, Sliding Door Exterior . . . . .	DRS-310/44
HANDLE, Window Regulator . . . . .	DRS-190/9
HANGER, Front Spring . . . . .	017-145/3
HANGER, Front Spring . . . . .	017-155/5
HANGER, Leaf Spring . . . . .	017-145/6
HANGER, Leaf Spring . . . . .	017-155/9
HARDWARE KIT, Accessory . . . . .	001-214/2
HARDWARE KIT, Accessory . . . . .	001-216/2
HARDWARE KIT, Accessory . . . . .	001-230/2
HARDWARE KIT, Accessory . . . . .	001-232/2
HARDWARE KIT, Bike Carrier . . . . .	001-210/5
HARDWARE KIT, Bike Carrier . . . . .	001-212/5
HARDWARE KIT, Bike Carrier . . . . .	001-216/4
HARNES . . . . .	005-650/8
HARNES . . . . .	008-1505/21
HARNES PACKAGE, Wiring . . . . .	008-1505/24
HARNES PACKAGE, Wiring . . . . .	008-1505/25
HARNES, EGR Supply . . . . .	025-240/5
HARNES, EGR Vacuum . . . . .	025-260/3
HARNES, LDP Vacuum Source . . . . .	025-490/7
HARNES, Leak Detection Pump . . . . .	025-490/1
HARNES, Leak Detection Pump To Canister . . . . .	025-490/8
HARNES, Proportional Purge Solenoid . . . . .	025-410/1

HARNESSES, Vacuum Speed Control	014-1010/4	HOSE, Heater	024-205/1
HEAD, Cylinder	2.4L-210/9	HOSE, Heater	024-230/8
HEAD, Cylinder	3.8L-210/7	HOSE, Heater	024-230/9
HEAD, Cylinder	3.3L6T-210/7	HOSE, Heater	024-150/17
HEADLINER	IRS-110/1	HOSE, Heater Return	024-205/5
HEADLINER AND VISOR	IRS/110	HOSE, Heater Return	024-205/11
HEADPHONES, Wireless	08A-315/11	HOSE, Heater Return	024-205/12
HEADPHONES, Wireless Infrared	001-142/5	HOSE, Heater Supply	024-205/13
HEADPHONES, Wireless Infrared	001-140/13	HOSE, Heater, 5/8 Roll Stock	024-230/14
HEADPHONES, Wireless Infrared	08A-310/26	HOSE, Liftgate Washer, Interior Floor	23D-305/9
HEADREST	IRS-525/6	HOSE, Oil Cooler Outlet	024-205/8
HEADREST	IRS-530/5	HOSE, Overflow, Roll Stock	007-330/6
HEADREST	IRS-815/11	HOSE, PCV Valve To Intake Manifold	2.4L-910/1
HEADREST, Front	IRS-510/6	HOSE, PCV Valve To Intake Manifold	3.8L-910/2
HEADREST, Front	IRS-515/6	HOSE, PCV Valve To Intake Manifold	3.3L6T-910/2
HEADREST, Front	IRS-520/6	HOSE, Power Steering	019-720/8
HEADREST, Rear	IRS-610/5	HOSE, Power Steering Pressure	019-720/1
HEADREST, Rear	IRS-615/5	HOSE, Power Steering Pressure	019-730/2
HEADREST, Rear	IRS-620/6	HOSE, Power Steering Reservoir	019-730/10
HEADREST, Rear	IRS-625/6	HOSE, Power Steering Return	019-720/4
HEADREST, Rear	IRS-630/4	HOSE, Power Steering Return	019-730/1
HEADREST, Rear	IRS-635/4	HOSE, Radiator Inlet	007-175/17
HEADREST, Rear	IRS-640/1	HOSE, Transmission Oil Cooler	007-630/2
HEADREST, Rear	IRS-640/7	HOSE, Transmission Oil Cooler	007-630/3
HEADREST, Rear	IRS-640/12	HOSE, Vacuum, 1/8" I.D. 50 Foot Roll	025-410/6
HEADREST, Rear	IRS-820/17	HOSE, Vapor Canister Load	025-310/14
HEAT SHIELDS, EXHAUST	011/210	HOSE, Vapor Canister Pass Thru	025-310/10
HEATER BLOCK [EDZ]	2.4L/320	HOSE, Vapor Canister Purge	025-310/16
HEATER BLOCK [EGA], [EGM]	3.3L6T/320	HOSE, Windshield Washer	23D-205/5
HEATER BLOCK [EGH]	3.8L/320	HOSE, Windshield Washer	23D-210/1
HEATER, Engine Block	008-1205/3	HOSE, Windshield Washer	23D-210/3
HEATER, Engine Block	008-1210/3	HOSE, Windshield Washer	23D-210/8
HEATER, Engine Block	2.4L-320/1	HOSE, Windshield Washer	23D-210/11
HEATER, Engine Block	3.8L-320/1	HOSES, POWER STEERING, 2.4L ENGINE	019/720
HEATER, Engine Block	2.4L-310/14	HOSES, POWER STEERING, 3.3L/3.8L ENGINE	019/730
HEATER, Engine Block	3.3L6T-320/1	HOUSING PACKAGE, Steering Column Lock	019-245/18
HEATER, Engine Block	3.3L6T-310/12	HOUSING PACKAGE, Wiper Nosecone	23D-205/24
HINGE PACKAGE, Hood	SRS-510/3	HOUSING, A/C Lower	024-150/2
HINGE, Front Door	DRS-180/19	HOUSING, A/C Upper	024-150/1
HINGE, Front Door	DRS-180/22	HOUSING, Air Inlet	024-120/1
HINGE, Hood	SRS-510/2	HOUSING, Air Inlet	024-130/1
HINGE, Liftgate	SRS-1310/2	HOUSING, Air Inlet	024-140/1
HINGE, Sliding Door	DRS-310/26	HOUSING, Blower Motor	024-120/2
HINGE, Sliding Door Body Side	DRS-310/4	HOUSING, Blower Motor	024-130/2
HINGE, Sliding Door Body Side	DRS-310/40	HOUSING, Blower Motor	024-140/2
HOLDER, Coin	08A-410/2	HOUSING, Bulb	08A-405/4
HOLDER, Grocery Bag	IRS-830/2	HOUSING, Cup Holder	IRS-610/16
HOLDER, Grocery Bag	IRS-825/21	HOUSING, Cup Holder	IRS-615/16
HOOD	SRS-510/1	HOUSING, Cup Holder	IRS-815/28
HOOD AND HINGE	SRS/510	HOUSING, Distribution	024-120/12
HOOD RELEASE AND RELATED PARTS	SRS/520	HOUSING, Distribution	024-130/12
HOOK, Coat	IRS-110/12	HOUSING, Distribution	024-140/12
HOOK, Tow	013-110/22	HOUSING, Fuel Filler	SRS-915/28
HORN AND BRACKET, Dual	008-905/1	HOUSING, Oil Fill	003-115/9
HORN	008/905	HOUSING, Steering Column	008-805/3
HOSE 1FT, Windshield Washer, 5/32"	23D-210/22	HOUSING, Steering Column	019-145/11
HOSE 1FT, Windshield Washer, 7/64"	23D-210/23	HOUSING, Steering Column	019-245/21
HOSE AND CLAMP, Radiator Inlet	007-105/3	HOUSING, Steering Column Lock	019-245/19
HOSE AND CLAMP, Radiator Outlet	007-105/4	HOUSING, Steering Column Lock	23D-105/44
HOSE AND CLAMP, Radiator Outlet	007-175/16	HOUSING, Thermostat	007-175/18
HOSE, Air Cleaner to T/Body	008-615/7	HOUSING, Wiper Nosecone	SRS-610/9
HOSE, Air Cleaner to T/Body	014-810/8	HUB AND BEARING, Brake	005-155/7
HOSE, Air Cleaner to T/Body	014-830/7	HUB AND BEARING, Brake	002-145/15
HOSE, Brake	005-561/1	HUB AND BEARING, Brake	005-210/27
HOSE, Brake	005-561/2	HUB AND BEARING, Brake	005-220/10
HOSE, Brake	005-565/1	HUB AND GEAR, Second And Fourth Clutch	41TE-AE-440/65
HOSE, Brake	005-565/6	HUB AND SHAFT PACKAGE, Underdrive Clutch	41TE-AE-425/7
HOSE, Brake	005-565/13	HUB AND SHAFT, Overdrive Clutch	41TE-AE-425/22
HOSE, Brake Booster	005-343/7	HUB PACKAGE, Input Clutch	41TE-AE-425/38
HOSE, Brake Booster Vacuum	005-343/6	HUB PACKAGE, Input Clutch	41TE-AE-425/47
HOSE, Canister to Vent Valve	025-310/5	HYDRAULIC CONTROL UNIT, Anti-Lock Brake System	005-431/1
HOSE, Crankcase Vent	014-830/8		
HOSE, Crankcase Vent	014-810/10		
HOSE, Crankcase Vent	3.8L-910/3		
HOSE, Crankcase Vent	3.3L6T-910/3		
HOSE, Drain	007-175/11		
HOSE, Fuel Filler Tube	014-210/2		

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

<b>-I-</b>	
I.D. LOCATION 2.4L [EDZ] .....	2.4L/110
I.D. LOCATION 3.3L [EGA],[EGM] .....	3.3L6T/110
I.D. LOCATION 3.8L EGH ENGINE, .....	3.8L/110
INDICATOR, Engine Oil Level .....	2.4L-710/6
INDICATOR, Engine Oil Level .....	3.8L-710/8
INDICATOR, Engine Oil Level .....	3.3L6T-710/9
INDICATOR, PRNDL .....	08A-205/4
INDICATOR, Transmission Fluid Level .....	31TH-210/4
INDICATOR, Transmission Fluid Level .....	41TE-AE- 220/5
INDICATOR, Valet Status .....	001-910/6
INDICATOR, Valet Status .....	001-914/3
INJECTOR, Fuel .....	014-440/5
INJECTOR, Fuel .....	014-460/2
INPUT SHAFT PACKAGE, Transaxle .....	41TE-AE- 425/37
INPUT SHAFT, Transaxle .....	31TH-415/2
INSERT, Manual .....	008-1605/13
INSTALL KIT, Vehicle Navigation System .....	001-130/3
INSTALLATION KIT, Multimedia System .....	001-140/17
INSTRUMENTPANELPANEL--SILENCERS--COVERS, .....	08A/105
INSULATOR, Exhaust .....	011-110/7
INTERLINER, Leaf Spring .....	017-155/4
INTERLOCK, steering column .....	019-245/10
ISOLATOR, Air Cleaner Mounting Leg .....	014-810/4
ISOLATOR, Air Cleaner Mounting Leg .....	014-830/3
ISOLATOR, Cradle .....	013-110/12
ISOLATOR, Crossmember .....	007-175/4
ISOLATOR, Cylinder Head Cover, Grommet And Bolt .....	2.4L-210/6
ISOLATOR, Cylinder Head Cover, Grommet And Bolt .....	3.3L6T-210/5
ISOLATOR, Cylinder Head Cover, Grommet And Stud .....	2.4L-210/18
ISOLATOR, Hood Prop Rod .....	SRS-520/1
ISOLATOR, Radiator .....	007-105/1
ISOLATOR, Radiator .....	007-175/6
ISOLATOR, Radiator .....	007-175/7
ISOLATOR, Spring .....	002-145/2
ISOLATOR, Spring .....	002-145/6
ISOLATOR, Spring .....	002-145/7
ISOLATOR, Spring .....	017-145/10
ISOLATOR, Spring .....	017-145/11
ISOLATOR, Throttle Cable .....	005-650/4
<b>-J-</b>	
JACK STOWAGE, .....	022/340
JACK, Scissors .....	022-340/2
JUMPER, Fuel Supply .....	014-310/3
JUMPER, Fuel Supply .....	014-310/9
JUNCTION BLOCK, Brake Tube .....	005-431/5
<b>-K-</b>	
KEY, Blank .....	23D-105/1
KEY, Crankshaft Sprocket .....	2.4L-410/11
KEY, Crankshaft Sprocket .....	2.4L-610/14
KEY, Crankshaft Sprocket .....	2.4L-620/14
KEY, Valet .....	23D-105/2
KNOB .....	IRS-540/4
KNOB .....	008-815/15
KNOB AND ELEMENT, Cigar Lighter .....	08A-105/31
KNOB AND LINK, Door Lock .....	DRS-310/47
KNOB, A/C And Heater Control - Rotary .....	024-310/3
KNOB, A/C And Heater Control - Slide .....	024-310/4
KNOB, Door Lock .....	DRS-180/17
KNOB, Power Seat Switch .....	IRS-540/3
KNOB, Power Seat Switch .....	008-815/16
KNUCKLE, Front .....	005-155/6
KNUCKLE, Front .....	002-145/14
<b>-L-</b>	
LABEL, Air Bag .....	08A-105/52
LABEL, Air Bag Warning .....	008-405/17
LABEL, Airbag, .....	IRS-110/8
LABEL, Authorized Software Update .....	008-705/3
LABEL, Child Protection Lock .....	SRS-710/2
LABEL, Child Protection Lock .....	DRS-310/53
LABEL, Coolant Warning .....	007-330/9
LABEL, Coolant Warning .....	013-260/14
LABEL, Emission .....	025-110/1

LABEL, Engine Identification .....	2.4L-110/1
LABEL, Engine Identification .....	3.8L-110/1
LABEL, Engine Identification .....	3.3L6T-110/1
LABEL, Equipment Identification .....	SRS-510/10
LABEL, Exhaust Gas Warning .....	011-110/8
LABEL, Front Door, INFINITY .....	IRS-410/9
LABEL, Fuel .....	014-210/11
LABEL, General Information .....	SRS-410/15
LABEL, Power Liftgate .....	SRS-1010/7
LABEL, Power Liftgate .....	SRS-1330/7
LABEL, Seat Attach .....	IRS-825/16
LABEL, Tire Pressure .....	022-140/9
LABEL, Unleaded Fuel Only .....	014-210/10
LAMP, Cargo .....	008-1115/8
LAMP, Dome .....	008-1115/5
LAMP, Door .....	008-1115/14
LAMP, Fog .....	008-1105/14
LAMP, Headlamp .....	008-1105/1
LAMP, Ignition .....	008-805/7
LAMP, License Plate .....	008-1110/16
LAMP, Liftgate Chmsl .....	008-1110/7
LAMP, Liftgate Flood Lamp .....	008-1115/11
LAMP, Reading .....	008-1115/1
LAMP, Tail Stop Turn .....	008-1110/1
LAMPS--CARGO-DOME-COURTESY-READING .....	008/1115
LAMPS--FRONT .....	008/1105
LAMPS--REAR .....	008/1110
LATCH KIT, Video Screen .....	08A-315/4
LATCH, Air Cleaner .....	014-810/5
LATCH, Air Cleaner .....	014-830/5
LATCH, Front Door .....	DRS-180/27
LATCH, Glovebox .....	08A-105/35
LATCH, Hood .....	SRS-520/8
LATCH, Liftgate .....	SRS-1320/1
LATCH, Seat .....	IRS-825/20
LATCH, Sliding Door .....	DRS-310/19
LATCH, Sliding Door Hold Open .....	DRS-310/3
LATCH, Storage Bin Lid .....	IRS-235/10
LATCH, Vent Window .....	SRS-710/14
LEAK DETECTION PUMP, .....	025/490
LENS, Cargo Lamp .....	008-1115/9
LENS, Diffuser .....	008-1115/3
LENS, Dome Lamp .....	008-1115/6
LENS, Door Lamp .....	008-1115/15
LENS, Instrument Cluster .....	08A-205/2
LENS, LIFTGATE FLOOD LAMP .....	008-1115/12
LENS, Reading Lamp .....	08A-405/3
LENS, Reading Lamp .....	008-1115/2
LENS, w/Grab Handle .....	IRS-110/15
LENS, w/Grab Handle .....	008-1115/19
LEVEL UNIT KIT, Fuel .....	014-510/4
LEVER .....	004-142/7
LEVER KIT, Rear Wheel Brake Adjust Pivot .....	005-210/13
LEVER, Auto Trans Throttle Control .....	014-740/8
LEVER, Front Door Cylinder .....	23D-105/15
LEVER, Gearshift .....	019-245/4
LEVER, Kickdown .....	31TH-520/6
LEVER, Liftgate Lock Cylinder .....	23D-105/30
LEVER, Manual Control .....	31TH-210/3
LEVER, Manual Control .....	31TH-1225/3
LEVER, Manual Control .....	41TE-AE- 1225/2
LEVER, Manual Control .....	41TE-AE- 220/10
LEVER, Manual Valve .....	41TE-AE- 715/4
LEVER, PARKING BRAKE, .....	004/142
LEVER, Park Brake .....	004-142/1
LEVER, Park Brake .....	005-210/4
LEVER, Park Brake .....	005-220/16
LEVER, Park Brake Adjusting .....	005-210/9
LEVER, Reverse Band .....	31TH-520/7
LEVER, Sliding Door .....	DRS-310/34
LEVER, Sliding DoorLock Cylinder .....	23D-105/21
LEVER, Tilt Column Release .....	019-245/7
LICENSE PLATE KIT .....	013-260/24
LID, Center Console Storage, Front .....	001-810/3
LID, Center Console Storage, Front .....	08A-410/12



**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

MOLDING, Sliding Door	ERS-220/7
MOLDING, Sliding Door	ERS-220/9
MOLDING, Sliding Door	IRS-420/4
MOLDING, Windshield	ERS-210/5
MOLDING, Windshield	ERS-220/11
MOLDING, Windshield Garnish	IRS-215/1
MOLDINGS, CHRYSLER	ERS/220
MOLDINGS, DODGE	ERS/210
MONITOR, Media System	001-140/9
MONITOR, Media System	001-142/8
MONITOR, Media System	08A-315/3
MOTOR AND GEAR, Power Liftgate	SRS-1330/5
MOTOR, A.I.S.	014-640/3
MOTOR, Blower with Wheel	024-120/8
MOTOR, Blower with Wheel	024-130/9
MOTOR, Blower with Wheel	024-140/9
MOTOR, Blower with Wheel	024-150/6
MOTOR, Liftgate	SRS-1330/6
MOTOR, Liftgate Wiper	23D-305/3
MOTOR, Sliding Door	DRS-310/15
MOTOR, Wiper	23D-205/8
MOUNT, Power Outlet	08A-410/7
MOUNT, Power Outlet	IRS-240/2
MOUNT, Power Outlet	08A-105/28
MOUNT, Power Outlet	08A-105/51
MOUNT, Strut	002-145/9
MOUNTING KIT, Console	001-140/4
MOUNTING PACKAGE, Console	001-810/11
MUFFLER AND RESONATOR, Exhaust	011-110/5

**-N-**

NAMEPLATE	ERS-110/21
NAMEPLATE, AWD	ERS-110/9
NAMEPLATE, Caravan	ERS-110/14
NAMEPLATE, Chrysler	ERS-110/10
NAMEPLATE, Deck Lid, Chrysler	ERS-110/20
NAMEPLATE, Dodge	ERS-110/15
NAMEPLATE, EL	ERS-110/5
NAMEPLATE, ES	ERS-110/17
NAMEPLATE, Ec	ERS-110/4
NAMEPLATE, Ex	ERS-110/3
NAMEPLATE, Grand Caravan	ERS-110/18
NAMEPLATE, Grand Voyager	ERS-110/12
NAMEPLATE, LIMITED	ERS-110/8
NAMEPLATE, LX	ERS-110/6
NAMEPLATE, LXI	ERS-110/7
NAMEPLATE, Liftgate, Town and Country	ERS-110/2
NAMEPLATE, SE	ERS-110/16
NAMEPLATE, Sport	ERS-110/19
NAMEPLATE, Voyager	ERS-110/11
NAMEPLATES	ERS/110
NAVIGATION KIT	001/130
NAVIGATION KIT, Vehicle	001-130/1
NET, Cargo	IRS-245/13
NET, Cargo	IRS-535/11
NIPPLE, Crankcase Vent	2.4L-910/4
NIPPLE, Pump	007-225/7
NOZZLE, Radio Cooling	024-120/20
NOZZLE, Radio Cooling	024-130/19
NOZZLE, Radio Cooling	024-140/19
NOZZLE, Washer, Liftgate	23D-210/4
NOZZLE, Washer, Liftgate	008-1110/8
NOZZLE, Washer, Windshield	23D-210/2
NUT	019-321/7
NUT	024-220/8
NUT	002-145/23
NUT	005-210/30
NUT	005-220/21
NUT	007-175/14
NUT	008-625/10
NUT	014-210/12
NUT	019-245/32
NUT	022-140/15
NUT	024-220/11
NUT	DRS-310/11
NUT & WASHER, M8x1.25	019-520/5
NUT AND WASHER, Hex, M6x1	SRS-815/8
NUT AND WASHER, Hex, M6x1	019-245/12
NUT AND WASHER, Hex, M6x1	SRS-915/33

NUT AND WASHER	002-145/11
NUT AND WASHER	DRS-310/42
NUT AND WASHER	DRS-310/49
NUT AND WASHER	IRS-825/12
NUT AND WASHER PACKAGE, Front Hub	002-245/8
NUT AND WASHER PACKAGE, Front Hub	003-420/6
NUT AND WASHER PACKAGE, Front Hub	005-210/24
NUT AND WASHER, Hex Nut-Coned Washer, M10x1.5	007-425/3
NUT AND WASHER, Hex Nut-Coned Washer, M10x1.5	019-510/6
NUT AND WASHER, Hex Nut-Coned Washer, M10x1.5	013-260/21
NUT AND WASHER, Hex Nut-Coned Washer, M10x1.5	024-410/18
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	SRS-815/2
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	014-1110/3
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	23D-205/14
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	SRS-710/13
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	SRS-915/10
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	2.4L-620/15
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	005-343/3
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	005-645/4
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	024-210/1
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	024-210/2
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	008-1005/3
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	008-1005/7
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	013-360/10
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	024-220/12
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	024-220/13
NUT AND WASHER, Hex Nut-Coned Washer, M8x1.25	024-220/14
NUT AND WASHER, Hex Nut-Coned Washer, M6x1.00	3.3L6T-810/29
NUT AND WASHER, Hex, M10x1.5	009-140/22
NUT AND WASHER, Hex, M10x1.5	009-160/22
NUT AND WASHER, Hex, M10x1.5	IRS-535/15
NUT AND WASHER, Hex, M12x1.75	002-145/29
NUT AND WASHER, Hex, M5x.80	013-260/23
NUT AND WASHER, Hex, M6x1.0	024-207/2
NUT AND WASHER, Hex, M6x1.0	08A-105/64
NUT AND WASHER, Hex, M6x1.0	3.8L-810/30
NUT AND WASHER, Hex, M8x1.25	IRS-825/24
NUT AND WASHER, M6x1.00	024-150/20
NUT, .312 Diameter	DRS-180/23
NUT, Band Adjusting Screw Lock	31TH-520/4
NUT, Flange	003-115/14
NUT, Fuel Pump Module	014-510/6
NUT, Hex Flange Lock	008-105/7
NUT, Hex Flange Lock	019-145/2
NUT, Hex Flange Lock	019-321/5
NUT, Hex Flange Lock	002-145/10
NUT, Hex Flange Lock	002-145/12
NUT, Hex Flange Lock	002-145/27
NUT, Hex Flange Lock	013-110/16
NUT, Hex Flange Lock	013-110/20
NUT, Hex Flange Lock, M10x1.5	002-145/34
NUT, Hex Flange Lock, M12x1.75	017-155/26
NUT, Hex Flange Lock, M14x2	017-145/5
NUT, Hex Flange Lock, M14x2	017-155/7
NUT, Hex Flange Lock, M16x1.5	088-120/55
NUT, Hex Flange Lock, M8 Phosphate	004-142/4
NUT, Hex Flange Lock, M8x1.25	2.4L-810/12
NUT, Hex Flange Lock, M8x1.25	2.4L-810/18
NUT, Hex Flange Serration, M6x1	014-1010/2
NUT, Hex Flange Serration, M6x1	014-1010/7
NUT, Hex Flange, M12x1.75	IRS-535/17
NUT, Hex Flange, M12x1.75	IRS-540/10
NUT, Hex Flange, M6x1	SRS-410/2
NUT, Hex Flange, M6x1	ERS-210/11
NUT, Hex Flange, M8x1.25	011-110/2
NUT, Hex Flange, M8x1.25	025-310/9
NUT, Hex Flange, M8x1.25	23D-205/18
NUT, Hex Flange, M8x1.25	IRS-510/14
NUT, Hex Lock, M8x1.25	005-416/2
NUT, Hex Weld, M8x1.25	008-1105/8
NUT, Hex, .375-24	3.8L-410/16
NUT, Hex, .375-24	3.3L6T-410/16
NUT, Hex, M10X1.25	23D-205/4
NUT, Hex, M20x1.5	31TH-425/24
NUT, Hex, M20x1.5	31TH-460/18
NUT, Hex, M6	013-260/13

NUT, Hex, M6x1.00	DRS-180/34
NUT, Hex, M6x1.00	008-1005/11
NUT, Hex, Mx1.5	017-145/23
NUT, Hex, Mx1.5	017-155/13
NUT, Hub, M22x1.5	002-245/7
NUT, Hub, M22x1.5	003-420/5
NUT, Hub, M22x1.5	005-210/23
NUT, J	3.8L-810/3
NUT, J	3.3L6T-810/2
NUT, Lock	019-321/4
NUT, Lock	013-110/18
NUT, M10x1.5	017-145/18
NUT, M10x1.5	017-155/22
NUT, M10x1.5	017-155/31
NUT, M10x1.50	3.8L-810/22
NUT, M10x1.50	3.3L6T-810/18
NUT, M12x1.75	017-145/36
NUT, Manifold Stud Mounting	024-410/6
NUT, Manifold Stud Mounting	024-410/13
NUT, Manifold Stud Mounting	024-410/21
NUT, Plastic Snap-in	23D-205/19
NUT, Plastic Snap-in	SRS-815/10
NUT, Plastic Snap-in	SRS-915/17
NUT, Plastic Snap-in	008-1110/20
NUT, Push On, M6	SRS-610/27
NUT, Push, .164-18	IRS-110/18
NUT, Push, .19	IRS-220/3
NUT, Push, .19	IRS-225/3
NUT, Push, .19	IRS-235/6
NUT, Push, .19	IRS-240/4
NUT, Retainer, M6 x 1.00	019-730/13
NUT, Rivet	IRS-215/2
NUT, Rivet	001-810/16
NUT, Rivet	08A-410/17
NUT, Rivet	SRS-1330/1
NUT, Rivet	008-1110/15
NUT, Round, M6 x 1.00	23D-305/4
NUT, Snap In	08A-105/26
NUT, Snap In, .164-18	IRS-410/2
NUT, Snap In, .164-18	IRS-420/3
NUT, Snap In, .164-18	IRS-420/9
NUT, Snap In, .164-18	DRS-310/12
NUT, Snap In, M4.2 x 1.41	08A-310/5
NUT, Snap In, M4.8x1.6	013-260/6
NUT, Speed Round Flat	IRS-510/15
NUT, Spring	005-155/2
NUT, Spring	IRS-230/2
NUT, Spring	08A-105/59
NUT, Spring Type, .164-7.5	IRS-1010/9
NUT, Steering Gear Lock	019-321/8
NUT, Transmission Lever Bolt, M6x1.00	31TH-210/2
NUT, Transmission Lever Bolt, M6x1.00	41TE-AE-220/8
NUT, U Multi Thread, M6 x 1.00	IRS-245/6
NUT, U Multi Thread, M6 x 1.00	008-1605/16
NUT, U, M6x1	007-330/1
NUT, U, M6x1	IRS-750/3
NUT, U, M6x1	024-150/19
NUT, U-Type, For M4.8x1.59 Screw	008-1110/9
NUT, Well	DRS-190/3
NUT, Well	DRS-310/18
NUT, Wheel	005-155/4
NUT, Wheel Chrome, M12x1.5	005-155/3
NUT, Wheel Chrome, M12x1.5	022-140/6
NUT, Wheel Chrome, M12x1.5	022-240/4
NUT, Wheel Chrome, M12x1.5	005-220/20
NUT, Wheel, M12x1.5	005-155/5
NUT, Wheel, M12x1.5	022-140/2
NUT, Wheel, M12x1.5	022-140/7
NUT, Wheel, M12x1.5	022-240/5
NUT, Wheel, M12x1.5	005-210/25
NUT, Wheel, M12x1.5	005-220/19
NUT, Wiper Arm	23D-305/6
NUT/RIVET, M6x1.00x13.50	SRS-1610/9
NUT/SPRING, "U"1THD, For .164-15 Screw	024-610/15

**-O-**

O RING	003-115/7
O RING KIT, Fuel Injector	014-440/4
O RING KIT, Fuel Injector	014-460/3
O RING, A/C Line	024-210/5
O RING, A/C Line	024-220/3
O RING, A/C Line	024-210/10
O RING, A/C Line	024-210/11
O RING, A/C Line	024-220/19
O RING, A/C Line	024-220/20
O RING, A/C Liquid Line	024-210/9
O RING, A/C Liquid Line	024-230/3
O RING, A/C Suction Line	024-210/4
O RING, A/C Suction Line	024-230/5
O RING, Accumulator, Transmission	41TE-AE-725/6
O RING, Engine Block Heater	008-1205/5
O RING, Engine Block Heater	008-1210/5
O RING, Engine Block Heater	2.4L-320/2
O RING, Engine Block Heater	3.8L-320/2
O RING, Engine Block Heater	2.4L-310/13
O RING, Engine Block Heater	3.3L6T-320/2
O RING, Engine Block Heater	3.3L6T-310/15
O RING, Expansion Valve	024-210/20
O RING, Expansion Valve	024-220/26
O RING, Front Cover Oil Inlet	2.4L-710/20
O RING, Heater Core	024-120/15
O RING, Output Shaft Flange Tube	088-120/5
O RING, PTU Case Rear Cover	088-120/6
O RING, Reverse & O/Drive Clutch Piston, Transmission	41TE-AE-425/46
O RING, Throttle Body	014-640/4
O RING, Throttle Body	014-660/7
O RING, Trans Kickdown Servo	31TH-725/8
O RING, Trans Oil Filter	41TE-AE-715/15
O RING, Trans Speed Sensor	008-620/2
O RING, Trans Speed Sensor	008-620/6
O RING, Trans Speed Sensor	41TE-AE-240/8
O RING, Trans Speed Sensor	41TE-AE-240/22
O RING, Transfer Shaft Bearing Retainer, ATX	31TH-425/4
O RING, Transfer Shaft Bearing Retainer, ATX	41TE-AE-415/44
O RING, Transmission Case	41TE-AE-240/31
O RING, Transmission Clutch	41TE-AE-425/39
O RING, Transmission Clutch	41TE-AE-425/40
O RING, Water Inlet Tube	007-207/4
O RING, Water Inlet Tube	007-225/9
ORGANIZER, CARGO	IRS-245/7
ORGANIZER, CARGO	IRS-310/7
OUTLET, A/C & Heater w/IR Sensor and Harness	024-610/7
OUTLET, Air Conditioning & Heater	024-310/9
OUTLET, Air Conditioning & Heater	024-610/4
OUTLET, Air Conditioning & Heater	024-610/6
OUTLET, Air Conditioning & Heater	024-610/9
OUTLET, Air Conditioning & Heater	024-620/8
OUTLET, Air Conditioning & Heater	024-610/13
OUTLET, Air Conditioning & Heater	08A-105/11
OUTLET, Air Conditioning & Heater	08A-105/47
OUTLET, Air Conditioning & Heater	08A-105/48
OUTPUT SHAFT, Rear Axle	31TH-460/1
OVERHAUL PACKAGE, Transaxle	31TH-215/2
OVERHAUL PACKAGE, Transaxle	41TE-AE-240/2

**-P-**

PAD	DRS-310/59
PAD	3.3L6T-810/25
PAD AND PANEL, Instrument Upper	08A-105/20

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

PAD KIT, Front Disc Brake.....	005-155/11
PAD KIT, Rear Disc Brake.....	005-220/2
PAD, Brake Pedal.....	005-650/5
PAD, Child Seat.....	IRS-610/19
PAD, Child Seat.....	IRS-620/15
PAD, Child Seat.....	IRS-630/13
PAD, Console.....	IRS-635/13
PAD, Console.....	001-810/12
PAD, Console.....	08A-410/16
PAD, Foam Compounding.....	IRS-110/20
PAD, Heater.....	IRS-525/13
PAD, Heater.....	IRS-530/12
PAD, Instrument Panel.....	08A-105/21
PAD, Jack.....	SRS-810/17
PAD, Jacking.....	SRS-810/16
PAD, Parking Brake Lever.....	004-142/6
PAD, Pedal.....	005-645/5
PAD, Quarter Panel.....	SRS-910/24
PAN PACKAGE, Floor.....	SRS-210/1
PAN, Engine Oil.....	2.4L-710/3
PAN, Engine Oil.....	3.8L-710/5
PAN, Engine Oil.....	3.3L6T-710/5
PAN, Transaxle Differential Oil.....	31TH-215/4
PAN, Transaxle Differential Oil.....	41TE-AE- 240/4
PAN, Transmission Oil.....	31TH-215/36
PAN, Transmission Oil.....	41TE-AE- 240/20
PANEL - LIFTGATE.....	IRS/1010
PANEL PACKAGE, Body Side Aperture Front.....	SRS-810/1
PANEL PACKAGE, Body Side Aperture Rear.....	SRS-915/18
PANEL PACKAGE, Body Side Sill.....	013-120/5
PANEL PACKAGE, Body Side Sill.....	SRS-210/3
PANEL PACKAGE, Cowl Side.....	SRS-610/24
PANEL PACKAGE, Fender Side Shield.....	SRS-410/5
PANEL PACKAGE, Roof Rail Sliding Door Track.....	SRS-915/13
PANEL, A Pillar.....	SRS-810/3
PANEL, B Pillar Inner.....	SRS-915/36
PANEL, Cowl.....	SRS-610/12
PANEL, Cowl And Plenum.....	SRS-610/4
PANEL, Cowl Plenum Support.....	SRS-610/30
PANEL, Cowl Top.....	23D-205/6
PANEL, Cowl Top.....	SRS-610/1
PANEL, Dash.....	SRS-610/19
PANEL, Dash.....	SRS-610/20
PANEL, Dash Panel Wheelhouse.....	SRS-610/29
PANEL, Dash Upper.....	SRS-610/28
PANEL, Fender Side Shield.....	SRS-410/18
PANEL, Front Door Outer Repair.....	DRS-180/3
PANEL, Front Door Trim.....	IRS-410/1
PANEL, Front Seat Back.....	IRS-510/9
PANEL, Front Seat Back.....	IRS-515/9
PANEL, Front Seat Back.....	IRS-520/9
PANEL, Front Seat Back.....	IRS-525/11
PANEL, Front Seat Back.....	IRS-530/10
PANEL, Instrument.....	019-245/14
PANEL, Instrument Lower.....	08A-105/27
PANEL, Instrument Panel.....	08A-105/18
PANEL, Liftgate.....	IRS-1010/6
PANEL, Liftgate Opening.....	SRS-1310/8
PANEL, Liftgate Trim Upper.....	IRS-1010/5
PANEL, Quad.....	IRS-820/1
PANEL, Quarter Inner.....	SRS-910/12
PANEL, Quarter Trim.....	IRS-235/1
PANEL, Quarter Trim.....	IRS-240/6
PANEL, Roof Rail Outer.....	SRS-915/8
PANEL, Scuff.....	IRS-215/7
PANEL, Seat Back, Three Passenger.....	IRS-830/1
PANEL, Seat Back, Three Passenger.....	IRS-825/15
PANEL, Seat Back, Two Passenger.....	IRS-815/9
PANEL, Sill.....	SRS-915/23
PANEL, Sliding Door.....	DRS-310/2
PANEL, Sliding Door Trim.....	IRS-420/1
PARKING SPRAG.....	31TH/740
PARKING SPRAG.....	41TE-AE/740
PAWL, Parking Sprag.....	31TH-740/7
PEDAL AND BRACKET, Accelerator.....	014-1110/1
PEDAL AND BRACKET, BRAKE.....	005-645/1

PEDAL AND PAD.....	005-650/3
PEDAL, BRAKE-POWER ADJUSTABLE.....	005/650
PEDAL, BRAKE-STANDARD.....	005/645
PICKUP, Engine Oil.....	3.8L-710/11
PICKUP, Engine Oil.....	3.3L6T-710/ 12
PIN.....	004-142/8
PIN.....	31TH-620/7
PIN KIT, Disc Brake.....	005-155/14
PIN, Brake Shoe Hold Down.....	005-210/6
PIN, Caliper.....	005-220/7
PIN, Caliper.....	005-155/16
PIN, Cotter, M5x36.00.....	002-245/9
PIN, Cotter, M5x36.00.....	003-420/7
PIN, Cotter, M5x36.00.....	005-210/26
PIN, Door Hinge.....	DRS-180/21
PIN, Dowel.....	2.4L-610/7
PIN, Dowel.....	2.4L-510/16
PIN, Dowel.....	3.8L-310/11
PIN, Dowel.....	3.3L6T-310/ 11
PIN, Hair, .250 Dia x.766x.059.....	019-245/30
PIN, Master Cylinder Reservoir.....	005-416/7
PIN, Push.....	019-730/7
PIN, Push.....	025-490/9
PIN, Push.....	IRS-110/2
PIN, Push.....	IRS-310/2
PIN, Push In, M6.3x15 LG.....	SRS-510/8
PIN, Push, .15x.41.....	007-175/15
PIN, Retainer.....	013-110/7
PIN, Retainer.....	SRS-610/32
PIN, Spring, M8.4x30x1.60.....	019-245/25
PINION, Differential.....	31TH-820/4
PINION, Differential.....	41TE-AE- 820/6
PINION, Speedometer Drive, Yellow.....	21P-120/3
PISTON PACKAGE, Disc Brake.....	005-220/3
PISTON PACKAGE, Disc Brake.....	005-155/17
PISTON PIN AND ROD.....	3.8L-410/1
PISTON PIN AND ROD.....	2.4L-410/19
PISTON PIN AND ROD.....	3.3L6T-410/1
PISTON RING SET, COMPLETE ENGINE, STD.....	2.4L-410/18
PISTON RING SET, COMPLETE ENGINE, STD.....	3.3L6T-410/2
PISTON, 2nd and 4th Accumulator.....	41TE-AE- 725/4
PISTON, 2nd and 4th Accumulator.....	41TE-AE- 715/10
PISTON, Accumulator.....	31TH-725/13
PISTON, Clutch.....	31TH-435/4
PISTON, Clutch.....	31TH-415/11
PISTON, Kickdown Servo.....	31TH-725/6
PISTON, Low and Reverse Clutch.....	41TE-AE- 440/6
PISTON, Reverse Servo.....	31TH-725/24
PISTON, Underdrive.....	41TE-AE- 425/30
PIVOT, Wiper.....	23D-205/11
PLATE.....	31TH-715/14
PLATE AND WASHER PACKAGE, Thrust.....	41TE-AE- 425/8
PLATE AND WASHER PACKAGE, Thrust.....	41TE-AE- 425/21
PLATE PACKAGE, Accumulator.....	31TH-725/15
PLATE PACKAGE, Low/Reverse Clutch, 5.753/6.012.....	41TE-AE- 440/47
PLATE PACKAGE, Low/Reverse Clutch, 6.013/6.272.....	41TE-AE- 440/48
PLATE PACKAGE, Low/Reverse Clutch, 6.273/6.532.....	41TE-AE- 440/49
PLATE PACKAGE, Low/Reverse Clutch, 6.533/6.792.....	41TE-AE- 440/50
PLATE PACKAGE, Low/Reverse Clutch, 6.793/7.052.....	41TE-AE- 440/51
PLATE PACKAGE, Underdrive Reaction, 5.72/5.82.....	41TE-AE- 425/2



PLATE PACKAGE, Underdrive Reaction, 6.21/6.31	41TE-AE-425/3	PLUG	SRS-310/12
PLATE PACKAGE, Underdrive Reaction, 6.70/6.80	41TE-AE-425/4	PLUG	SRS-310/15
PLATE, Air Bag Module	SRS-610/18	PLUG	3.3L6T-310/18
PLATE, Camshaft Thrust	3.8L-610/8	PLUG PACKAGE, Fill	088-120/47
PLATE, Camshaft Thrust	3.3L6T-610/8	PLUG, A/C Plumbing Access	SRS-310/1
PLATE, Clamp	024-210/21	PLUG, Anti-Rattle	SRS-310/20
PLATE, Clamp	024-220/27	PLUG, Armrest	IRS-410/5
PLATE, Drive Plate	2.4L-410/15	PLUG, Armrest	IRS-610/7
PLATE, Drive Plate	3.8L-410/20	PLUG, Armrest	IRS-615/7
PLATE, Drive Plate	3.3L6T-410/21	PLUG, Armrest	IRS-620/8
PLATE, Drive Plate Backing	2.4L-410/17	PLUG, Armrest	IRS-625/8
PLATE, Drive Plate Backing	3.8L-410/18	PLUG, Armrest	IRS-630/6
PLATE, Drive Plate Backing	3.3L6T-410/19	PLUG, Armrest	IRS-635/6
PLATE, Evaporator	024-150/14	PLUG, Armrest	IRS-820/4
PLATE, Extension	024-150/13	PLUG, Armrest	IRS-535/26
PLATE, Extension	024-230/6	PLUG, Armrest	IRS-815/13
PLATE, Jack Locator	SRS-810/7	PLUG, Armrest	IRS-220/6
PLATE, Jack Locator	SRS-915/22	PLUG, B Pillar	IRS-410/6
PLATE, Retaining	024-150/3	PLUG, Bezel Trim	IRS-420/7
PLATE, Scuff	IRS-215/8	PLUG, Bezel Trim	SRS-910/6
PLATE, Scuff	IRS-245/10	PLUG, Body Side Aperture	SRS-310/13
PLATE, Seat Belt	SRS-910/19	PLUG, Body, .75 Diameter	005-210/20
PLATE, Spring Shackle	017-145/9	PLUG, Brake Adjusting Hole	005-220/17
PLATE, Spring Shackle	017-145/22	PLUG, Brake Adjusting Hole	2.4L-510/8
PLATE, Spring Shackle	017-145/32	PLUG, Camshaft	2.4L-210/16
PLATE, Spring Shackle	017-155/11	PLUG, Camshaft	3.8L-510/22
PLATE, Spring Shackle	017-155/12	PLUG, Camshaft	3.3L6T-510/20
PLATE, Steering Column Cover	08A-105/24	PLUG, Core, 1.25 Diameter	2.4L-210/11
PLATE, Striker	SRS-1320/16	PLUG, Core, 1.25 Diameter	2.4L-310/11
PLATE, Transmission Module	31TH-445/10	PLUG, Core, 1.25 Diameter	3.8L-210/12
PLATE, Transmission Clutch Reaction	31TH-435/6	PLUG, Core, 1.25 Diameter	3.3L6T-210/11
PLATE, Transmission Clutch Reaction	31TH-435/8	PLUG, Core, 1.39 Diameter	2.4L-310/12
PLATE, Transmission Clutch Reaction	31TH-415/16	PLUG, Core, 1.50 Diameter	2.4L-310/17
PLATE, Transmission Clutch Reaction	31TH-415/17	PLUG, Core, 1.625 Diameter	3.8L-310/4
PLATE, Transmission Clutch Reaction	31TH-415/19	PLUG, Core, 1.625 Diameter	3.3L6T-310/4
PLATE, Transmission Clutch Reaction	41TE-AE-425/16	PLUG, Cowl Side	SRS-310/14
PLATE, Transmission Clutch Reaction	41TE-AE-440/45	PLUG, Cowl Side	SRS-710/18
PLATE, Transmission Clutch Reaction	41TE-AE-440/66	PLUG, Cylinder Block Oil Hole	3.8L-310/9
PLATE, Transmission O/Drive Clutch	41TE-AE-425/11	PLUG, Cylinder Block Oil Hole	2.4L-210/17
PLATE, Transmission O/Drive Clutch	41TE-AE-425/12	PLUG, Cylinder Block Oil Hole	2.4L-310/16
PLATE, Transmission O/Drive Clutch	41TE-AE-425/15	PLUG, Cylinder Block Oil Hole	3.3L6T-310/9
PLATE, Transmission O/Drive Clutch	41TE-AE-425/23	PLUG, Cylinder Block Oil Hole	3.3L6T-310/17
PLATE, Transmission O/Drive Clutch	41TE-AE-425/26	PLUG, Door	DRS-310/57
PLATE, Transmission Valve Body	31TH-715/10	PLUG, Dummy	008-405/13
PLATE, Window Regulator	SRS-710/19	PLUG, Floor Pan	SRS-310/5
PLAYER KIT - CD CHANGER - 4 DISC	001/110	PLUG, Front Side Rail	SRS-310/4
PLAYER PACKAGE, CD Changer - 4 Disc	001-110/1	PLUG, Hex Socket, 3/8-18NPTx.475	3.3L6T-310/19
PLAYER, DVD - Single Play	001-142/3	PLUG, Liftgate	SRS-1310/13
PLAYER, DVD - Single Play	08A-315/1	PLUG, Oil Drain	2.4L-710/2
PLAYER, Video Cassette	08A-315/2	PLUG, Oil Drain	3.8L-710/4
PLAYER, Video Cassette	001-140/10	PLUG, Oil Drain	3.3L6T-710/4
PLENUM, Intake Manifold	3.8L-810/1	PLUG, Pipe	2.4L-310/5
PLENUM, Intake Manifold	3.3L6T-810/1	PLUG, Pressure Check	31TH-210/13
PLENUM, Manifold	2.4L-810/13	PLUG, Pressure Check	31TH-215/48
PLINTH, Winged Medallion	ERS-110/1	PLUG, Pressure Check	41TE-AE-240/18
PLUG	022-410/5	PLUG, Quarter Trim Panel	IRS-235/11
PLUG	SRS-310/2	PLUG, Quarter Trim Panel	IRS-240/11
PLUG	SRS-310/3	PLUG, Reverse Servo	31TH-725/22
PLUG	SRS-310/6	PLUG, Seat Belt Opening	IRS-220/12
PLUG	SRS-310/7	PLUG, Shock Tower Hole	SRS-410/8
PLUG	SRS-310/8	PLUG, Shock Tower Hole	SRS-310/16
PLUG	SRS-310/9	PLUG, Shock Tower Hole	SRS-310/17
PLUG	31TH-520/8	PLUG, Shock Tower Hole	SRS-310/18
PLUG	SRS-310/10	PLUG, Sill, Button	IRS-245/12
PLUG	SRS-310/11	PLUG, Sliding Door/Liftgate	IRS-420/14
		PLUG, Splash Shield	007-404/6
		PLUG, Trim Panel	IRS-1010/10
		PLUG, Underbody Access	SRS-310/19
		PLUG, Water Pump Reservoir	007-225/5
		PLUGS	SRS/310
		PLUMBING, AIR CONDITIONING AND HEATER, REAR	024/230
		PLUMBING, AIR CONDITIONING, 3.3L, 3.8L	024/220

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

PLUMBING, AIR CONDITIONING,2.4L, . . . . .	024/210
PLUMBING, HEATER, . . . . .	024/205
PLUMBING, HEATER, WITH AUX. HEATER, . . . . .	024/207
PLUNGER, Oil Pressure Relief Valve . . . . .	2.4L-710/17
PLUNGER, Oil Pressure Relief Valve . . . . .	3.8L-710/18
PLUNGER, Oil Pressure Relief Valve . . . . .	3.3L6T-710/20
POWER DISTRIBUTION CENTER . . . . .	008-505/1
POWER DISTRIBUTION CENTER . . . . .	008-1305/2
POWER DISTRIBUTION CENTER,RELAYS & FUSES, . . . . .	008/505
POWER OUTLET . . . . .	08A-105/29
POWER OUTLET . . . . .	08A-105/50
POWER OUTLET, Cigar Lighter . . . . .	001-810/8
POWER OUTLET, Cigar Lighter . . . . .	08A-410/6
POWER OUTLET, Cigar Lighter . . . . .	IRS-240/1
POWER OUTLET, Cigar Lighter . . . . .	08A-410/11
POWER STEERING PUMP 2.4L ENGINE, . . . . .	019/510
POWER STEERING PUMP 3.3L / 3.8L ENGINE, . . . . .	019/520
POWER TRANSFER UNIT . . . . .	088-110/1
POWER TRANSFER UNIT ASSEMBLY . . . . .	088/110
POWER TRANSFER UNIT SERVICE PARTS . . . . .	088/120
PROP, Liftgate . . . . .	SRS-1320/10
PROPELLER, SHAFT . . . . .	016/120
PROTECTOR, Heel . . . . .	IRS-310/5
PULLEY HUB KIT, A/C Compressor . . . . .	024-410/5
PULLEY HUB KIT, A/C Compressor . . . . .	024-410/11
PULLEY, Alternator . . . . .	008-215/7
PULLEY, Idler . . . . .	007-425/4
PULLEY, Idler . . . . .	008-205/7
PULLEY, Idler . . . . .	008-215/2
PULLEY, Idler . . . . .	2.4L-610/11
PULLEY, Power Steering Pump . . . . .	019-510/2
PULLEY, Power Steering Pump . . . . .	019-520/2
PULLEY, Power Steering Pump . . . . .	007-404/11
PULLEY, Water Pump . . . . .	007-225/4
PULLEY, Water Pump . . . . .	007-425/9
PULLEYS AND RELATED PARTS, . . . . .	007/425
PULLEYS AND RELATED PARTS,2.4L Engine . . . . .	007/404
PUMP, Engine Oil . . . . .	2.4L-710/1
PUMP, Leak Detection. . . . .	025-490/2
PUMP, OIL WITH REACTION SHAFT, . . . . .	31TH/320
PUMP, OIL WITH REACTION SHAFT, . . . . .	41TE-AE/320
PUMP, Power Steering . . . . .	019-510/1
PUMP, Power Steering . . . . .	019-520/1
PUMP, Power Steering . . . . .	019-720/9
PUMP, Transmission Oil . . . . .	31TH-320/1
PUMP, Transmission Oil . . . . .	41TE-AE-320/2
PUMP, Washer, Liftgate . . . . .	23D-210/14
PUMP, Washer, Windshield . . . . .	23D-210/13
PUMP, Water . . . . .	007-207/1
PUMP, Water . . . . .	007-225/3
PUSH NUT . . . . .	008-1505/5
PUSH NUT, M8 . . . . .	008-1005/14
PUSH ROD, Valve . . . . .	3.8L-510/20
PUSH ROD, Valve . . . . .	3.3L6T-510/18

**-Q-**

QUAD SEATS - ATTACHING PARTS (ADJUSTERS, COVERS AND SHIELDS), . . . . .	IRS/820
QUAD SEATS, TRIM CODE [A7] . . . . .	IRS/630
QUAD SEATS, TRIM CODE [CL ML] . . . . .	IRS/625
QUAD SEATS, TRIM CODE [DL], . . . . .	IRS/620
QUAD SEATS, TRIM CODE [E7, H5, L5] . . . . .	IRS/635
QUARTER PANEL - LEFT, . . . . .	IRS/240
QUARTER PANEL - RIGHT, . . . . .	IRS/235
QUARTER PANEL WITH SLIDING DOOR INNER PANEL PARTS, . . . . .	SRS/910
QUARTER PANEL WITH SLIDING DOOR OUTER PANEL PARTS . . . . .	SRS/915

**-R-**

RACK KIT - MULTIPURPOSE . . . . .	001/292
RACK KIT, Multipurpose . . . . .	001-292/1
RADIATOR AND RELATED PARTS,2.4L Engine . . . . .	007/105
RADIATOR AND RELATED PARTS,3.3L - 3.8L Engine . . . . .	007/175
RADIATOR, Engine Cooling . . . . .	007-105/2

RADIATOR, Engine Cooling . . . . .	007-175/1
RADIO . . . . .	08A-105/14
RADIO, AM/FM Cassette . . . . .	08A-305/1
RADIO, AM/FM with CD and Cassette . . . . .	08A-305/2
RADIO, AM/FM with CD and Equalizer . . . . .	08A-305/4
RADIO, AM/FM/Cassette With CD . . . . .	08A-305/6
RADIO, AM/FM/Cassette With CD . . . . .	08A-305/7
RADIO, AM/FM/Cassette With CD Control . . . . .	08A-305/3
RADIOS, . . . . .	08A/305
RAIL PACKAGE, Front . . . . .	013-110/2
RAIL PACKAGE, Front . . . . .	013-110/3
RAIL, Fuel . . . . .	014-440/1
RAIL, Fuel . . . . .	014-460/1
RAIL, LUGG RACK CROSS . . . . .	SRS-1610/6
RAIL, Luggage Rack Side . . . . .	SRS-1610/2
RAIL, Rear Floor Pan Side. . . . .	013-120/10
RAIL, Roof Side . . . . .	SRS-915/24
REARDIFFERENTIALMOUNTING-ALLWHEELDRIVE, . . . . .	003/135
REAR ENTERTAINMENT CENTER . . . . .	08A/315
REAR SEAT - 2 PASSENGER ADJUSTERS - COVERS/SHIELDS AND ATTACHING PARTS, . . . . .	IRS/815
REAR SEAT - 3 PASSENGER ATTACHING PARTS, STRAIGHT BENCH, STRAIGHT BENCH WITH CENTER ARMREST . . . . .	IRS/825
REAR SEAT, 2- PASSENGER TRIM CODE [K5], . . . . .	IRS/615
REARSEAT,2-PASSENGERTRIMCODE[E7,J7,L5,H5] . . . . .	IRS/610
REAR SEAT, 3 PASSENGER, 50/50 SEAT, ATTACHING PARTS . . . . .	IRS/830
REAR WIPER, . . . . .	23D/305
RECEPTACLE, Organizer . . . . .	IRS-245/3
RECEPTACLE, Organizer . . . . .	IRS-245/4
RECEPTACLE, Organizer . . . . .	IRS-310/6
RECEPTACLE, Organizer . . . . .	IRS-230/10
RECLINER, Seat Back . . . . .	IRS-535/4
RECLINER, Seat Back . . . . .	IRS-815/7
RECLINER, Seat Back . . . . .	IRS-820/9
RECLINER, Seat Back . . . . .	IRS-825/6
RECLINER, Seat Back . . . . .	IRS-830/9
RECLINER, Seat Back . . . . .	IRS-540/13
RECLINER, Seat Back . . . . .	IRS-820/18
RECLINER, Seat Back . . . . .	IRS-830/10
REFLECTOR, Door Trim Panel . . . . .	IRS-410/8
REFLECTOR, Door Trim Panel . . . . .	008-1115/17
REGULATOR KIT, Fuel Pressure. . . . .	014-510/2
REGULATOR, Front Door Window . . . . .	DRS-190/2
REINFORCEMENT . . . . .	SRS-810/18
REINFORCEMENT AND NUT, Liftgate Striker . . . . .	SRS-1310/6
REINFORCEMENT PACKAGE, Body Side Aperture . . . . .	SRS-910/9
REINFORCEMENT PACKAGE, Headlamp . . . . .	013-110/4
REINFORCEMENT PACKAGE, Headlamp . . . . .	013-110/5
REINFORCEMENT PACKAGE, Sliding Door . . . . .	SRS-915/35
REINFORCEMENT, Body Side Aperture. . . . .	SRS-910/8
REINFORCEMENT, Cowl Plenum. . . . .	SRS-610/6
REINFORCEMENT, Dash Panel Accelerator . . . . .	SRS-610/17
REINFORCEMENT, Dash Panel Belt . . . . .	SRS-610/15
REINFORCEMENT, Door Striker . . . . .	SRS-810/10
REINFORCEMENT, Door Striker . . . . .	SRS-810/11
REINFORCEMENT, Floor Pan Rail to Sill . . . . .	013-120/3
REINFORCEMENT, Floor Pan Side Rail . . . . .	013-120/16
REINFORCEMENT, Front Bumper . . . . .	013-260/9
REINFORCEMENT, Front Crossmember . . . . .	013-110/14
REINFORCEMENT, Front Side Rail to Dash. . . . .	SRS-610/35
REINFORCEMENT, Front Side Rail to Sill. . . . .	013-110/1
REINFORCEMENT, Front Side Rail to Sill. . . . .	SRS-410/3
REINFORCEMENT, Instrument Panel . . . . .	SRS-610/23
REINFORCEMENT, Jacking . . . . .	SRS-810/5
REINFORCEMENT, Jacking . . . . .	SRS-910/15
REINFORCEMENT, Jacking . . . . .	SRS-915/37
REINFORCEMENT, Liftgate Opening . . . . .	SRS-1110/5
REINFORCEMENT, Liftgate Opening . . . . .	SRS-1310/9
REINFORCEMENT, Liftgate Opening . . . . .	SRS-1310/10
REINFORCEMENT, Liftgate Opening . . . . .	SRS-1310/14
REINFORCEMENT, Quarter Panel . . . . .	SRS-910/1
REINFORCEMENT, Quarter Panel . . . . .	SRS-910/2
REINFORCEMENT, Quarter Panel . . . . .	SRS-910/13
REINFORCEMENT, Rear Bumper. . . . .	013-360/6
REINFORCEMENT, Rear Seat . . . . .	013-120/18
REINFORCEMENT, Seat Belt Swivel . . . . .	013-120/1

REINFORCEMENT, Seat Belt Swivel . . . . .	SRS-210/4
REINFORCEMENT, Seat Cushion Frame . . . . .	IRS-525/2
REINFORCEMENT, Seat Cushion Frame . . . . .	IRS-510/11
REINFORCEMENT, Seat Cushion Frame . . . . .	IRS-515/11
REINFORCEMENT, Seat Striker . . . . .	013-120/17
REINFORCEMENT, Shoulder Belt . . . . .	SRS-910/3
REINFORCEMENT, Sill . . . . .	013-120/2
REINFORCEMENT, Sill . . . . .	013-120/9
RELAY PACKAGE, Electrical . . . . .	008-505/8
RELAY PACKAGE, Electrical . . . . .	008-505/9
RELAY, Electrical . . . . .	008-505/18
RELAY, Radiator Fan . . . . .	008-505/16
RELEASE, Hood Latch . . . . .	SRS-520/5
REMOTE, Wireless Infrared . . . . .	001-142/6
REMOTE, Wireless Infrared . . . . .	001-140/12
REMOTE, Wireless Infrared . . . . .	08A-310/29
REMOTE, Wireless Infrared . . . . .	08A-315/12
RESERVOIR, Brake Master Cylinder . . . . .	005-416/3
RESERVOIR, Power Steering Pump . . . . .	019-720/10
RESERVOIR, Power Steering Pump . . . . .	019-730/11
RESERVOIR, Washer . . . . .	23D-210/7
RESISTOR, Blower Motor . . . . .	024-120/9
RESISTOR, Blower Motor . . . . .	024-130/8
RESISTOR, Blower Motor . . . . .	024-150/7
RESTRICTOR, Heater Return Hose . . . . .	024-205/15
RETAINER . . . . .	08A-405/11
RETAINER . . . . .	IRS-110/13
RETAINER . . . . .	31TH-725/20
RETAINER AND SEAL, Transmission U/Drive Spring . . . . .	41TE-AE-425/28
RETAINER PACKAGE, 2nd & 4th Clutch Piston . . . . .	41TE-AE-440/59
RETAINER PACKAGE, 2nd & 4th Clutch Piston . . . . .	41TE-AE-440/61
RETAINER, Air Outlet . . . . .	024-620/10
RETAINER, Battery Hold Down . . . . .	008-1005/6
RETAINER, Bearing . . . . .	31TH-425/5
RETAINER, Condenser Seal . . . . .	007-105/15
RETAINER, Crankshaft Rear Oil Seal . . . . .	3.8L-310/5
RETAINER, Crankshaft Rear Oil Seal . . . . .	3.8L-410/22
RETAINER, Crankshaft Rear Oil Seal . . . . .	3.3L6T-310/5
RETAINER, Crankshaft Rear Oil Seal . . . . .	3.3L6T-410/23
RETAINER, Differential . . . . .	31TH-435/10
RETAINER, Differential Bearing . . . . .	31TH-215/29
RETAINER, Differential Bearing . . . . .	41TE-AE-240/13
RETAINER, Differential Bearing . . . . .	41TE-AE-820/21
RETAINER, Fascia . . . . .	013-260/4
RETAINER, Fascia . . . . .	013-360/5
RETAINER, Foam To Reinforcement . . . . .	013-260/8
RETAINER, Fog Lamp Bulb . . . . .	008-1105/19
RETAINER, Front Suspension . . . . .	002-145/36
RETAINER, Headlamp Bulb . . . . .	008-1105/4
RETAINER, M6.3x19.65 . . . . .	DRS-610/12
RETAINER, Molding . . . . .	IRS-210/3
RETAINER, Overhead Console . . . . .	024-310/7
RETAINER, Parking Brake Cable . . . . .	004-142/5
RETAINER, Phone Holder . . . . .	001-810/9
RETAINER, Phone Holder . . . . .	08A-410/24
RETAINER, Push On . . . . .	IRS-110/5
RETAINER, Push On . . . . .	SRS-420/4
RETAINER, Push On . . . . .	013-360/11
RETAINER, Push On . . . . .	SRS-410/12
RETAINER, Push On . . . . .	SRS-910/20
RETAINER, Push On . . . . .	SRS-910/23
RETAINER, Spring to Fuel Filler . . . . .	014-210/7
RETAINER, Sunvisor . . . . .	IRS-110/9
RETAINER, Sunvisor . . . . .	IRS-110/19
RETAINER, Tappet Yoke Aligning . . . . .	3.8L-510/21
RETAINER, Tappet Yoke Aligning . . . . .	3.3L6T-510/19
RETAINER, Throttle Cable . . . . .	014-740/5
RETAINER, Throttle Cable . . . . .	014-760/4
RETAINER, Throttle Cable . . . . .	014-760/6
RETAINER, Throttle Cable . . . . .	014-1110/6

RETAINER, Transfer Gear Bearing . . . . .	41TE-AE-415/1
RETAINER,Transmission2ndand4thAccumulatorPiston . . . . .	41TE-AE-715/18
RETAINER, Transmission Extension Oil . . . . .	31TH-215/43
RETAINER, Transmission Extension Oil . . . . .	41TE-AE-240/12
RETAINER, Transmission Extension Oil . . . . .	41TE-AE-240/32
RETAINER, Transmission Front Clutch . . . . .	31TH-435/1
RETAINER, Transmission Governor Support . . . . .	31TH-425/7
RETAINER, Transmission Input Clutch . . . . .	41TE-AE-425/34
RETAINER,TransmissionLowandReverseClutchPiston . . . . .	41TE-AE-440/8
RETAINER, Transmission Rear Clutch . . . . .	31TH-415/5
RETAINER, Valve Rocker Shaft . . . . .	3.8L-510/6
RETAINER, Valve Rocker Shaft . . . . .	3.3L6T-510/6
RETAINER, Valve Spring . . . . .	3.8L-510/8
RETAINER, Valve Spring . . . . .	2.4L-510/10
RETAINER, Valve Spring . . . . .	3.3L6T-510/8
RETAINER, Visor . . . . .	IRS-110/10
REVERSE SERVO PACKAGE . . . . .	31TH-725/18
RING PACKAGE, Piston . . . . .	3.8L-410/2
RING, Retaining . . . . .	003-115/3
RISER, Dump . . . . .	IRS-820/25
RISER, Dump . . . . .	IRS-825/10
RISER, Dump . . . . .	IRS-830/16
RISER, Seat . . . . .	IRS-535/16
RISER, Seat . . . . .	IRS-815/23
RISER, Seat . . . . .	IRS-820/28
RIVET . . . . .	IRS-245/9
RIVET . . . . .	007-105/19
RIVET . . . . .	007-175/24
RIVET . . . . .	ERS-220/12
RIVET, .197 Grip-.187-.375 . . . . .	013-260/18
RIVET, .197 Grip-.187-.375 . . . . .	019-245/33
RIVET, .197 Grip-.187-.375 . . . . .	08A-105/60
RIVET, .25x.110/.189 . . . . .	011-110/9
RIVET, Blind, .125 . . . . .	08A-105/61
RIVET, Blind, .156x.540 . . . . .	SRS-610/31
RIVET, Blind, .250 x .660 . . . . .	008-505/17
ROCKER ARM, Exhaust . . . . .	3.8L-510/1
ROCKER ARM, Exhaust . . . . .	3.3L6T-510/1
ROCKER ARM, Intake . . . . .	3.8L-510/2
ROCKER ARM, Intake . . . . .	3.3L6T-510/2
ROCKER ARM, Valve Roller . . . . .	2.4L-510/14
ROD KIT, Fan Shroud Stabilizer . . . . .	007-105/17
ROD, Hood Prop . . . . .	SRS-520/2
ROD, Kickdown Servo Piston . . . . .	31TH-725/5
ROD, Liftgate Handle to Latch . . . . .	23D-105/32
ROD, Liftgate Handle to Latch . . . . .	SRS-1320/3
ROD, Parking Sprag . . . . .	31TH-740/2
ROD, Parking Sprag . . . . .	41TE-AE-740/6
ROLLER AND SPRING PACKAGE, Overrunning Clutch . . . . .	31TH-460/9
ROLLER, Front and Rear Pinion . . . . .	41TE-AE-440/72
ROOF . . . . .	SRS-1110/1
ROOF PANEL . . . . .	SRS/1110
ROTOR SET, Oil Pump . . . . .	2.4L-710/18
ROTOR SET, Oil Pump . . . . .	3.8L-710/15
ROTOR SET, Oil Pump . . . . .	3.3L6T-710/16
ROTOR, Brake . . . . .	005-155/1
ROTOR, Brake . . . . .	005-220/1
RUB STRIP, Lugg Rack Cross . . . . .	SRS-1610/10
RUN, Front Door Glass . . . . .	DRS-610/10
RUNNING BOARD KIT, Full . . . . .	001-430/1
RUNNING BOARD, Left Side . . . . .	001-430/3
RUNNING BOARD, Right Side . . . . .	001-430/4
RUNNING BOARDS . . . . .	001/430

**-S-**

SCREEN, Transmission Regulator Valve . . . . .	31TH-715/13
SCREEN, Transmission Regulator Valve . . . . .	41TE-AE-715/16

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

SCREW.....	008-205/3
SCREW.....	008-705/2
SCREW.....	013-260/5
SCREW.....	013-360/2
SCREW.....	013-360/4
SCREW.....	014-210/9
SCREW.....	014-760/5
SCREW.....	019-145/6
SCREW.....	025-260/6
SCREW.....	DRS-190/4
SCREW.....	IRS-110/3
SCREW.....	IRS-215/9
SCREW.....	IRS-245/2
SCREW.....	IRS-410/4
SCREW.....	IRS-420/8
SCREW.....	IRS-810/2
SCREW.....	IRS-820/2
SCREW.....	SRS-710/8
SCREW.....	007-175/13
SCREW.....	008-1905/9
SCREW.....	008-405/16
SCREW.....	008-615/14
SCREW.....	019-730/14
SCREW.....	024-120/22
SCREW.....	024-220/28
SCREW.....	08A-105/65
SCREW.....	08A-410/23
SCREW.....	2.4L-610/3
SCREW.....	3.8L-810/7
SCREW.....	3.8L-810/9
SCREW.....	DRS-180/28
SCREW.....	DRS-180/30
SCREW.....	DRS-310/13
SCREW.....	DRS-310/24
SCREW.....	ERS-210/12
SCREW.....	ERS-220/10
SCREW.....	IRS-820/15
SCREW.....	SRS-1330/3
SCREW.....	SRS-815/12
SCREW.....	SRS-815/14
SCREW.....	008-1905/10
SCREW.....	3.8L-810/32
SCREW.....	3.3L6T-810/8
SCREW.....	3.3L6T-810/10
SCREW.....	3.3L6T-810/30
SCREW.....	41TE-AE-715/5
SCREW AND WASHER, Hex Head, .312-18x1.00	005-210/29
SCREW AND WASHER, Hex Head, .312-18x1.00	005-220/12
SCREW AND WASHER.....	007-330/2
SCREW AND WASHER.....	007-330/3
SCREW AND WASHER.....	DRS-510/8
SCREW AND WASHER.....	007-175/22
SCREW AND WASHER.....	013-260/22
SCREW AND WASHER.....	024-150/18
SCREW AND WASHER.....	DRS-310/32
SCREW AND WASHER.....	SRS-710/15
SCREW AND WASHER.....	SRS-810/14
SCREWANDWASHER,HeadHeadLock,M8-1.25x30.00	005-343/8
SCREWANDWASHER,HeadHeadLock,M8-1.25x30.00	005-431/4
SCREW AND WASHER, Hex.....	007-404/4
SCREW AND WASHER, Hex.....	007-404/12
SCREW AND WASHER, Hex Head.....	SRS-520/9
SCREW AND WASHER, Hex Head.....	DRS-180/20
SCREWANDWASHER,HexFlangeHeadLock,M8x1.25x25.00	31TH-215/30
SCREWANDWASHER,HexFlangeHeadLock,M8x1.25x25.00	41TE-AE-240/16
SCREWANDWASHER,HexFlangeHead,.25-14x.875	014-840/2
SCREWANDWASHER,HexFlangeHead,.25-14x.875	23D-210/18
SCREWANDWASHER,HexFlangeHead,M8x1.25x25	31TH-320/6
SCREWANDWASHER,HexFlangeHead,M8x1.25x25	41TE-AE-320/7
SCREWANDWASHER,HexFlangeHead,M8x1.25x25	41TE-AE-240/15
SCREWANDWASHER,HexFlangeHead,M8x1.25x70	3.8L-810/17

SCREWANDWASHER,HexFlangeHead,M8x1.25x70	3.3L6T-810/28
SCREW AND WASHER, Hex Head.....	019-321/3
SCREW AND WASHER, Hex Head.....	025-240/3
SCREW AND WASHER, Hex Head.....	005-220/23
SCREW AND WASHER, Hex Head.....	009-140/13
SCREW AND WASHER, Hex Head.....	009-140/15
SCREW AND WASHER, Hex Head.....	009-140/17
SCREW AND WASHER, Hex Head.....	009-140/27
SCREW AND WASHER, Hex Head.....	009-160/13
SCREW AND WASHER, Hex Head.....	009-160/15
SCREW AND WASHER, Hex Head.....	009-160/17
SCREW AND WASHER, Hex Head.....	013-260/17
SCREW AND WASHER, Hex Head.....	024-610/12
SCREW AND WASHER, Hex Head.....	SRS-1320/6
SCREWANDWASHER,HexHeadSpecialPointM8x1.25x17	007-425/8
SCREWANDWASHER,HexHeadSpecialPointM8x1.25x17	008-1905/11
SCREW AND WASHER, Hex Head Tapping, .25-14x1	014-830/9
SCREW AND WASHER, Hex Head Tapping, .25-14x1	014-810/11
SCREW AND WASHER, Hex Head Tapping, M4.8 x 1.59 x 16.00.....	008-1605/18
SCREW AND WASHER, Hex Head, .19-16x1.00.....	014-660/8
SCREW AND WASHER, Hex Head, .50-13x1.50.....	017-145/28
SCREW AND WASHER, Hex Head, .50-13x3.00.....	017-155/23
SCREW AND WASHER, Hex Head, M10-1.50x30	013-110/19
SCREW AND WASHER, Hex Head, M10x1.50x35	005-569/6
SCREW AND WASHER, Hex Head, M10x1.50x35	014-110/4
SCREW AND WASHER, Hex Head, M10x1.50x35	016-120/3
SCREW AND WASHER, Hex Head, M10x1.50x35	017-145/4
SCREW AND WASHER, Hex Head, M10x1.50x35	017-155/8
SCREW AND WASHER, Hex Head, M10x1.50x35	017-145/26
SCREW AND WASHER, Hex Head, M10x1.50x35	017-145/30
SCREW AND WASHER, Hex Head, M10x1.50x35	017-145/37
SCREW AND WASHER, Hex Head, M10x1.50x35	017-145/40
SCREW AND WASHER, Hex Head, M10x1.50x35	017-155/10
SCREW AND WASHER, Hex Head, M10x1.50x35	017-155/14
SCREW AND WASHER, Hex Head, M10x1.50x35	017-155/33
SCREW AND WASHER, Hex Head, M10x1.5x105	009-140/21
SCREW AND WASHER, Hex Head, M10x1.5x105	009-160/21
SCREW AND WASHER, Hex Head, M10x1.5x105	024-410/16
SCREW AND WASHER, Hex Head, M10x1.5x25.	009-140/10
SCREW AND WASHER, Hex Head, M10x1.5x25.	024-205/10
SCREW AND WASHER, Hex Head, M10x1.5x25.	41TE-AE-220/1
SCREW AND WASHER, Hex Head, M10x1.5x30.	013-110/23
SCREW AND WASHER, Hex Head, M10x1.5x40.	009-140/18
SCREW AND WASHER, Hex Head, M10x1.5x40.	009-160/10
SCREW AND WASHER, Hex Head, M10x1.5x40.	009-160/18
SCREW AND WASHER, Hex Head, M10x1.5x40.	3.8L-610/4
SCREW AND WASHER, Hex Head, M10x1.5x40.	3.3L6T-610/4
SCREW AND WASHER, Hex Head, M10x1.5x45.	016-120/4
SCREW AND WASHER, Hex Head, M10x1.5x45.	3.8L-810/21
SCREW AND WASHER, Hex Head, M10x1.5x45.	3.3L6T-810/17
SCREW AND WASHER, Hex Head, M10x1.5x50.	008-215/3
SCREW AND WASHER, Hex Head, M10x1.5x50.	024-410/17
SCREW AND WASHER, Hex Head, M10x1.5x53.	008-105/4
SCREW AND WASHER, Hex Head, M10x1.5x53.	002-145/30
SCREW AND WASHER, Hex Head, M10x1.5x53.	009-140/19
SCREW AND WASHER, Hex Head, M10x1.5x53.	009-160/19
SCREW AND WASHER, Hex Head, M12x1.75x30	009-140/12
SCREW AND WASHER, Hex Head, M12x1.75x30	009-160/12
SCREW AND WASHER, Hex Head, M14-2x95.....	019-321/2
SCREW AND WASHER, Hex Head, M14x2.00x125.00	013-110/13
SCREW AND WASHER, Hex Head, M14x2.00x125.00	017-145/39
SCREW AND WASHER, Hex Head, M14x2.00x125.00	017-155/35
SCREW AND WASHER, Hex Head, M14x2.0x55.	013-110/15
SCREW AND WASHER, Hex Head, M5x.8x14.....	41TE-AE-1225/3
SCREW AND WASHER, Hex Head, M6 x 1.00 x 23.30	08A-105/66
SCREW AND WASHER, Hex Head, M6 x 1.00 x 23.30	DRS-310/25
SCREW AND WASHER, Hex Head, M6 x 1.00 x 23.30	DRS-310/36
SCREW AND WASHER, Hex Head, M6x1x14.....	31TH-210/9
SCREW AND WASHER, Hex Head, M6x1x14.....	3.8L-510/13
SCREW AND WASHER, Hex Head, M6x1x14.....	3.3L6T-510/13

SCREW AND WASHER, Hex Head, M6x1x14 . . . . .	41TE-AE-220/14	SCREW, .164-18x.625 . . . . .	001-295/3
SCREW AND WASHER, Hex Head, M6x1x15 . . . . .	3.8L-810/31	SCREW, .164-18x.75 . . . . .	DRS-190/6
SCREW AND WASHER, Hex Head, M6x1x15 . . . . .	3.3L6T-810/31	SCREW, .164-18x1.00 . . . . .	019-245/5
SCREW AND WASHER, Hex Head, M6x1x16 . . . . .	014-460/5	SCREW, .164-32x1.00 . . . . .	019-245/23
SCREW AND WASHER, Hex Head, M6x1x16 . . . . .	014-740/9	SCREW, .19-16x1.00 . . . . .	008-1110/10
SCREW AND WASHER, Hex Head, M6x1x16 . . . . .	024-205/3	SCREW, .190-16 X .750 . . . . .	SRS-420/2
SCREW AND WASHER, Hex Head, M6x1x16 . . . . .	31TH-210/6	SCREW, .190-16x.542 . . . . .	025-490/12
SCREW AND WASHER, Hex Head, M6x1x16 . . . . .	3.8L-810/10	SCREW, .25-14x.75 . . . . .	014-210/8
SCREW AND WASHER, Hex Head, M6x1x17 . . . . .	3.8L-710/7	SCREW, Cluster PC Board . . . . .	008-1105/18
SCREW AND WASHER, Hex Head, M6x1x17 . . . . .	3.3L6T-710/7	SCREW, Flange Head, M10x1.5x65 . . . . .	3.8L-810/33
SCREW AND WASHER, Hex Head, M6x1x18 . . . . .	21P-120/2	SCREW, Flange Head, M10x1.5x65 . . . . .	3.3L6T-810/32
SCREW AND WASHER, Hex Head, M6x1x18 . . . . .	2.4L-620/18	SCREW, Flange Head, M6x1x18 . . . . .	2.4L-710/8
SCREW AND WASHER, Hex Head, M6x1x25 . . . . .	007-225/1	SCREW, Flange Head, M6x1x18 . . . . .	3.3L6T-710/17
SCREW AND WASHER, Hex Head, M6x1x25 . . . . .	024-205/9	SCREW, Flange Head, M8x1.25x26 . . . . .	SRS-1320/11
SCREW AND WASHER, Hex Head, M6x1x25 . . . . .	IRS-750/4	SCREW, Flange Head, M8x1.25x33 . . . . .	088-120/49
SCREW AND WASHER, Hex Head, M6x1x25 . . . . .	2.4L-710/4	SCREW, Flange Head, M8x1.25x33 . . . . .	31TH-215/45
SCREW AND WASHER, Hex Head, M6x1x25 . . . . .	SRS-1320/17	SCREW, Flange Head, M8x1.25x33 . . . . .	41TE-AE-240/28
SCREW AND WASHER, Hex Head, M6x1x30 . . . . .	014-110/5	SCREW, Header Point, M10x1.50x25.00 . . . . .	003-420/8
SCREW AND WASHER, Hex Head, M6x1x30 . . . . .	DRS-180/35	SCREW, Headlamp Extension . . . . .	008-1105/9
SCREW AND WASHER, Hex Head, M6x1x35 . . . . .	2.4L-620/17	SCREW, Heater Core Mounting . . . . .	024-120/23
SCREW AND WASHER, Hex Head, M6x1x93.5 . . . . .	41TE-AE-240/23	SCREW, Hex Flange Head . . . . .	009-140/9
SCREW AND WASHER, Hex Head, M8 x 1.25 x 38.00	23D-205/25	SCREW, Hex Flange Head . . . . .	024-205/4
SCREW AND WASHER, Hex Head, M8-1.25x22.00	013-110/10	SCREW, Hex Flange Head Locking, M5x.8x37 . . . . .	31TH-620/4
SCREW AND WASHER, Hex Head, M8-1.25x32.00	SRS-1310/4	SCREW, Hex Flange Head Pilot, M6x1x30 . . . . .	SRS-510/4
SCREW AND WASHER, Hex Head, M8-1.25x32.00	SRS-1320/8	SCREW, Hex Flange Head Tapping, .19-16x1.00 . . . . .	019-245/27
SCREW AND WASHER, Hex Head, M8-1.25x32.00	SRS-1310/11	SCREW, Hex Flange Head, .25-14x.625 . . . . .	008-1110/18
SCREW AND WASHER, Hex Head, M8-1.25x40 . . . . .	019-520/6	SCREW, Hex Flange Head, M10x1.5x61 . . . . .	3.8L-410/13
SCREW AND WASHER, Hex Head, M8-1.25x40 . . . . .	31TH-210/1	SCREW, Hex Flange Head, M10x1.5x61 . . . . .	3.3L6T-410/13
SCREW AND WASHER, Hex Head, M8-1.25x40 . . . . .	41TE-AE-220/9	SCREW, Hex Flange Head, M4.8x1.59x13 . . . . .	08A-410/18
SCREW AND WASHER, Hex Head, M8x1.25x20 . . . . .	025-310/8	SCREW, Hex Flange Head, M6 x 1.00 x 14.00 . . . . .	008-1105/7
SCREW AND WASHER, Hex Head, M8x1.25x20 . . . . .	007-105/10	SCREW, Hex Flange Head, M6 x 1.00 x 59.8 . . . . .	008-1605/15
SCREW AND WASHER, Hex Head, M8x1.25x20 . . . . .	025-260/11	SCREW, Hex Flange Head, M6x1x 60 . . . . .	23D-305/5
SCREW AND WASHER, Hex Head, M8x1.25x20 . . . . .	2.4L-810/8	SCREW, Hex Flange Head, M8x1.25x20 . . . . .	004-147/6
SCREW AND WASHER, Hex Head, M8x1.25x20 . . . . .	3.3L6T-710/11	SCREW, Hex Flange Head, M8x1.25x20 . . . . .	SRS-1320/9
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	007-175/20	SCREW, Hex Flange Head, M8x1.25x20 . . . . .	SRS-1310/12
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	008-1005/4	SCREW, Hex Flange Head, M8x1.25x32 . . . . .	088-120/46
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	2.4L-810/9	SCREW, Hex Flange Head, M8x1.25x32 . . . . .	2.4L-810/7
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	2.4L-620/16	SCREW, Hex Flange Head, M8x1.25x32 . . . . .	2.4L-710/22
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	2.4L-710/11	SCREW, Hex Flange Head, M8x1.25x40 . . . . .	2.4L-210/15
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	3.8L-710/12	SCREW, Hex Head . . . . .	003-115/16
SCREW AND WASHER, Hex Head, M8x1.25x25 . . . . .	3.3L6T-710/13	SCREW, Hex Head . . . . .	005-561/14
SCREW AND WASHER, Hex Head, M8x1.25x30 . . . . .	025-310/3	SCREW, Hex Head Locking, .437-20x1.695 . . . . .	IRS-710/5
SCREW AND WASHER, Hex Head, M8x1.25x33 . . . . .	DRS-180/24	SCREW, Hex Head Locking, .437-20x1.695 . . . . .	IRS-740/6
SCREW AND WASHER, Hex Head, M8x1.25x45 . . . . .	008-205/8	SCREW, Hex Head, .19-16x1 . . . . .	004-142/11
SCREW AND WASHER, Hex Head, M8x1.25x45 . . . . .	011-110/4	SCREW, Hex Head, M10x1.5x50 . . . . .	008-105/3
SCREW AND WASHER, Hex Head, M8x1.25x45 . . . . .	007-404/10	SCREW, Hex Head, M12x1.75x65.00 . . . . .	017-145/35
SCREW AND WASHER, Hex Head, M8x1.25x45 . . . . .	3.8L-610/2	SCREW, Hex Head, M12x1.75x50 . . . . .	31TH-210/8
SCREW AND WASHER, Hex Head, M8x1.25x45 . . . . .	3.3L6T-610/2	SCREW, Hex Head, M12x1.75x50 . . . . .	41TE-AE-220/11
SCREW AND WASHER, Hex Head, M8x1.25x65 . . . . .	014-640/6	SCREW, Hex Head, M12x1.75x92.00 . . . . .	017-145/21
SCREW AND WASHER, Hex Head, M8x1.25x65 . . . . .	014-660/6	SCREW, Hex Head, M12x1.75x92.00 . . . . .	017-155/25
SCREW AND WASHER, Hex Head, M8x1.25x65 . . . . .	3.3L6T-210/12	SCREW, Hex Head, M12x1.75x92.00 . . . . .	017-155/32
SCREW AND WASHER, Hex Head, M8x1.25x90 . . . . .	019-510/9	SCREW, Hex Head, M4.09 x 0.79 x 17.78 . . . . .	3.8L-810/12
SCREW AND WASHER, Hex Head, M8x1.25x95 . . . . .	024-410/3	SCREW, Hex Head, M4.2x1.41 . . . . .	019-145/4
SCREW AND WASHER, M8x1.25x20 . . . . .	IRS-825/23	SCREW, Hex Head, M4.8-1.59x19 . . . . .	024-120/5
SCREW AND WASHER, Oval Head, .19-16x.75 . . . . .	08A-405/12	SCREW, Hex Head, M4.8-1.59x19 . . . . .	024-130/5
SCREW AND WASHER, Oval Head, M6x1x25 . . . . .	019-720/5	SCREW, Hex Head, M4.8-1.59x19 . . . . .	024-140/5
SCREW AND WASHER, Oval Head, M6x1x25 . . . . .	019-730/6	SCREW, Hex Head, M4.8x1.59x68.00 . . . . .	008-405/3
SCREW AND WASHER, Oval Head, M6x1x25 . . . . .	025-490/6	SCREW, Hex Head, M6 x 1.00 x 17.50 . . . . .	008-405/12
SCREW AND WASHER, Oval Head, M6x1x25 . . . . .	013-260/20	SCREW, Hex Head, M6x1x16 . . . . .	008-625/5
SCREW AND WASHER, Pan Head, M5x.8x25 . . . . .	31TH-715/12	SCREW, Hex Head, M6x1x20 . . . . .	024-207/3
SCREW AND WASHER, Pan Head, M5x.8x25 . . . . .	31TH-715/18	SCREW, Hex Head, M6x1x20 . . . . .	005-561/13
SCREW AND WASHER, Pan Head, M5x.8x25 . . . . .	41TE-AE-715/12	SCREW, Hex Head, M6x1x25 . . . . .	025-310/20
SCREW AND WASHER, Pan Head, M5x0.8x11.00	41TE-AE-440/9	SCREW, Hex Head, M8x1.25x24 . . . . .	SRS-1330/8
SCREW AND WASHER, Round Head, .164-15x.625	008-625/8	SCREW, Hex Head, M8x20 . . . . .	SRS-510/5
SCREW AND WASHER, Round Head, .164-15x.625	SRS-1320/14	SCREW, Jack . . . . .	IRS-535/9
SCREW AND WASHER, Self Tapping, M6x1x22 . . . . .	008-1605/17	SCREW, LargeRoundWasherHeadLock,M6x1.00x20.00	022-340/5
SCREW AND WASHER, Tapping, M6-1.0x20.0 . . . . .	008-505/4	SCREW, LargeRoundWasherHeadLock,M6x1.00x20.00	DRS-310/22
SCREW AND WASHER, Tapping, M6-1.0x20.0 . . . . .	019-730/15	SCREW, M6x1.00x15.00 . . . . .	SRS-1320/4
		SCREW, M6x1x20 . . . . .	IRS-420/13
		SCREW, M6x1x25 . . . . .	014-310/5
		SCREW, M7X1.25X16.00 . . . . .	IRS-740/8
		SCREW, M8-1.25 . . . . .	SRS-410/14
			025-260/13

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

SCREW, M8x1.25x25	005-569/9	SCREW, Tress Head, #8x.5	IRS-535/28
SCREW, Oval Head, M8x1.25x39.5	SRS-915/4	SCREW, Tress Head, #8x.5	IRS-815/19
SCREW, Oval Head, M8x1.25x39.5	DRS-180/33	SCREW, Tress Head, #8x.5	IRS-815/28
SCREW, Pan Head Locking, M5x0.8x30.00	41TE-AE-715/23	SCREW, Tress Head, #8x.5	IRS-820/13
SCREW, Pan Head Tapping, .125-40x.437	008-805/6	SCREW, Tress Head, #8x.5	IRS-825/22
SCREW, Pan Head Tapping, .19-16x.625	SRS-420/8	SCREW, Truss Head, M6x1x15	SRS-915/7
SCREW, Pan Head, .19-16x.75	SRS-610/2	SCREW, Truss Head, M6x1x15	DRS-310/28
SCREW, Pan Head, .437-20x1.875	IRS-740/9	SCREW, Truss Head, M6x1x15	DRS-610/11
SCREW, Pan Head, M5 x 0.8 x 12.60	31TH-715/11	SCREW, pan head, .19-16x1.300	IRS-110/11
SCREW, Pan Head, M5 x 0.8 x 12.60	41TE-AE-715/17	SCUFF PAD, Rear Fascia	013-360/9
SCREW, Pan Head, M6-1.00x29.00	SRS-1610/8	SEAL	088-120/4
SCREW, Pan Head, M8x1.25x41.5	IRS-610/8	SEAL	088-120/7
SCREW, Pan Head, M8x1.25x41.5	IRS-615/8	SEAL	088-120/8
SCREW, Pan Head, M8x1.25x41.5	IRS-620/9	SEAL	088-120/10
SCREW, Pan Head, M8x1.25x41.5	IRS-625/9	SEAL	31TH-215/31
SCREW, Pan Head, M8x1.25x41.5	IRS-630/7	SEAL	31TH-215/46
SCREW, Pan Head, M8x1.25x41.5	IRS-635/7	SEAL	41TE-AE-240/17
SCREW, Pan Head, M8x1.25x41.5	IRS-820/5	SEAL	41TE-AE-240/26
SCREW, Pan Head, M8x1.25x41.5	IRS-535/25	SEAL AND GASKET PACKAGE, Transmission	31TH-215/49
SCREW, Pan Head, M8x1.25x41.5	IRS-815/14	SEAL AND GASKET PACKAGE, Transmission	41TE-AE-240/1
SCREW, Recliner Handle, M4x7x14	IRS-535/29	SEALANDGASKETPACKAGE,TransmissionFrontClutch	41TE-AE-425/1
SCREW, Reverse Band Adjusting, M8x1.25x42	31TH-520/11	SEALANDGASKETPACKAGE,TransmissionOilPump	41TE-AE-320/1
SCREW, Round Head, .164-15x1.00	IRS-1010/8	SEAL KIT, A/C And Heater Unit	024-120/21
SCREW, Round Head, M6x1x16	IRS-215/5	SEAL KIT, A/C And Heater Unit	024-130/20
SCREW, Round Head, M6x1x16	001-810/14	SEAL KIT, A/C And Heater Unit	024-140/20
SCREW, Round Head, M8x1.25x30	DRS-310/33	SEAL KIT, A/C And Heater Unit	024-150/10
SCREW, Self Piercing, .164-15-1	019-245/15	SEAL KIT, Rear Axle	003-115/6
SCREW, Self Piercing, .25-14x.625	001-295/2	SEAL PACKAGE, Transmission Clutch	41TE-AE-440/5
SCREW, Self Tapping, M4.2x1.69x19.05	08A-305/9	SEAL PACKAGE, Transmission Clutch	41TE-AE-440/7
SCREW, Self Tapping, M4.2x1.69x19.05	08A-310/3	SEAL PACKAGE, Transmission Clutch	41TE-AE-425/33
SCREW, Self Tapping, M4.2x1.69x19.05	08A-410/8	SEAL PACKAGE, Transmission Clutch	41TE-AE-425/42
SCREW, Self Tapping, M4.2x1.69x19.05	013-260/19	SEAL PACKAGE, Transmission Clutch	41TE-AE-440/60
SCREW, Shoulder Hex Flange Head, M5x.8x20	31TH-620/5	SEAL PACKAGE, Transmission Clutch	41TE-AE-440/62
SCREW, Shouldered Hex Head, M10x1.5x70	017-145/31	SEAL, Accumulator	31TH-725/2
SCREW, Shouldered Hex Head, M10x1.5x70	017-155/21	SEAL, Accumulator	31TH-725/16
SCREW, Shouldered Hex Head, M10x1.5x70	017-155/30	SEAL, Accumulator	41TE-AE-715/9
SCREW, Special Head, M5x.8x42.40	31TH-715/4	SEAL, Accumulator	41TE-AE-725/3
SCREW, Special Head, M8x1.25x32.5	IRS-630/9	SEAL, Accumulator	41TE-AE-725/8
SCREW, Special Head, M8x1.25x32.5	IRS-635/9	SEAL, Air Conditioning Unit	024-120/7
SCREW, Special Head, M8x1.25x32.5	IRS-820/8	SEAL, Air Conditioning Unit	024-130/7
SCREW, Special Head, M8x1.25x32.5	IRS-535/23	SEAL, Air Conditioning Unit	024-140/7
SCREW, Special Head, M8x1.25x32.5	IRS-610/10	SEAL, Air Conditioning Unit	024-130/21
SCREW, Special Head, M8x1.25x32.5	IRS-615/10	SEAL, Air Conditioning Unit	024-140/21
SCREW, Special Head, M8x1.25x32.5	IRS-620/11	SEAL, Air Inlet	024-610/14
SCREW, Special Head, M8x1.25x32.5	IRS-625/11	SEAL, Ball Joint	002-145/21
SCREW, Special Head, M8x1.25x32.5	IRS-815/17	SEAL, Brake Booster To Dash	005-343/2
SCREW, Special Shouldered, M10x1x29	41TE-AE-820/14	SEAL, Camshaft	2.4L-210/8
SCREW, Strip-Out Repair	008-615/5	SEAL, Camshaft	2.4L-510/7
SCREW, Strip-Out Repair	025-260/12	SEAL, Camshaft Sensor	008-605/4
SCREW, Tap, M9x1.25x26	008-1005/13	SEAL, Camshaft Sensor	2.4L-510/18
SCREW, Tapping	024-310/2	SEAL, Catch	DRS-310/43
SCREW, Tapping	IRS-235/5	SEAL, Catch	SRS-815/15
SCREW, Tapping	IRS-235/8	SEAL, Clutch Feed	41TE-AE-715/6
SCREW, Tapping Hex Flange Head, M6.3x1.81x20.00	IRS-230/3	SEAL, Cowl	SRS-610/13
SCREW, Tapping, .164-15x.50	IRS-510/16	SEAL, EGR Tube	3.8L-810/6
SCREW, Tapping, .19-16x.625	024-620/6	SEAL, EGR Tube	3.3L6T-810/6
SCREW, Tapping, .19-16x.625	IRS-220/5	SEAL, Extension	088-120/3
SCREW, Tapping, .19-16x.625	IRS-225/2	SEAL, Front Clutch Piston	31TH-435/3
SCREW, Tapping, .19-16x.625	IRS-235/2	SEAL, Front Door Belt	DRS-610/6
SCREW, Tapping, .19-16x.625	IRS-240/5	SEAL, Front Main Crankshaft	2.4L-710/21
SCREW, Tapping, .19-16x.625	SRS-1330/2	SEAL, Front Main Crankshaft	3.8L-610/12
SCREW, Tapping, .19-16x.625	008-1110/19		
SCREW, Tapping, .19-16x.75	SRS-520/6		
SCREW, Tapping, .19-16x.75	08A-310/17		
SCREW, Tapping, .19-16x.75	08A-310/25		
SCREW, Tapping, .190-16X.500	011-210/4		
SCREW, Tapping, M8x20	005-565/2		
SCREW, Tapping, M8x20	005-565/12		
SCREW, Thumb	001-130/8		
SCREW, Tress Head, #8x.5	IRS-540/1		
SCREW, Tress Head, #8x.5	IRS-815/2		
SCREW, Tress Head, #8x.5	IRS-825/2		
SCREW, Tress Head, #8x.5	IRS-830/8		
SCREW, Tress Head, #8x.5	IRS-535/12		
SCREW, Tress Head, #8x.5	IRS-535/13		

SEAL, Front Main Crankshaft . . . . .	3.3L6T-610/ 12	SEAT BACK, Front . . . . .	IRS-510/3
SEAL, Front Piston Clutch . . . . .	31TH-435/5	SEAT BACK, Front . . . . .	IRS-515/3
SEAL, Fuel Pump and Level Unit . . . . .	014-510/5	SEAT BACK, Front . . . . .	IRS-520/3
SEAL, Governor Support . . . . .	31TH-620/12	SEAT BACK, Front . . . . .	IRS-525/4
SEAL, Hood . . . . .	SRS-510/9	SEAT BACK, Front . . . . .	IRS-530/3
SEAL, Impeller Hub, 57.25mm OD . . . . .	31TH-320/9	SEAT BACK, Rear Quad . . . . .	IRS-620/3
SEAL, Impeller Hub, 57.25mm OD . . . . .	41TE-AE- 320/10	SEAT BACK, Rear Quad . . . . .	IRS-625/3
SEAL, Input Shaft . . . . .	31TH-415/1	SEAT BACK, Rear Quad . . . . .	IRS-630/2
SEAL, Input Shaft . . . . .	41TE-AE- 425/35	SEAT BACK, Rear Quad . . . . .	IRS-635/2
SEAL, Intake Manifold . . . . .	3.8L-810/5	SEAT BACK, Rear, 2 Passenger . . . . .	IRS-610/2
SEAL, Intake Manifold . . . . .	3.3L6T-810/5	SEAT BACK, Rear, 2 Passenger . . . . .	IRS-615/2
SEAL, Kickdown Servo . . . . .	31TH-725/9	SEAT BACK, Rear, 2 Passenger . . . . .	IRS-815/10
SEAL, Kickdown Servo . . . . .	31TH-725/10	SEAT BACK, Rear, 3 Passenger . . . . .	IRS-640/4
SEAL, Manual Lever Shaft . . . . .	31TH-215/35	SEAT BACK, Rear, w/Center Armrest . . . . .	IRS-640/8
SEAL, Manual Valve Lever . . . . .	41TE-AE- 715/3	SEAT BACK, Rear, w/Child Seat . . . . .	IRS-610/3
SEAL, Manual Valve Position Sensor . . . . .	008-620/4	SEAT BACK, Rear, w/Child Seat . . . . .	IRS-615/3
SEAL, Master Cylinder To Booster . . . . .	005-416/6	SEAT BELT, 1st Rear Outer . . . . .	IRS-740/3
SEAL, Oil Cooler By-Pass Valve . . . . .	2.4L-710/25	SEAT BELT, 2 Passenger Inner . . . . .	IRS-730/1
SEAL, Oil Filler Tube . . . . .	31TH-210/7	SEAT BELT, 2nd Rear Outer . . . . .	IRS-750/1
SEAL, Oil Filler Tube . . . . .	31TH-715/21	SEAT BELT, 3 Passenger Inner . . . . .	IRS-730/2
SEAL, Oil Filler Tube . . . . .	41TE-AE- 220/12	SEAT BELT, Front Inner . . . . .	IRS-710/1
SEAL, Oil Pick Up Tube . . . . .	2.4L-710/10	SEAT BELT, QUAD SEATS, . . . . .	IRS/720
SEAL, Oil Pick Up Tube . . . . .	3.8L-710/13	SEAT BELT, Rear Outer . . . . .	IRS-750/6
SEAL, Oil Pick Up Tube . . . . .	3.3L6T-710/ 14	SEAT BELT, Rear Quad Inner . . . . .	IRS-720/1
SEAL, Oil Pump . . . . .	31TH-320/7	SEAT BELT, Retractor . . . . .	IRS-710/2
SEAL, Oil Pump . . . . .	41TE-AE- 320/8	SEAT BELT, Retractor . . . . .	IRS-740/4
SEAL, Piston Accumulator . . . . .	31TH-725/11	SEAT BELTS, FRONT SEAT, . . . . .	IRS/710
SEAL, Piston Accumulator . . . . .	31TH-725/12	SEAT BELTS, REAR INNER, 2 AND 3 PASSENGERS, . . . . .	IRS/730
SEAL, Piston Outer, 140mm OD . . . . .	41TE-AE- 425/32	SEAT BELTS, REAR SECOND SEAT, OUTER, . . . . .	IRS/740
SEAL, Pump Reaction Shaft . . . . .	31TH-320/3	SEAT BELTS, REAR THIRD SEAT, OUTER, . . . . .	IRS/750
SEAL, Radiator . . . . .	007-105/14	SEAT COMPLETE, Front . . . . .	IRS-510/8
SEAL, Radiator . . . . .	007-175/10	SEAT COMPLETE, Front . . . . .	IRS-515/8
SEAL, Radiator Side Air . . . . .	007-175/9	SEAT COMPLETE, Front . . . . .	IRS-520/8
SEAL, Radiator Side Air . . . . .	007-105/13	SEAT COMPLETE, Front . . . . .	IRS-530/9
SEAL, Rear Axle Flange . . . . .	003-115/4	SEAT COMPLETE, Front . . . . .	IRS-525/10
SEAL, Rear Clutch Piston . . . . .	31TH-415/10	SEAT COMPLETE, REAR, 50/50 BENCH . . . . .	IRS-640/21
SEAL, Rear Clutch Piston . . . . .	31TH-415/13	SEAT COMPLETE, REAR, 50/50 BENCH . . . . .	IRS-640/22
SEAL, Rear Clutch Retainer, 1.75 OD . . . . .	31TH-415/3	SEAT COMPLETE, Rear Quad . . . . .	IRS-620/13
SEAL, Rear Main Crankshaft . . . . .	3.8L-310/6	SEAT COMPLETE, Rear Quad . . . . .	IRS-625/13
SEAL, Rear Main Crankshaft . . . . .	2.4L-310/10	SEAT COMPLETE, Rear Quad . . . . .	IRS-630/11
SEAL, Rear Main Crankshaft . . . . .	2.4L-410/12	SEAT COMPLETE, Rear Quad . . . . .	IRS-635/11
SEAL, Rear Main Crankshaft . . . . .	3.8L-410/23	SEAT COMPLETE, Rear, Three Passenger . . . . .	IRS-640/6
SEAL, Rear Main Crankshaft . . . . .	3.3L6T-310/6	SEAT COMPLETE, Rear, Three Passenger . . . . .	IRS-640/11
SEAL, Rear Main Crankshaft . . . . .	3.3L6T-410/ 24	SEAT COMPLETE, Rear, Two Passenger . . . . .	IRS-610/12
SEAL, Reverse Servo Piston . . . . .	31TH-725/25	SEAT COMPLETE, Rear, Two Passenger . . . . .	IRS-615/12
SEAL, Reverse Servo Piston . . . . .	41TE-AE- 425/49	SEAT COMPLETE, Rear, Two Passenger Child Seat . . . . .	IRS-610/13
SEAL, Ring Reaction Support, 2 1/16 O.D. . . . .	41TE-AE- 320/3	SEAT COMPLETE, Rear, Two Passenger Child Seat . . . . .	IRS-615/13
SEAL, Spark Plug Tube . . . . .	2.4L-210/5	SEAT FRONT - TRIM CODE [A7], . . . . .	IRS/520
SEAL, Spark Plug Tube . . . . .	008-1905/21	SEAT FRONT - TRIM CODE [CL, ML] . . . . .	IRS/525
SEAL, Throttle Body to Intake . . . . .	014-660/4	SEAT FRONT - TRIM CODE [DL], . . . . .	IRS/530
SEAL, Throttle Body to Intake . . . . .	3.8L-810/4	SEAT FRONT - TRIM CODE [E7,L5,H5]. . . . .	IRS/510
SEAL, Throttle Body to Intake . . . . .	3.3L6T-810/4	SEAT FRONT - TRIM CODE [J7, K5],. . . . .	IRS/515
SEAL, Torque Converter Hub . . . . .	3.8L-410/24	SEAT, Exhaust Valve . . . . .	3.8L-510/25
SEAL, Under Drive . . . . .	41TE-AE- 425/41	SEAT, Exhaust Valve . . . . .	3.3L6T-510/ 23
SEAL, Valve Guide . . . . .	2.4L-510/12	SEAT, Intake Valve . . . . .	3.8L-510/26
SEAL, Valve Guide . . . . .	3.8L-510/10	SEAT, Intake Valve . . . . .	3.3L6T-510/ 24
SEAL, Valve Guide . . . . .	3.3L6T-510/ 10	SEAT, Valve Spring . . . . .	3.8L-510/19
SEAL, Valve Lever Shift . . . . .	31TH-715/3	SEAT, Valve Spring . . . . .	3.3L6T-510/ 17
SEAL, Water Pump Body . . . . .	007-207/3	SENSOR AND BRACKET, Ambient Temperature . . . . .	008-625/3
SEAL, Water Pump To Front Cover . . . . .	007-225/6	SENSOR PACKAGE, Camshaft . . . . .	008-605/3
SEAT - REAR ATTACHMENTS FLOOR PAN, . . . . .	IRS/810	SENSOR, Ambient Temperature . . . . .	008-625/4
SEAT BACK, 50/50 BENCH . . . . .	IRS-640/13	SENSOR, Anti-Lock Brakes . . . . .	005-565/3
SEAT BACK, 50/50 BENCH . . . . .	IRS-640/14	SENSOR, Anti-Lock Brakes . . . . .	005-565/9
		SENSOR, Anti-Lock Brakes . . . . .	008-625/1
		SENSOR, Anti-Lock Brakes . . . . .	008-625/2
		SENSOR, Anti-Lock Brakes . . . . .	005-220/22
		SENSOR, Anti-Lock Brakes . . . . .	005-561/11
		SENSOR, Anti-Lock Brakes . . . . .	005-565/18
		SENSOR, Brake Pedal . . . . .	005-650/7
		SENSOR, Charge Air Temp . . . . .	008-615/6
		SENSOR, Charge Air Temp . . . . .	014-810/7
		SENSOR, Charge Air Temp . . . . .	008-605/12
		SENSOR, Charge Air Temp . . . . .	014-830/12
		SENSOR, Coolant Temperature . . . . .	008-605/1
		SENSOR, Coolant Temperature . . . . .	008-615/3

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

SENSOR, Crankshaft	008-615/13	SHIELD KIT, Air - Front	001-520/1
SENSOR, Crankshaft Position	008-605/6	SHIELD SIDE, Seat	IRS-535/2
SENSOR, D.I.S. Camshaft Reference	008-615/11	SHIELD SIDE, Seat	IRS-540/6
SENSOR, Knock	008-605/5	SHIELD SIDE, Seat	IRS-540/7
SENSOR, Knock	008-615/12	SHIELD SIDE, Seat	IRS-535/10
SENSOR, Map	008-615/4	SHIELD SIDE, Seat	IRS-820/21
SENSOR, Map	008-605/10	SHIELD, Accessory Drive	007-404/5
SENSOR, Map	3.8L-810/11	SHIELD, Accessory Drive	SRS-420/3
SENSOR, Map	3.3L6T-810/7	SHIELD, Accessory Drive	007-425/10
SENSOR, Oxygen	008-605/8	SHIELD, Battery	008-1005/10
SENSOR, Oxygen	008-605/9	SHIELD, CLOSEOUT PANEL	IRS-535/30
SENSOR, Oxygen	008-615/1	SHIELD, Coil	008-1905/12
SENSOR, Oxygen	008-615/2	SHIELD, Door	SRS-420/5
SENSOR, Pinch	008-625/7	SHIELD, Engine Mount	011-210/6
SENSOR, Pinch	SRS-1320/13	SHIELD, Engine Mount	009-140/16
SENSOR, Shock, With Terminals	001-914/5	SHIELD, Engine Mount	009-160/16
SENSOR, Throttle Position	008-615/9	SHIELD, Exhaust Manifold	3.8L-810/26
SENSOR, Throttle Position	014-640/2	SHIELD, Exhaust Manifold	3.8L-810/27
SENSOR, Throttle Position	014-660/3	SHIELD, Exhaust Manifold	3.8L-810/28
SENSOR, Throttle Position	008-605/11	SHIELD, Exhaust Manifold	3.3L6T-810/22
SENSOR, Tire Pressure, valve stem	008-625/9	SHIELD, Exhaust Manifold	3.3L6T-810/23
SENSOR, Tire Pressure, valve stem	022-140/11	SHIELD, Exhaust Manifold	24
SENSOR, Transmission Input Speed	008-620/1	SHIELD, Exhaust Manifold	3.3L6T-810/24
SENSOR, Transmission Input Speed	41TE-AE-240/14	SHIELD, Fender	SRS-420/7
SENSOR, Transmission Output Speed	008-620/5	SHIELD, Heat	011-210/1
SENSOR, Transmission Output Speed	41TE-AE-240/9	SHIELD, Heat	011-210/2
SENSOR, Transmission Range	008-620/3	SHIELD, Heat	011-210/3
SENSOR, Transmission Range	41TE-AE-715/8	SHIELD, Heat	011-210/7
SENSOR, Vehicle Speed	21P-120/1	SHIELD, Shock Absorber Dust	002-145/4
SENSOR, Washer Fluid Level	008-625/6	SHIELD, Starter	008-105/2
SENSOR, Washer Fluid Level	23D-210/16	SHIELD, Steering Coupling	019-245/26
SENSORS, BODY	008/625	SHIELD, W/CUPHOLDER	IRS-820/20
SENSORS, ENGINE 2.4 (EDZ)	008/605	SHIELD, Wheel Bearing	002-245/5
SENSORS, ENGINE 3.3, 3.8 (EGA,EGH, EGM)	008/615	SHIELD, Wheelhouse	SRS-410/1
SENSORS, TRANSMISSION	008/620	SHIELD, Wheelhouse	SRS-420/1
SEPARATOR, Liquid Vapor	014-310/10	SHIELD, Wheelhouse	SRS-420/6
SEPERATOR, Ignition Cable	008-1905/13	SHIELDS	SRS-910/7
SERVO, Speed Control	014-1010/5	SHIM	SRS/420
SERVOS, ACCUMULATOR PISTON AND SPRINGS	31TH/725	SHIM, Door Hinge	SRS-1310/5
SHAFT TRANSFER	41TE-AE/415	SHIM, Output Shaft, 4.67 - 4.69mm	DRS-180/26
SHAFT, Axle Half	003-420/1	SHIM, Output Shaft, 4.70 - 4.72mm	088-120/11
SHAFT, Balance	2.4L-620/4	SHIM, Output Shaft, 4.73 - 4.75mm	088-120/12
SHAFT, Balance	2.4L-620/5	SHIM, Output Shaft, 4.76 - 4.78mm	088-120/13
SHAFT, Band Lever	31TH-520/1	SHIM, Output Shaft, 4.79 - 4.81mm	088-120/14
SHAFT, Band Lever	31TH-520/13	SHIM, Output Shaft, 4.82 - 4.84mm	088-120/15
SHAFT, Differential	41TE-AE-820/11	SHIM, Output Shaft, 4.85 - 4.87mm	088-120/16
SHAFT, Drive	016-120/1	SHIM, Output Shaft, 4.88 - 4.90mm	088-120/17
SHAFT, FRONT DRIVE	002/245	SHIM, Output Shaft, 4.91 - 4.93mm	088-120/18
SHAFT, Front Drive	002-245/1	SHIM, Output Shaft, 4.94 - 4.96mm	088-120/19
SHAFT, Intermediate	019-245/24	SHIM, Output Shaft, 4.97 - 4.99mm	088-120/20
SHAFT, OUTPUT, REAR CARRIER, REVERSE DRUM AND OVER RUNNING CLUTCH	31TH/460	SHIM, Output Shaft, 5.00 - 5.02mm	088-120/21
SHAFT, Parking Sprag	31TH-740/5	SHIM, Output Shaft, 5.03 - 5.05mm	088-120/22
SHAFT, Parking Sprag	41TE-AE-740/3	SHIM, Output Shaft, 5.06 - 5.08mm	088-120/23
SHAFT, Parking Sprag	41TE-AE-740/4	SHIM, Output Shaft, 5.09 - 5.11mm	088-120/24
SHAFT, Pinion Gear	31TH-820/9	SHIM, Output Shaft, 5.12 - 5.14mm	088-120/25
SHAFT, Pinion Gear	41TE-AE-820/12	SHIM, Output Shaft, 5.15 - 5.17mm	088-120/26
SHAFT, REAR AXLE-ALL WHEEL DRIVE	003/420	SHIM, Output Shaft, 5.18 - 5.20mm	088-120/27
SHAFT, Rocker Arm	3.8L-510/4	SHIM, Output Shaft, 5.21 - 5.23mm	088-120/28
SHAFT, Rocker Arm	3.3L6T-510/4	SHIM, Output Shaft, 5.24 - 5.26mm	088-120/29
SHAFT, TRANSFER	31TH/425	SHIM, Output Shaft, 5.27 - 5.29mm	088-120/30
SHAFT, Transfer Gear	31TH-425/1	SHIM, Output Shaft, 5.30 - 5.35mm	088-120/31
SHAFT, Transfer Gear	31TH-820/10	SHIM, Output Shaft, 5.33 - 5.35mm	088-120/32
SHAFT, Transfer Gear	41TE-AE-415/46	SHIM, Output Shaft, 5.36 - 5.38mm	088-120/33
SHAFT, Transfer Gear	41TE-AE-820/13	SHIM, Output Shaft, 5.39 - 5.41mm	088-120/34
SHAFT, Valve Body	31TH-715/9	SHIM, Output Shaft, 5.42 - 5.44mm	088-120/35
SHELL, Sun Gear	31TH-445/11	SHIM, Output Shaft, 5.45 - 5.47mm	088-120/36
SHIELD KIT - AIR FRONT	001/520	SHIM, Output Shaft, 5.48 - 5.50mm	088-120/37
		SHIM, Output Shaft, 5.51 - 5.53mm	088-120/38
		SHIM, Output Shaft, 5.54 - 5.56mm	088-120/39
		SHIM, Output Shaft, 5.57 - 5.59mm	088-120/40
		SHIM, Output Shaft, 5.60 - 5.62mm	088-120/41
		SHIM, Output Shaft, 5.63 - 5.65mm	088-120/42
		SHIM, Output Shaft, 5.66 - 5.68mm	088-120/43
		SHIM, Output Shaft, 5.69 - 5.71mm	088-120/44
		SHOCK ABSORBER, Suspension	017-145/20



SHOCK ABSORBER, Suspension	017-155/24	SNAP RING	41TE-AE-425/43
SHOE AND LINING KIT, Parking Brake	005-220/14	SNAP RING	41TE-AE-425/44
SHOE AND LINING KIT, drum	005-210/1	SNAP RING	41TE-AE-440/46
SHROUD, Antenna Cap Nut	08A-310/18	SNAP RING	41TE-AE-440/52
SHROUD, Steering Column	019-245/16	SNAP RING	41TE-AE-440/54
SHROUD, Steering Column	019-245/22	SNAP RING	41TE-AE-440/57
SHUTTER, Door, Deck and Liftgate, Bright	23D-105/18	SNAP RING	41TE-AE-440/58
SHUTTER, Door, Deck and Liftgate, Bright	23D-105/28	SNAP RING KIT, A/C Clutch	024-410/9
SILENCER KIT, Wiper Housing	23D-205/17	SNAP RING KIT, A/C Clutch	024-410/15
SILENCER, Cowl Side	SRS-410/11	SNAP RING, 1.205 OD	31TH-725/7
SILENCER, Dash Panel	IRS-210/6	SNAP RING, Input Shaft	31TH-415/6
SILENCER, Dash Panel	SRS-610/3	SNAP RING, Input Shaft	31TH-460/2
SILENCER, Hood	SRS-510/7	SNAP RING, Reverse Clutch, 1.77-1.83mm	41TE-AE-425/18
SILENCER, Instrument Panel Left	08A-105/44	SNAP RING, Reverse Clutch, 2.02-2.07mm	41TE-AE-425/19
SILENCER, Wheelhouse	SRS-410/16	SNAP RING, Reverse Clutch, 2.27-2.32mm	41TE-AE-425/20
SILENCER, Wheelhouse	SRS-410/17	SNAP RING, Rod	31TH-740/1
SILENCER, Wheelhouse	SRS-910/21	SNAP RING, Rod	41TE-AE-740/7
SILL, Rear	IRS-245/11	SNAP RING, Steering Column, .687	019-245/9
SINGLE BOARD ENGINE CONTROLLERS (POWERTRAIN CONTROL MODULE)	008/705	SNAP RING, Sun Gear Shell	31TH-445/12
SIREN, Alarm	001-910/3	SNAP RING, Underdrive Clutch, Flat	41TE-AE-425/24
SIREN, Alarm	001-914/2	SNAP RING, Underdrive Clutch, Tapered	41TE-AE-425/5
SKID STRIP, Luggage Rack	SRS-1610/1	SNAP RING, Wheel Hub	005-565/23
SLEEVE, Bumper Bracket	013-360/12	SOCKET	008-1105/6
SLEEVE, Carrier Rubber	003-135/3	SOCKET	008-1110/11
SLEEVE, Fuel Filler Vent Hose	014-210/3	SOCKET, Self Adjuster	005-210/10
SLEEVE, Headrest	IRS-510/7	SOCKET, Tail, Stop, and Turn Lamp	008-1110/4
SLEEVE, Headrest	IRS-515/7	SOLENOID PACKAGE, Valve Body	41TE-AE-240/24
SLEEVE, Headrest	IRS-520/7	SOLENOID, Linear IACV	014-660/1
SLEEVE, Headrest	IRS-525/8	SOLENOID, Proportional Purge	025-410/2
SLEEVE, Headrest	IRS-530/7	SOLENOID, Transmission Lock Up	31TH-715/20
SLEEVE, Headrest	IRS-610/6	SPACER	SRS-710/11
SLEEVE, Headrest	IRS-615/6	SPACER, Air Deflector	001-520/2
SLEEVE, Headrest	IRS-620/7	SPACER, Door Latch Striker	DRS-180/32
SLEEVE, Headrest	IRS-625/7	SPACER, Door Latch Striker	DRS-310/51
SLEEVE, Headrest	IRS-630/5	SPACER, Final Drive, 0.82mm	31TH-820/16
SLEEVE, Headrest	IRS-635/5	SPACER, Final Drive, 0.98mm	31TH-215/7
SLEEVE, Headrest	IRS-640/2	SPACER, Final Drive, 0.98mm	41TE-AE-240/35
SLEEVE, Headrest	IRS-640/3	SPACER, Final Drive, 1.02mm	31TH-215/8
SLEEVE, Headrest	IRS-815/12	SPACER, Final Drive, 1.02mm	41TE-AE-240/36
SLEEVE, Headrest	IRS-820/16	SPACER, Final Drive, 1.06mm	31TH-215/9
SLEEVE, Starter Shield	008-105/5	SPACER, Final Drive, 1.06mm	41TE-AE-240/37
SMOKERS KIT, Ash Receiver With Lighter	08A-105/56	SPACER, Final Drive, 1.10mm	31TH-215/10
SNAP RING	088-120/9	SPACER, Final Drive, 1.10mm	41TE-AE-240/38
SNAP RING	31TH-425/6	SPACER, Final Drive, 1.14mm	31TH-215/11
SNAP RING	31TH-445/1	SPACER, Final Drive, 1.14mm	41TE-AE-240/39
SNAP RING	31TH-445/3	SPACER, Final Drive, 1.18mm	31TH-215/12
SNAP RING	31TH-715/1	SPACER, Final Drive, 1.18mm	41TE-AE-240/40
SNAP RING	31TH-725/1	SPACER, Final Drive, 1.22mm	31TH-215/13
SNAP RING	31TH-1225/5	SPACER, Final Drive, 1.22mm	41TE-AE-240/41
SNAP RING	31TH-415/20	SPACER, Final Drive, 1.26mm	31TH-215/14
SNAP RING	31TH-415/21	SPACER, Final Drive, 1.26mm	41TE-AE-240/42
SNAP RING	31TH-415/22	SPACER, Final Drive, 1.30mm	31TH-215/15
SNAP RING	31TH-415/23		
SNAP RING	31TH-415/24		
SNAP RING	31TH-435/11		
SNAP RING	31TH-435/12		
SNAP RING	31TH-725/17		
SNAP RING	31TH-725/19		
SNAP RING	31TH-725/26		
SNAP RING	41TE-AE-425/9		
SNAP RING	41TE-AE-440/3		
SNAP RING	41TE-AE-725/7		
SNAP RING	41TE-AE-415/42		
SNAP RING	41TE-AE-425/13		
SNAP RING	41TE-AE-425/17		
SNAP RING	41TE-AE-425/27		
SNAP RING	41TE-AE-425/31		

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

SPACER, Final Drive, 1.30mm .....	41TE-AE- 240/43	SPACER, Output Shaft, 3.74mm .....	41TE-AE- 440/18
SPACER, Final Drive, 1.34mm .....	31TH-215/16	SPACER, Output Shaft, 3.78mm .....	41TE-AE- 415/17
SPACER, Final Drive, 1.34mm .....	41TE-AE- 240/44	SPACER, Output Shaft, 3.78mm .....	41TE-AE- 440/19
SPACER, Final Drive, 1.38mm .....	31TH-215/17	SPACER, Output Shaft, 3.82mm .....	41TE-AE- 415/18
SPACER, Final Drive, 1.38mm .....	41TE-AE- 240/45	SPACER, Output Shaft, 3.82mm .....	41TE-AE- 440/20
SPACER, Final Drive, 1.42mm .....	31TH-215/18	SPACER, Output Shaft, 3.86mm .....	41TE-AE- 415/19
SPACER, Final Drive, 1.42mm .....	41TE-AE- 240/46	SPACER, Output Shaft, 3.86mm .....	41TE-AE- 440/21
SPACER, Final Drive, 1.46mm .....	31TH-215/19	SPACER, Output Shaft, 3.90mm .....	41TE-AE- 415/20
SPACER, Final Drive, 1.46mm .....	41TE-AE- 240/47	SPACER, Output Shaft, 3.90mm .....	41TE-AE- 440/22
SPACER, Final Drive, 1.50mm .....	31TH-215/20	SPACER, Output Shaft, 3.94mm .....	41TE-AE- 415/21
SPACER, Final Drive, 1.50mm .....	41TE-AE- 240/48	SPACER, Output Shaft, 3.94mm .....	41TE-AE- 440/23
SPACER, Final Drive, 1.54mm .....	31TH-215/21	SPACER, Output Shaft, 3.98mm .....	41TE-AE- 415/22
SPACER, Final Drive, 1.54mm .....	41TE-AE- 240/49	SPACER, Output Shaft, 4.02mm .....	41TE-AE- 440/24
SPACER, Final Drive, 1.58mm .....	31TH-215/22	SPACER, Output Shaft, 4.02mm .....	41TE-AE- 415/23
SPACER, Final Drive, 1.58mm .....	41TE-AE- 240/50	SPACER, Output Shaft, 4.06mm .....	41TE-AE- 440/25
SPACER, Final Drive, 1.62mm .....	31TH-215/23	SPACER, Output Shaft, 4.06mm .....	41TE-AE- 415/24
SPACER, Final Drive, 1.62mm .....	41TE-AE- 240/51	SPACER, Output Shaft, 4.10mm .....	41TE-AE- 440/26
SPACER, Final Drive, 1.66mm .....	31TH-215/24	SPACER, Output Shaft, 4.10mm .....	41TE-AE- 415/25
SPACER, Final Drive, 1.66mm .....	41TE-AE- 240/52	SPACER, Output Shaft, 4.14mm .....	41TE-AE- 440/27
SPACER, Final Drive, 1.70mm .....	31TH-215/25	SPACER, Output Shaft, 4.14mm .....	41TE-AE- 415/26
SPACER, Final Drive, 1.70mm .....	41TE-AE- 240/53	SPACER, Output Shaft, 4.18mm .....	41TE-AE- 440/28
SPACER, Final Drive, 1.74mm .....	31TH-820/17	SPACER, Output Shaft, 4.18mm .....	41TE-AE- 415/27
SPACER, Final Drive, 1.78mm .....	31TH-820/18	SPACER, Output Shaft, 4.22mm .....	41TE-AE- 440/29
SPACER, Final Drive, 1.82mm .....	31TH-820/19	SPACER, Output Shaft, 4.22mm .....	41TE-AE- 415/28
SPACER, Final Drive, 1.86mm .....	31TH-820/20	SPACER, Output Shaft, 4.26mm .....	41TE-AE- 440/30
SPACER, Final Drive, 2.02mm .....	31TH-215/26	SPACER, Output Shaft, 4.26mm .....	41TE-AE- 415/29
SPACER, Final Drive, 2.02mm .....	41TE-AE- 240/54	SPACER, Output Shaft, 4.30mm .....	41TE-AE- 440/31
SPACER, Final Drive, 2.06mm .....	31TH-215/27	SPACER, Output Shaft, 4.30mm .....	41TE-AE- 415/30
SPACER, Final Drive, 2.06mm .....	41TE-AE- 240/55	SPACER, Output Shaft, 4.34mm .....	41TE-AE- 440/32
SPACER, Output Shaft, 12.65mm .....	31TH-460/13	SPACER, Output Shaft, 4.34mm .....	41TE-AE- 415/31
SPACER, Output Shaft, 13.65mm .....	31TH-460/14	SPACER, Output Shaft, 4.38mm .....	41TE-AE- 440/33
SPACER, Output Shaft, 13.65mm .....	31TH-460/22	SPACER, Output Shaft, 4.38mm .....	41TE-AE- 415/32
SPACER, Output Shaft, 14.99mm .....	31TH-460/15	SPACER, Output Shaft, 4.42mm .....	41TE-AE- 440/34
SPACER, Output Shaft, 3.46mm .....	41TE-AE- 415/9	SPACER, Output Shaft, 4.42mm .....	41TE-AE- 415/33
SPACER, Output Shaft, 3.46mm .....	41TE-AE- 440/12	SPACER, Sun Gear .....	31TH-445/9
SPACER, Output Shaft, 3.50mm .....	41TE-AE- 415/10	SPACER, Transfer Shaft, 0.94mm(.037") .....	31TH-425/10
SPACER, Output Shaft, 3.50mm .....	41TE-AE- 440/13		
SPACER, Output Shaft, 3.54mm .....	41TE-AE- 415/11		
SPACER, Output Shaft, 3.54mm .....	41TE-AE- 440/14		
SPACER, Output Shaft, 3.58mm .....	41TE-AE- 415/12		
SPACER, Output Shaft, 3.58mm .....	41TE-AE- 440/15		
SPACER, Output Shaft, 3.62mm .....	41TE-AE- 415/13		
SPACER, Output Shaft, 3.66mm .....	41TE-AE- 415/14		
SPACER, Output Shaft, 3.66mm .....	41TE-AE- 440/16		
SPACER, Output Shaft, 3.70mm .....	41TE-AE- 415/15		
SPACER, Output Shaft, 3.70mm .....	41TE-AE- 440/17		
SPACER, Output Shaft, 3.74mm .....	41TE-AE- 415/16		

SPACER, Transfer Shaft, 0.99mm(.039")	31TH-425/11	SPRING, Drive Lower Case	41TE-AE-425/29
SPACER, Transfer Shaft, 1.04mm(.041")	31TH-425/12	SPRING, Front Clutch	31TH-435/9
SPACER, Transfer Shaft, 1.09mm(.043")	31TH-425/13	SPRING, Front Coil	002-145/5
SPACER, Transfer Shaft, 1.14mm(.045")	31TH-425/14	SPRING, Fuel Filler Door	SRS-915/27
SPACER, Transfer Shaft, 1.19mm(.047")	31TH-425/15	SPRING, Gearshift Lever	019-245/6
SPACER, Transfer Shaft, 1.24mm(.051")	31TH-425/16	SPRING, Governor Valve	31TH-620/2
SPACER, Transfer Shaft, 1.29mm(.052")	31TH-425/17	SPRING, Ignition Tumbler, Sidebar	23D-105/8
SPACER, Transfer Shaft, 1.34mm(.053")	31TH-425/18	SPRING, Kickdown Servo Piston	31TH-725/4
SPACER, Transfer Shaft, 1.39mm(.055")	31TH-425/19	SPRING, Lock Cylinder Tumbler	23D-105/43
SPACER, Transfer Shaft, 1.84mm(.072")	31TH-425/20	SPRING, Low/Reverse Clutch Piston	41TE-AE-440/4
SPACER, Transfer Shaft, 2.29mm(.090")	31TH-425/21	SPRING, Oil Pressure Relief Valve	2.4L-710/16
SPACER, Transfer Shaft, 3.22mm	41TE-AE-415/3	SPRING, Oil Pressure Relief Valve	3.8L-710/17
SPACER, Transfer Shaft, 3.26mm	41TE-AE-415/5	SPRING, Oil Pressure Relief Valve	3.3L6T-710/19
SPACER, Transfer Shaft, 3.30mm	41TE-AE-415/6	SPRING, Overdrive Piston	41TE-AE-425/45
SPACER, Transfer Shaft, 3.34mm	41TE-AE-415/7	SPRING, Parking Sprag	31TH-740/6
SPACER, Transfer Shaft, 3.38mm	41TE-AE-415/8	SPRING, Parking Sprag Return	41TE-AE-740/2
SPACER, Transfer Shaft, 4.46mm	41TE-AE-415/34	SPRING, Rear Clutch	31TH-415/15
SPACER, Transfer Shaft, 4.50mm	41TE-AE-415/35	SPRING, Rear Clutch Piston	31TH-415/14
SPACER, Transfer Shaft, 4.54mm	41TE-AE-415/36	SPRING, Rear Leaf	017-145/1
SPACER, Transfer Shaft, 4.62mm	41TE-AE-415/37	SPRING, Rear Leaf	017-155/1
SPACER, Transfer Shaft, 4.66mm	41TE-AE-415/38	SPRING, Reverse Servo Piston	31TH-725/21
SPACER, Window Regulator	DRS-190/8	SPRING, Reverse Servo Piston	31TH-725/23
SPARK PLUG	008-1905/7	SPRING, Valve	3.8L-510/9
SPARK PLUG, RE-14-PLP5	008-1905/6	SPRING, Valve	2.4L-510/11
SPARK PLUGS--CABLES--COILS	008/1905	SPRING, Valve	3.3L6T-510/9
SPAT, Front Fender	ERS-220/2	SPROCKET PACKAGE, Camshaft	3.8L-610/5
SPAT, Front Fender	ERS-210/10	SPROCKET PACKAGE, Camshaft	3.3L6T-610/5
SPEAKER	08A-310/6	SRING AND ROLLER PACKAGE, Overrunning Clutch	31TH-460/8
SPEAKER, Front Door	08A-310/4	STABILIZER, Door Glass	DRS-190/10
SPEAKER, Front Door	DRS-190/5	STABILIZER, Sliding Door	DRS-310/31
SPEAKER, Instrument Panel	08A-310/1	STABILIZER, Sliding Door	SRS-810/13
SPEAKER, Instrument Panel	08A-310/2	STABILIZER, Sliding Door	SRS-815/13
SPEAKER, Rear, 6x9	08A-310/7	STARTER	008/105
SPEAKER, Rear, 6x9	08A-310/8	STARTER, Engine	008-105/1
SPEAKER, Tweeter	08A-310/9	STEM, Wheel Valve	022-140/3
SPEAKERS-ANTENNA	08A/310	STEM, Wheel Valve	022-240/3
SPEED CONTROL	014/1010	STIRRUP, Retainer Nut	31TH-425/25
SPEEDOMETER PINION	21P/120	STIRRUP, Retainer Nut	31TH-460/19
SPINDLE, CUPHOLDER	08A-105/40	STIRRUP, Retaining Nut	41TE-AE-440/68
SPRING	IRS-820/22	STOP, Fuel Filler Door To Sliding Door Lockout	DRS-310/54
SPRING	IRS-820/23	STRAP KIT, Bike Carrier Latch	001-210/3
SPRING KIT, Brake Shoe Hold Down	005-220/15	STRAP KIT, Bike Carrier Latch	001-212/3
SPRING KIT, Rear Seat Riser	IRS-815/30	STRAP KIT, Luggage Carrier	001-220/2
SPRING, 2nd And 4th Clutch Piston	41TE-AE-440/63	STRAP KIT, Luggage Carrier	001-272/2
SPRING, Accumulator	31TH-725/14	STRAP KIT, Velcro	001-210/2
SPRING, Accumulator	31TH-725/27	STRAP KIT, Velcro	001-212/2
SPRING, Accumulator	41TE-AE-725/1	STRAP, A/C Unit Mounting	024-120/18
SPRING, Accumulator	41TE-AE-725/2	STRAP, A/C Unit Mounting	024-130/17
SPRING, Accumulator	41TE-AE-725/9	STRAP, A/C Unit Mounting	024-140/17
SPRING, Accumulator	41TE-AE-715/11	STRAP, Cargo Tie Down	001-214/3
SPRING, Accumulator	41TE-AE-715/20	STRAP, Cargo Tie Down	001-216/3
SPRING, Brake Auto Adjuster Lever	005-210/14	STRAP, Cargo Tie Down	001-230/3
SPRING, Brake Shoe Anchor	005-210/7	STRAP, Cargo Tie Down	001-232/3
SPRING, Brake Shoe Hold Down	005-210/5	STRAP, Fuel Tank	014-110/2
SPRING, Brake Shoe Return	005-210/8	STRAP, Fuel Tank	014-110/3
SPRING, Brake Shoe Return	005-210/17	STRAP, Ground	08A-310/16
SPRING, Cylinder Return	23D-105/16	STRAP, Ground, Fuel Filler Tube	014-110/6
SPRING, Cylinder Return	23D-105/31	STRAP, Ground, Fuel Filler Tube	008-1605/5
SPRING, Door and Deck Tumbler	23D-105/14	STRAP, Radio Noise Suppression	008-1605/6
SPRING, Door and Deck Tumbler	23D-105/27	STRAP, Radio Noise Suppression	08A-310/24
		STRAP, Retaining	31TH-425/26
		STRAP, Retaining	31TH-460/20
		STRAP, Retaining	41TE-AE-440/69
		STRAP, Tie	001-295/4
		STRAP, Tie	001-295/5
		STRAP, Tie	001-295/9
		STRAP, Tie	019-720/6
		STRAP, Tie	001-130/13
		STRAP, Tie	001-142/12

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

STRAP, Tie	008-1205/6	SUPPORT, Luggage Rack	SRS-1610/7
STRAP, Tie	008-1210/6	SUPPORT, Parking Sprag Rod	31TH-740/4
STRAP, Tie	008-1605/2	SUPPORT, Radiator	007-175/8
STRAP, Tie	2.4L-320/4	SUPPORT, Radiator	007-105/16
STRAP, Tie	3.8L-320/4	SUPPORT, Radiator	024-220/10
STRAP, Tie	008-1605/14	SUPPORT, Radiator Grille	013-260/12
STRAP, Tie	3.3L6T-320/4	SUPPORT, Rear Fascia	013-360/1
STRAP, Tie	3.3L6T-310/14	SUPPORT, Sliding Door Track	SRS-915/34
STRIKER AND BUMPER, Door Latch	DRS-180/31	SUPPORT, Steering Column	SRS-610/16
STRIKER PACKAGE, Sliding Door	SRS-915/1	SUPPORT, Transmission	009-140/5
STRIKER PACKAGE, Sliding Door	DRS-310/37	SUPPORT, Transmission	009-160/5
STRIKER PACKAGE, Sliding Door	IRS-420/15	SUSPENSION, FRONT	002/145
STRIKER, Console Lid Catch	08A-410/3	SUSPENSION, REAR-ALL WHEEL DRIVE	017/155
STRIKER, Door	SRS-915/38	SUSPENSION, REAR-FRONT WHEEL DRIVE	017/145
STRIKER, Glove Box Door Latch	08A-105/36	SWITCH AND BEZEL, Lighting Control	008-805/15
STRIKER, Hood Latch	SRS-520/10	SWITCH AND BEZEL, Lighting Control	08A-105/16
STRIKER, Liftgate	SRS-1320/12	SWITCH AND LAMP, Glove Box	001-810/7
STRIKER, Sliding Door	SRS-915/2	SWITCH AND LAMP, Glove Box	008-805/11
STRIKER, Sliding Door	DRS-310/38	SWITCH AND LAMP, Glove Box	08A-105/33
STRIKER, Sliding Door Stop	SRS-815/4	SWITCH AND LAMP, Glove Box	08A-410/19
STRIKER, Sliding Door Stop	SRS-815/6	SWITCH, Adjustable Pedals	005-650/10
STRIKER, Sliding Door Stop	SRS-915/5	SWITCH, Brake Fluid Level	005-416/5
STRIKER, Sliding Door Stop	DRS-310/50	SWITCH, Brake Fluid Level	008-815/17
STRUT, Bracket	SRS-1330/11	SWITCH, Door Ajar	008-815/19
STRUT, Engine	2.4L-810/14	SWITCH, Door Ajar	008-815/20
STRUT, Intake Manifold	2.4L-810/15	SWITCH, Door Lock	008-815/2
STRUT, Kickdown Band	31TH-520/2	SWITCH, Ignition	008-805/5
STRUT, Parking Brake	005-210/16	SWITCH, Key Position	008-815/8
STRUT, Pump Bracket	019-520/3	SWITCH, Key Position	008-815/11
STRUT, Reverse Band	31TH-520/9	SWITCH, Lift Motor	008-815/12
STUD	002-145/22	SWITCH, Liftgate	008-815/18
STUD	013-360/13	SWITCH, Liftgate Release	008-815/13
STUD	008-1105/15	SWITCH, Memory Selector	008-815/7
STUD, A/C Heater Housing	024-120/6	SWITCH, Mirror	008-805/1
STUD, A/C Heater Housing	024-130/6	SWITCH, Multifunction	008-805/2
STUD, A/C Heater Housing	024-140/6	SWITCH, Neutral, Safety, Back Up	008-810/1
STUD, Air Cleaner/Resonator Mtg., M8x1.25x16.5	014-810/12	SWITCH, Oil Pressure	008-605/7
STUD, Air Cleaner/Resonator Mtg., M8x1.25x16.5	014-830/11	SWITCH, Oil Pressure	008-810/2
STUD, Double Ended	008-1905/22	SWITCH, Oil Pressure	008-615/10
STUD, Double Ended, M10 x 1.50 x M8 x 1.25 x 78.60	008-105/6	SWITCH, Overhead Console	08A-405/2
STUD, Double Ended, M12x1.75/9x67	31TH-520/5	SWITCH, Parking Brake	004-142/10
STUD, Hub	005-155/8	SWITCH, Parking Brake	008-805/16
STUD, Hub	005-220/11	SWITCH, Power Window	008-815/3
STUD, M10-1.50x44	08A-105/57	SWITCH, Programing Bypass	001-910/7
STUD, M6x1.00mmx48.80mm	019-245/11	SWITCH, Rear Blower	024-310/5
STUD, M6x1.00x40.00	2.4L-620/13	SWITCH, Rear Blower	008-815/10
STUD, M8x1.25x41.00	41TE-AE-220/7	SWITCH, Rear Wiper/Washer and Hazard	008-805/9
STUD, M8x1.25x44.80	2.4L-210/13	SWITCH, Rear Wiper/Washer and Hazard	08A-105/22
STUD, M8x1.25x44.80	2.4L-810/11	SWITCH, Rear Wiper/Washer, Hazard and Heated Seat	008-805/10
STUD, Weld, M5x1.60x14	024-230/16	SWITCH, Remote Radio	019-145/9
STUD, Wheel	002-145/17	SWITCH, Remote Radio	008-805/20
STUD, Wheel, M12-1.50x45	005-210/28	SWITCH, Seat	IRS-540/5
STUFFER	SRS-610/34	SWITCH, Seat	008-815/14
STUFFER, Sliding Door Track Lower	SRS-915/32	SWITCH, Sliding Door	008-815/9
SUPPORT, Annulus Gear	31TH-445/4	SWITCH, Speaker	001-140/7
SUPPORT, Armrest	IRS-610/11	SWITCH, Speed Control	019-145/7
SUPPORT, Armrest	IRS-615/11	SWITCH, Speed Control	019-145/8
SUPPORT, Armrest	IRS-620/12	SWITCH, Speed Control	008-805/17
SUPPORT, Armrest	IRS-625/12	SWITCH, Speed Control	008-805/18
SUPPORT, Armrest	IRS-630/10	SWITCH, Stop Lamp	005-645/7
SUPPORT, Armrest	IRS-635/10	SWITCH, Stop Lamp	008-805/12
SUPPORT, B-Pillar	SRS-910/14	SWITCH, Traction Control	008-805/19
SUPPORT, Cowl Grille	23D-205/7	SWITCH, Underhood	008-815/1
SUPPORT, Cowl Plenum	SRS-610/7	SWITCHES, BODY	008/815
SUPPORT, Engine Mount	009-140/1	SWITCHES, INSTRUMENT PANEL AND CONSOLE	008/805
SUPPORT, Engine Mount	009-140/3	SWITCHES, POWERTRAIN	008/810
SUPPORT, Engine Mount	009-140/7		
SUPPORT, Engine Mount	009-160/1	<b>-T-</b>	
SUPPORT, Engine Mount	009-160/3	TANK, FUEL	014/110
SUPPORT, Engine Mount	009-160/7	TANK, Fuel	014-110/1
SUPPORT, Governor	31TH-620/11	TAPE, Anti-Rattle	DRS-310/56
SUPPORT, Jack	SRS-915/25	TAPE, C Pillar	ERS-210/9
SUPPORT, Jounce Bumper	017-155/28	TAPE, C Pillar	ERS-220/15
SUPPORT, Luggage Rack	SRS-1610/3	TAPE, Hole Cover, 50x50x1 mm	SRS-810/2
SUPPORT, Luggage Rack	SRS-1610/4	TAPE, Hole Cover, 50x50x1 mm	IRS-1010/4
SUPPORT, Luggage Rack	SRS-1610/5	TAPE, Radio Connector, Foam	001-295/8
		TAPE, Radio Connector, Foam	008-1605/7
		TAPE, Sliding Door Inner Panel Reflector	DRS-310/55
		TAPPET, Valve	3.8L-510/14

TAPPET, Valve	3.3L6T-510/14	TRANSAXLEPACKAGE,WITHTORQUECONVERTER	31TH-120/1
TAPPET, Valve, .001 Oversize	3.8L-510/15	TRANSAXLEPACKAGE,WITHTORQUECONVERTER	41TE-AE-120/1
TAPPET, Valve, .008 Oversize	3.8L-510/16	TRANSDUCER PACKAGE, A/C Pressure	024-220/21
TAPPING PLATE	SRS-1330/13	TRANSMITTER, Alarm or Keyless	001-910/4
TAPPING PLATE, Shoulder Belt	SRS-910/4	TRANSMITTER, Audio Control	08A-310/28
TAPPING PLATE, Side Door Stabilizer, Right	SRS-810/9	TRANSMITTER, Keyless Entry	001-920/3
TAPPING PLATE, Striker	SRS-810/6	TRANSMITTER, Keyless Entry	008-405/23
TAPPING PLATE, Striker	SRS-1310/3	TRANSMITTER, Keyless Entry	23D-105/35
TAPPING PLATE, Striker	SRS-810/12	TRAY, Battery	013-110/8
TAPPING PLATE, Striker	SRS-910/10	TRAY, Battery	008-1005/1
TEE, Hose, .25x.25x.25	014-1010/9	TRAY, Battery	014-1010/8
TENSIONER PACKAGE, Belt	2.4L-610/8	TRAY, Floor Console	001-810/5
TENSIONER, Belt	007-404/3	TRAY, Floor Console	001-810/13
TENSIONER, Belt	007-425/1	TRAY, Floor Console	08A-410/15
TENSIONER, Belt	008-215/5	TRAY, Floor Console	08A-410/22
TENSIONER, Chain	2.4L-620/9	TRAY, Molded Cargo	IRS-310/8
TERMINAL, Eyelet	008-1605/8	TRIM RING, Ignition Key Cylinder	008-805/8
TETHER, Fuel Filler Cap	014-210/6	TRIM RING, Ignition Key Cylinder	019-245/20
THERMOSTAT, Water Pump, 195 Degrees	007-105/8	TRIM RING, Ignition Key Cylinder	23D-105/37
THERMOSTAT, Water Pump, 195 Degrees	007-175/21	TROUGH PACKAGE	SRS-910/11
THIRD SEAT - 3 PASSENGER	IRS/640	TROUGH, Carrier Cover	2.4L-620/10
THROTTLE BODY	008-615/8	TROUGH, Power Take Of Unit	088-120/53
THROTTLE BODY	014-640/1	TUBE & HOSE, Supply & Return	024-205/14
THROTTLE BODY	014-660/2	TUBE & HOSE, Supply & Return w/Aux. Heater	024-207/1
THROTTLE BODY 2.4L [EDZ]	014/640	TUBE & HOSE, Supply & Return w/Aux. Heater	024-230/13
THROTTLE BODY 3.3L-3.8L [EGA],[EGH],[EGM]	014/660	TUBE, Brake	005-431/7
THROTTLE CONTROLS 2.4L [EDZ]	014/740	TUBE, Brake	005-431/8
THROTTLECONTROLS3.3L-3.8L[EGA],[EGH],[EGM]	014/760	TUBE, Brake	005-431/9
THRUST BEARING	41TE-AE-425/6	TUBE, Brake	005-561/6
THRUST BEARING	41TE-AE-425/36	TUBE, Brake	005-561/8
THRUST BEARING	41TE-AE-440/41	TUBE, Brake	005-561/9
THRUST BEARING	41TE-AE-440/56	TUBE, Brake	005-431/10
THRUST BEARING, Rear Sun Gear, Front	41TE-AE-440/43	TUBE, Brake	005-561/10
THRUST WASHER, Annulus Gear	31TH-445/2	TUBE, Brake	005-565/20
THRUST WASHER, Oil Pump	31TH-320/2	TUBE, Brake	005-565/24
THRUST WASHER, Output Shaft, 1.98-2.03mm	31TH-415/7	TUBE, Convoluted	008-1605/9
THRUST WASHER, Output Shaft, 2.16-2.21mm	31TH-415/8	TUBE, Drain	008-1005/5
THRUST WASHER, Output Shaft, 2.34-2.39mm	31TH-415/9	TUBE, EGR	025-240/2
THRUST WASHER, Overrunning Clutch	31TH-460/10	TUBE, EGR	025-260/4
THRUST WASHER, Planet Pinion	41TE-AE-440/71	TUBE, Engine Oil Indicator	2.4L-710/5
THRUST WASHER, Planetary Carrier	31TH-445/6	TUBE, Evaporator Housing	024-120/11
THRUST WASHER, Planetary Carrier	31TH-460/3	TUBE, Evaporator Housing	024-130/11
THRUST WASHER, Planetary Carrier	31TH-445/13	TUBE, Evaporator Housing	024-140/11
THRUST WASHER, Rear Clutch	31TH-415/4	TUBE, Filler	41TE-AE-220/6
THRUST WASHER, Rocker Arm	3.8L-510/3	TUBE, Fuel Filler	014-210/1
THRUST WASHER, Rocker Arm	3.3L6T-510/3	TUBE, Fuel Vapor	014-310/7
THRUST WASHER, Second and Fourth Clutch	41TE-AE-440/64	TUBE, Fuel Vapor	025-310/21
TIE STRAP	008-1605/10	TUBE, Heater	024-230/7
TIMING BELT AND COVER 2.4L [EDZ]	2.4L/610	TUBE, Heater Core	024-120/16
TIMING CHAIN AND COVER 3.3L [EGA],[EGM]	3.3L6T/610	TUBE, Heater Core	024-130/15
TIMING CHAIN AND COVER 3.8L [EGH]	3.8L/610	TUBE, Heater Core	024-140/15
TOOL, Screw Driver	001-214/4	TUBE, Junction Block to Valve	005-569/4
TOOL, Screw Driver	001-216/5	TUBE, Junction Block to Valve	005-569/5
TOOL, Screw Driver	001-292/2	TUBE, Junction Block to Valve	005-569/7
TORQUE ARM, Rear Axle	003-115/13	TUBE, Junction Block to Valve	005-569/8
TOWER PACKAGE, Front Suspension	SRS-410/7	TUBE, Junction Block to Valve	005-431/11
TRACK, Sliding Door	SRS-815/1	TUBE, Junction Block to Valve	005-431/12
TRACK, Sliding Door	SRS-815/5	TUBE, Oil Filler	3.8L-710/9
TRACK, Sliding Door	SRS-815/7	TUBE, Oil Filler	3.3L6T-710/10
TRACK, Sliding Door	SRS-815/9	TUBE, Oil Pickup	2.4L-710/9
TRACK, Sliding Door	SRS-915/9	TUBE, Roll Stock, .25 I.D.	025-410/5
TRACK, Sliding Door	SRS-915/15	TUBE, Roll Stock, .25 I.D.	025-410/7
TRACK, Sliding Door	SRS-915/31	TUBE, Roll Stock, .25 I.D.	025-490/10
TRAILER TOW HARNESS	001/295	TUBE, Spark Plug	008-1905/20
TRANS. OIL COOLER AND LINES	007/630	TUBE, Transmission Oil Filler	31TH-210/5
TRANSAXLE ASSEMBLY	31TH/120	TUBE, Valve Body	31TH-715/16
TRANSAXLE ASSEMBLY	41TE-AE/120	TUBE, Water Inlet	007-207/5
TRANSAXLE MOUNTING AND MISC. PARTS	41TE-AE/220	TUBE, Water Inlet	007-225/8
TRANSAXLE MOUNTING AND MISCELLANEOUS PARTS	31TH/210	TUBE, Wiper Drain Module	23D-205/20
		TUBE, Wiper Drain Module	23D-205/23
		TUMBLER, Door and Deck Number 1, Wide	23D-105/10
		TUMBLER, Door and Deck Number 1, Wide	23D-105/23
		TUMBLER, Door and Deck Number 2, Wide	23D-105/11
		TUMBLER, Door and Deck Number 2, Wide	23D-105/24
		TUMBLER, Door and Deck Number 3, Wide	23D-105/12

**2002 CHRYSLER, DODGE MINIVAN (RS)  
PARTS CATALOG**

TUMBLER, Door and Deck Number 3, Wide . . . . . 23D-105/25  
 TUMBLER, Door and Deck Number 4, Wide . . . . . 23D-105/13  
 TUMBLER, Door and Deck Number 4, Wide . . . . . 23D-105/26  
 TUMBLER, Ignition Number 1 . . . . . 23D-105/39  
 TUMBLER, Ignition Number 1, Sidebar . . . . . 23D-105/4  
 TUMBLER, Ignition Number 2 . . . . . 23D-105/40  
 TUMBLER, Ignition Number 2, Sidebar . . . . . 23D-105/5  
 TUMBLER, Ignition Number 3 . . . . . 23D-105/41  
 TUMBLER, Ignition Number 3, Sidebar . . . . . 23D-105/6  
 TUMBLER, Ignition Number 4 . . . . . 23D-105/42  
 TUMBLER, Ignition Number 4, Sidebar . . . . . 23D-105/7

**-U-**

U-CLIP, Grille To Facia . . . . . 013-260/11  
 U-NUT, Headlamp . . . . . 008-1105/11  
 U-NUT, M10-1.50 . . . . . 013-110/21  
 U-NUT, M6 x 1.00, M6x1.00 . . . . . 022-340/1  
 U-NUT, M8x1.25 . . . . . 022-410/1

**-V-**

VALVE BODY . . . . . 31TH-715/5  
 VALVE BODY . . . . . 31TH/715  
 VALVE BODY . . . . . 41TE-AE/715  
 VALVE BODY, Complete . . . . . 41TE-AE-715/2  
 VALVE CORE, WHEEL SENSOR VALVE, ALUMINUM . . . . . 022-140/12  
 VALVE KIT, Expansion . . . . . 024-150/8  
 VALVE KIT, Expansion . . . . . 024-210/19  
 VALVE KIT, Expansion . . . . . 024-220/25  
 VALVE KIT, Expansion . . . . . 024-230/15  
 VALVE, Brake Booster Check . . . . . 005-343/4  
 VALVE, Charging . . . . . 024-220/4  
 VALVE, Charging . . . . . 024-210/15  
 VALVE, Check . . . . . 024-220/24  
 VALVE, Check, 1/4 . . . . . 014-1010/10  
 VALVE, Cooler Bypass . . . . . 31TH-215/47  
 VALVE, Cooler Bypass . . . . . 41TE-AE-240/30  
 VALVE, EGR . . . . . 025-240/1  
 VALVE, EGR . . . . . 025-260/2  
 VALVE, Exhaust, .015" O/S . . . . . 2.4L-510/2  
 VALVE, Exhaust, Standard . . . . . 2.4L-510/1  
 VALVE, Exhaust, Standard . . . . . 3.8L-510/12  
 VALVE, Exhaust, Standard . . . . . 3.3L6T-510/12  
 VALVE, Governor . . . . . 31TH-620/1  
 VALVE, Governor . . . . . 31TH-620/6  
 VALVE, Height Sensing Brake . . . . . 005-569/10  
 VALVE, Intake, .015" O/S . . . . . 2.4L-510/4  
 VALVE, Intake, Standard . . . . . 2.4L-510/3  
 VALVE, Intake, Standard . . . . . 3.8L-510/11  
 VALVE, Intake, Standard . . . . . 3.3L6T-510/11  
 VALVE, PCV . . . . . 2.4L-910/2  
 VALVE, PCV . . . . . 3.8L-910/1  
 VALVE, PCV . . . . . 3.3L6T-910/1  
 VALVE, Proportioning . . . . . 005-569/3  
 VALVE, Proportioning . . . . . 005-565/22  
 VALVE, Transmission Regulator . . . . . 31TH-715/7  
 VALVE, Transmission Regulator . . . . . 41TE-AE-715/21  
 VALVE, Vent . . . . . 025-310/6  
 VAPOR CANISTER . . . . . 025/310  
 VENT, A/C Duct Left . . . . . 024-620/11  
 VENT, A/C Duct Right . . . . . 024-620/12  
 VENT, Headlamp . . . . . 008-1105/2  
 VENT, Headlamp . . . . . 008-1105/16  
 VENT, Rear Axle Overrunning Clutch . . . . . 003-115/15  
 VENT, Transaxle, Hose . . . . . 088-120/52  
 VENT, Transmission . . . . . 41TE-AE-715/7  
 VISCOUS COUPLING . . . . . 003-115/12  
 VISOR, Illuminated . . . . . IRS-110/7  
 VISOR, W/Mirror . . . . . IRS-110/6

**-W-**

WASHER . . . . . 003-135/1  
 WASHER . . . . . 005-561/3

WASHER . . . . . 005-565/7  
 WASHER . . . . . 005-565/15  
 WASHER . . . . . 3.8L-410/14  
 WASHER . . . . . 31TH-210/15  
 WASHER . . . . . 3.3L6T-410/14  
 WASHER PACKAGE, Side Gear Thrust . . . . . 31TH-820/7  
 WASHER PACKAGE, Side Gear Thrust . . . . . 41TE-AE-820/9  
 WASHER SYSTEM . . . . . 23D/210  
 WASHER, Coned, M22.6x45x3.42 . . . . . 41TE-AE-415/40  
 WASHER, Flared, 13x35.00x4.70 . . . . . 2.4L-610/10  
 WASHER, Flat, M23x38.0x405 . . . . . 002-245/6  
 WASHER, Flat, M23x38.0x405 . . . . . 003-420/4  
 WASHER, Flat, M23x38.0x405 . . . . . 005-210/22  
 WASHER, Flat, M6.82x17.00x1.75 . . . . . SRS-710/17  
 WASHER, Manual Valve Lever . . . . . 31TH-715/2  
 WASHER, Output Shaft . . . . . 31TH-425/23  
 WASHER, Output Shaft . . . . . 31TH-460/17  
 WASHER, Output Shaft . . . . . 41TE-AE-440/39  
 WASHER, Rear Axle Isolator . . . . . 003-135/2  
 WASHER, Rear Axle Isolator . . . . . 003-135/4  
 WASHER, Thrust . . . . . 31TH-820/5  
 WASHER, Thrust . . . . . 41TE-AE-820/7  
 WASHER, Wave, .520x.745 . . . . . IRS-610/9  
 WASHER, Wave, .520x.745 . . . . . IRS-615/9  
 WASHER, Wave, .520x.745 . . . . . IRS-630/8  
 WASHER, Wave, .520x.745 . . . . . IRS-635/8  
 WASHER, Wave, .520x.745 . . . . . IRS-820/6  
 WASHER, Wave, .520x.745 . . . . . IRS-535/24  
 WASHER, Wave, .520x.745 . . . . . IRS-620/10  
 WASHER, Wave, .520x.745 . . . . . IRS-625/10  
 WASHER, Wave, .520x.745 . . . . . IRS-815/15  
 WATER PUMP AND RELATED PARTS, 2.4L Engine . . . . . 007/207  
 WATERPUMPANDRELATEDPARTS, 3.3L-3.8L Engine . . . . . 007/225  
 WATERSHIELD, Front Door . . . . . DRS-180/2  
 WEATHERSTRIP, Door Panel . . . . . IRS-420/18  
 WEATHERSTRIP, Front Door . . . . . DRS-610/4  
 WEATHERSTRIP, Front Door . . . . . DRS-610/5  
 WEATHERSTRIP, Front Door . . . . . SRS-1010/2  
 WEATHERSTRIP, Front Door . . . . . SRS-810/15  
 WEATHERSTRIP, Front Door Belt . . . . . DRS-610/2  
 WEATHERSTRIP, Front Door Belt . . . . . DRS-610/3  
 WEATHERSTRIP, Hood to Cowl . . . . . SRS-610/10  
 WEATHERSTRIP, Liftgate Opening . . . . . SRS-1010/9  
 WEATHERSTRIP, Liftgate Opening . . . . . IRS-1010/12  
 WEATHERSTRIP, Liftgate Secondary Upper . . . . . SRS-1010/8  
 WEATHERSTRIP, Liftgate Secondary Upper . . . . . IRS-1010/11  
 WEATHERSTRIP, Rear Aperture Panel Glass . . . . . SRS-710/16  
 WEATHERSTRIP, Sliding Door . . . . . DRS-610/8  
 WEATHERSTRIP, Sliding Door . . . . . SRS-1010/4  
 WEATHERSTRIP, Sliding Door . . . . . SRS-915/12  
 WEATHERSTRIP, Sliding Door B Pillar . . . . . DRS-610/7  
 WEATHERSTRIP, Sliding Door B Pillar . . . . . SRS-1010/3  
 WEATHERSTRIP, Sliding Door Secondary . . . . . DRS-610/1  
 WEATHERSTRIP, Sliding Door Secondary . . . . . DRS-610/9  
 WEATHERSTRIP, Sliding Door Secondary . . . . . SRS-1010/1  
 WEATHERSTRIP, Sliding Door Secondary . . . . . SRS-1010/6  
 WEATHERSTRIP, Sliding Door Secondary . . . . . SRS-915/11  
 WEATHERSTRIP, Sliding Door Secondary . . . . . SRS-915/14  
 WEATHERSTRIPS . . . . . DRS/610  
 WEATHERSTRIPS . . . . . SRS/1010  
 WEIGHT, Wheel Balance Tape . . . . . 022-140/10  
 WHEEL, Aluminum . . . . . 022-140/5  
 WHEEL, SPARE . . . . . 022/410  
 WHEEL, STEERING . . . . . 019/145  
 WHEEL, Spare . . . . . 022-410/4  
 WHEEL, Steel . . . . . 022-140/1  
 WHEEL, Steering . . . . . 019-145/1  
 WHEELHOUSE, Rear Inner . . . . . SRS-910/18  
 WHEELHOUSE, Rear Outer . . . . . SRS-910/16  
 WHEELS AND HARDWARE . . . . . 022/140  
 WINCH, Spare Tire Carrier . . . . . 022-410/2  
 WINDSHIELD . . . . . SRS-710/1  
 WINDSHIELD WIPER SYSTEM . . . . . 23D/205

WINGNUT, Jack and Tire Hold Down . . . . .	022-340/4
WIRE COVER, Mirror . . . . .	SRS-710/9
WIRE TRACK, Sliding Door Left . . . . .	008-1505/18
WIRE TRACK, Sliding Door Right . . . . .	008-1505/17
WIRE, Three Passenger Adjuster . . . . .	IRS-825/17
WIRING . . . . .	08A-315/6
WIRING . . . . .	001-140/16
WIRING . . . . .	001-142/11
WIRING HARNESS REPAIR PKG. . . . .	008/1605
WIRING KIT, Alarm with Keyless . . . . .	001-914/6
WIRING KIT, Audio System Adapter . . . . .	08A-305/10
WIRING PACKAGE, Trailer Tow . . . . .	001-295/1
WIRING PACKAGE, Trailer Tow . . . . .	001-295/7
WIRING PACKAGE, Underhood Connector Repair . . . . .	008-1605/1
WIRING, A/C and HEATER . . . . .	024-120/19
WIRING, A/C and HEATER . . . . .	024-130/18
WIRING, A/C and HEATER . . . . .	024-140/18
WIRING, A/C and HEATER . . . . .	024-150/12
WIRING, A/C and HEATER . . . . .	008-1505/14
WIRING, Air Conditioning Dome Jumper . . . . .	08A-405/7
WIRING, Air Conditioning Dome Jumper . . . . .	008-1505/7
WIRING, Air Conditioning Dome Jumper . . . . .	008-1505/23
WIRING, BODY, DOORS & MISC. WIRING, . . . . .	008/1505
WIRING, Compact Disc Changer . . . . .	001-110/3
WIRING, Compact Disc Changer . . . . .	08A-305/8
WIRING, Console . . . . .	001-810/17
WIRING, DVD to Auxiliary Jack . . . . .	08A-315/7
WIRING, DVD to Auxiliary Jack . . . . .	001-142/10
WIRING, DVD to Screen . . . . .	08A-315/8
WIRING, DVD to Screen . . . . .	001-142/13
WIRING, Dome Lamp . . . . .	08A-405/6
WIRING, Dome Lamp . . . . .	008-1505/6
WIRING, Door Jumper . . . . .	008-1505/26
WIRING, Engine . . . . .	008-1205/1
WIRING, Engine . . . . .	008-1210/1
WIRING, Engine . . . . .	008-1905/17
WIRING, Front Door . . . . .	008-1505/9
WIRING, Front Door . . . . .	008-1505/10
WIRING, Fuel Rail . . . . .	008-1205/2
WIRING, Fuel Rail . . . . .	008-1210/2
WIRING, HEADLAMP TO DASH, . . . . .	008/1305
WIRING, Headlamp . . . . .	008-1105/13
WIRING, Headlamp to Dash . . . . .	008-1305/1
WIRING, Heated Seat . . . . .	008-1505/16
WIRING, INSTRUMENT PANEL, . . . . .	008/1405
WIRING, Instrument Panel . . . . .	008-1405/1
WIRING, Jumper . . . . .	005-650/9
WIRING, Jumper . . . . .	008-1505/27
WIRING, License Lamp . . . . .	008-1110/17
WIRING, License Lamp . . . . .	008-1505/13
WIRING, Liftgate . . . . .	008-1505/8
WIRING, Navigation Display . . . . .	001-130/9
WIRING, Navigation System . . . . .	001-130/6
WIRING, Power Seat . . . . .	008-1505/15
WIRING, Radio Adapter . . . . .	008-1505/22
WIRING, Sliding Door Left . . . . .	008-1505/11
WIRING, Sliding Door Right . . . . .	008-1505/12
WIRING, Trailer Tow - 4 Way . . . . .	001-295/10
WIRING, Trailer Tow Package . . . . .	008-1505/19
WIRING, Unified Body . . . . .	008-1505/1
WIRING, Windshield Wiper, 4 Way . . . . .	23D-205/10
WIRING--ENGINE & RELATED PARTS 2.4 [EDZ] . . . . .	008/1205
WIRING-ENGINE AND RELATED PARTS 3.3 [EGA, EGM], 3.8 [EGH] . . . . .	008/1210
WRENCH, Wheel Lug Nut . . . . .	022-340/3

**-Y-**

YOKE, Tappet Aligning . . . . .	3.8L-510/17
YOKE, Tappet Aligning . . . . .	3.3L6T-510/

