## 2006 ND Dakota

## Engine

Component	Fluids, Lubricants and Genuine Parts
Engine Coolant	Mopar Antifreeze/Coolant 5 Year/100,000 Mile Formula
	HOAT (Hybrid Organic Additive Technology) P/N
	5011764AB or equivalent.
Engine Oil	Use SAE 5W-30, API Certified, meeting material
	standard MS-6395.
Engine Oil Filter	Mopar Engine Oil Filter, P/N 5281090 or equivalent.
Spark Plugs	Refer to the Vehicle Emission Control Information label
	in the engine compartment.
Fuel Selection	3.7L/4.7L 87 Octane, (R+M)/2 Method
Fuel Selection	4.7L HO 91 Octane, (R+M)/2 Method (Recommend, Not
	Required.)

## Chassis

Component	Fluids, Lubricants and Genuine Parts.
Automatic Transmission	Mopar ATF+4, Automatic Transmission Fluid.
Manual Transmission (Getrag 238)	Mopar ATF+4, Automatic Transmission Fluid.
Transfer Case	Mopar ATF+4, Automatic Transmission Fluid.
Front Axle	SAE 75W-90 Multipurpose Type, GL-5 Gear Lubricant
	(MS9763).
Rear Axle	SAE 75W-140 Synthetic Gear Lubricant (MS-8985).
	Limited-slip rear axles require Mopar <sup>1</sup> / <sub>4</sub> ñêôlimited-slip
	additive (MS-10111). Four ounces (118 ml) should be
	added to the gear lubricant whenever a fluid change is
	made.
Brake Master Cylinder	Mopar DOT 3 and SAE J1703 should be used. If DOT 3
	brake fluid is not available, then DOT 4 is acceptable.
	Use only recommended brake fluids.
Power Steering Reservoir	Mopar ATF+4, Automatic Transmission Fluid.